


# FILM-TECH

**THE INFORMATION CONTAINED IN THIS ADOBE ACROBAT PDF FILE IS PROVIDED AT YOUR OWN RISK AND GOOD JUDGMENT.**

**THESE MANUALS ARE DESIGNED TO FACILITATE THE EXCHANGE OF INFORMATION RELATED TO CINEMA PROJECTION AND FILM HANDLING, WITH NO WARRANTIES NOR OBLIGATIONS FROM THE AUTHORS, FOR QUALIFIED FIELD SERVICE ENGINEERS.**

**IF YOU ARE NOT A QUALIFIED TECHNICIAN, PLEASE MAKE NO ADJUSTMENTS TO ANYTHING YOU MAY READ ABOUT IN THESE ADOBE MANUAL DOWNLOADS.**

**[WWW.FILM-TECH.COM](http://WWW.FILM-TECH.COM)**

	TITLE		NUMBER	REV	PAGE
	Tech Notice, DTS-ECP/6AD Serial Control		TN-E374	A	1 OF 5
DATE PREPARED	CREATED BY:	EFFECTIVE DATE	APPROVED BY:		
6/8/01	F. Pflaum	6/8/01			

DTS, 5171 Clareton Dr., Agoura Hills, CA 91301  
Ph. (818) 706-3525

Contact Document Control for the latest revision.

This document describes how to control the DTS-ECP/6AD cinema processor externally through the use of the serial interface. All of these commands operate the same through either the RS232 or RS422 interface of the DTS-ECP/6AD. This assumes that the DTS-ECP/6AD unit is installed with software version 1.06 or greater.

These commands are designed to allow control of the DTS-ECP/6AD to facilitate the implementation of a show control interface, automation control, or remote front panel.

## Connections

**RS232.** Connect from the port labeled RS-232 port on the back of the DTS-6AD to the control device. Refer to the manual for the required pin-out. The port is always initialized at 9600 baud 8N1 (8-bits, not parity, and 1 stop bit).

**RS422 (AUTOMATION).** Connect the port labeled AUTOMATION on the back of the DTS-6AD to the control device. Refer to the manual for the required pin-out. The port only operates at 9600 baud 8N1 (8-bits, not parity, and 1 stop bit). It is allowed to have more than one device connected to the automation port.

## Status

A change in the status of either the format, volume or mute causes a status string to automatically be transmitted through the AUTOMATION port. (It is not transmitted through the RS-232 port.) The following is the format for the status response:

```

Response:  Vvv<CR>
           Ff<CR>
           Mm
           Ee

           vv          Master fader value from 00 (0.0) to 99 (9.9)


           f           1          Select format assigned to the F1 key (usually Mono)
                   A          Projector input with A-type noise reduction
                   S          Projector input with SR noise reduction
                   X          External 6-channel input
                   D          DTS digital
                   N          Nonsync input

           m           +          Muted
                   -          Not muted

           e           -          No error
                   E          Error: Configuration settings lost on power-up.

```



	TITLE		NUMBER	REV	PAGE
	Tech Notice, DTS-ECP/6AD Serial Control		TN-E374	A	3 OF 5
DATE PREPARED	CREATED BY:	EFFECTIVE DATE	APPROVED BY:		
6/8/01	F. Pflaum	6/8/01			

DTS, 5171 Clareton Dr., Agoura Hills, CA 91301  
Ph. (818) 706-3525

Contact Document Control for the latest revision.

## ***Audio Format Command***

Selects the specified format. Responds with the new format after the selection is applied.

Format:        F<CR>            Respond with the current format only  
                   Fc<CR>            Select the format defined by 'c'

Response:     Fc<CR>

Values for c:    1                    Select format assigned to the F1 key (usually Mono)  
                   A                    Projector input with A-type noise reduction  
                   S                    Projector input with SR noise reduction  
                   X                    External 6-channel input  
                   D                    DTS digital  
                   N                    Nonsync input

## ***Key control***

Format:        Kc<CR>            Acts as a front panel a key press

Values for c:    F                    Format  
                   M                    Menu  
                   E                    Exit  
                   O                    OK  
                   1-8                F1-F8  
                   U                    Mute

## ***Mute command***


Mute or unmute the cinema processor.

Format:        M+<CR>            Mute  
                   M-<CR>            Unmute

## ***Timecode offset***

This is not the timecode reader offset adjustment. This is a separate offset that can be used when the DTS timecode is not on the film but goes through a tach to timecode converter. This offset should be used to match the audio start time (DTS TC = 60) according to the timecode received.

Format:        On<CR>            Selects the offset in timecode where n = -99999 to 99999

	TITLE		NUMBER	REV	PAGE
	Tech Notice, DTS-ECP/6AD Serial Control		TN-E374	A	4 OF 5
DATE PREPARED	CREATED BY:	EFFECTIVE DATE	APPROVED BY:		
6/8/01	F. Pflaum	6/8/01			

DTS, 5171 Clareton Dr., Agoura Hills, CA 91301  
Ph. (818) 706-3525

Contact Document Control for the latest revision.

## Select Reel

Substitute the directory entry number from the directory command (D<cr>) to play that reel selection. When a reel selection is made the reel number read from the timecode is ignored. Also there should not be a serial number in the timecode received.

Format:            S*n*<CR>            Where n= from 0 to the total number of reels on all the discs.

The command S0<CR> turns off the reel selection feature.

## Trailer directory

Format:            T<CR>

Lists the serial numbers of all trailers installed. This command is for informational purposes only.

Example trailer directory listing:

```

1) Drive A -- R14 SN=1045
2) Drive A -- R14 SN=4
3) Drive A -- R14 SN=15
4) Drive A -- R14 SN=56
5) Drive A -- R14 SN=71
6) Drive A -- R14 SN=257
7) Drive A -- R14 SN=414
8) Drive A -- R14 SN=469
9) Drive A -- R14 SN=528
10) Drive A -- R14 SN=612
11) Drive A -- R14 SN=613
12) Drive A -- R14 SN=688
13) Drive A -- R14 SN=699
14) Drive A -- R14 SN=735
15) Drive A -- R14 SN=942


```

## Volume Command

Sets or changes the master volume setting.

Format:            V<CR>            Response only  
                  V+<CR>            Volume up  
                  V-<CR>            Volume down  
                  V*nm*<CR>            Set master fader to n.m

Response:        V*nm*<CR>

	TITLE		NUMBER	REV	PAGE
	Tech Notice, DTS-ECP/6AD Serial Control		TN-E374	A	5 OF 5
DATE PREPARED	CREATED BY:	EFFECTIVE DATE	APPROVED BY:		
6/8/01	F. Pflaum	6/8/01			

DTS, 5171 Clareton Dr., Agoura Hills, CA 91301  
Ph. (818) 706-3525

Contact Document Control for the latest revision.

### ***Autoswitch Command***

This command is used to enable or disable the feature that automatically switches the cinema processor to DTS digital playback.

Format:            W<CR>            Response only  
                  W+<CR>            Enable autoswitch (power-on default)  
                  W-<CR>            Disable autoswitch

Response:        W+<CR> or W-<CR>

### ***Version***

Returns the version number for the software installed on the DTS-6AD or DTS-ECP.

Format:            X<CR>

Response:        CPU VERSION:        1.06<CR>  
                  DSP CONTROLLER:    1.03<CR>  
                  DSP FIRMWARE:     1.10<CR>  
                  E-<CR>