

# FILM-TECH

**THE INFORMATION CONTAINED IN THIS ADOBE ACROBAT PDF FILE IS PROVIDED AT YOUR OWN RISK AND GOOD JUDGMENT.**

**THESE MANUALS ARE DESIGNED TO FACILITATE THE EXCHANGE OF INFORMATION RELATED TO CINEMA PROJECTION AND FILM HANDLING, WITH NO WARRANTIES NOR OBLIGATIONS FROM THE AUTHORS, FOR QUALIFIED FIELD SERVICE ENGINEERS.**

**IF YOU ARE NOT A QUALIFIED TECHNICIAN, PLEASE MAKE NO ADJUSTMENTS TO ANYTHING YOU MAY READ ABOUT IN THESE ADOBE MANUAL DOWNLOADS.**

[WWW.FILM-TECH.COM](http://WWW.FILM-TECH.COM)



How to Use the  
**KODAK EKTAGRAPHIC CT1000**  
**16 mm Projector**



# INTRODUCTION

---

Continuing the traditional Kodak features of clear, bright images, and gentle, positive film handling, the *KODAK EKTAGRAPHIC* CT1000 16 mm Projector also brings you

**Channel Threading**—Threading film through the projector is fast and simple.

**Easy Review and Rewind**—Turn just one control.

**Convenience**—Easy setup, a built-in speaker, and a padded carrying handle, all in a compact and self-contained unit, make this projector convenient to use and store.

Before you start to use your new projector, be sure you read and understand these basic safety precautions:

## IMPORTANT SAFEGUARDS

1. Read and understand all instructions.
2. Maintain close supervision when the projector is used by anyone not fully acquainted with correct operating procedures.
3. Take special care to avoid burns that can result from touching hot parts. Allow the projector to cool before replacing a lamp or cleaning lenses.
4. Do not operate this projector with a damaged cord. If the unit has been dropped or damaged, have it examined by a qualified service representative before using it again.
5. Be careful to place all cords where you or others will not trip over them.
6. If an extension cord is necessary, use a 3-wire grounding-type cord with a minimum 5-ampere current rating. (Cords rated for less amperage may overheat.) Be sure to plug the power cord into a permanent, properly installed 3-wire power receptacle.
7. Never yank the cord to pull the plug from the outlet. Grasp the plug and pull it to disconnect it.
8. Do not disassemble this projector beyond the extent necessary to perform the routine maintenance procedures described in this manual. If further disassembly is required, take the projector to a qualified service representative, since incorrect reassembly can cause electric shock hazard.

## MAJOR PARTS AND CONTROLS

For your convenience, leave this page open so that you can refer to this figure while reading the sequential operating instructions.




Figure 1




Figure 2

# CONTENTS

---

	<i>Page</i>
SEQUENTIAL OPERATING INSTRUCTIONS . . . . .	1
Preparation . . . . .	1
Threading the Projector . . . . .	2
Projection . . . . .	3
Review . . . . .	3
After the Show . . . . .	3
Storing the Projector . . . . .	3
CONVENIENT FEATURES . . . . .	4
High-Normal Lamp Switch . . . . .	4
External Speaker Jack . . . . .	4
Microphone Jack . . . . .	4
TAKING CARE OF THE PROJECTOR . . . . .	5
Access . . . . .	5
Removing and Replacing the Projector	
Lens Cover . . . . .	5
Removing and Replacing the Front Cover . . . . .	5
Cleaning the Film Gate, Film Path,	
and Sound Optics . . . . .	6
Cleaning the Projector Lens . . . . .	7
Replacing the Projection Lamp . . . . .	8
Replacing the Exciter Lamp . . . . .	10
Replacing Fuses . . . . .	11
HAVING PROBLEMS? . . . . .	12
ACCESSORIES . . . . .	12
KODAK PUBLICATIONS . . . . .	12
SPECIFICATIONS . . . . .	13



# SEQUENTIAL OPERATING INSTRUCTIONS

---

## Preparation

1. Put the projector on a sturdy support, pointing at the center of the projection screen. Remove the protective dust cover.
2. Check that the master control switch (see Figure 1) is in the OFF position, then plug the power cord into a grounded 110- to 125-volt 60 Hz receptacle.
3. Raise the supply-reel arm and the take-up reel arm up to the operating position. They will lock in place.

4. Open the reel latch on the take-up reel arm to the unlocked position. Be sure the take-up reel is as big as, or bigger than, the supply reel. Put the take-up reel on the spindle and move the latch to the locked position. See Figure 3.
5. Open the latch on the supply-reel arm and put the supply reel on the spindle with the film coming off to the right of the reel, film perforations as shown in Figure 4. Move the latch to the locked position.



## Threading the Projector

1. Holding the film leader near the end, pull it under the supply-tension roller (see Figure 5), around the first threading guide (Figure 6), around the second threading guide (Figure 7), and under the tension roller (Figure 8).

2. Attach the leader to the take-up reel—If you are using the 800-foot reel supplied with the projector, it is not necessary to put the leader in a slot in the take-up reel hub, or tape the leader to the hub; just wind the leader onto the take-up reel, as shown in Figure 9. Then manually turn the take-up reel through two or three clockwise revolutions to take up any slack in the film.



Figure 5



Figure 6



Figure 7




Figure 8



Figure 9

## Projection

1. Turn the master control switch (see Figure 1) clockwise through  (forward) to  (lamp).
2. Adjust focus with the focus control (see Figure 1). If a frame line appears on the screen image, adjust the frame control (see Figure 1) until the frame line disappears. Adjust the elevation control (see Figure 1) as desired.
3. Wait for the first scene to come on the screen, then turn up the amplifier by turning the volume control (see Figure 10) clockwise. Adjust volume and tone by turning the controls clockwise or counterclockwise.

## Review

If you want to see a portion of the film again, turn the master control switch counterclockwise from  through  to OFF and then to . When the portion you want to see again has been rewound onto the supply reel, turn the master control switch clockwise to OFF. Pause very briefly at OFF, and then continue turning the control switch clockwise through  to .

## After the Show

1. Turn the master control switch counterclockwise to OFF. Turn the exciter lamp off by turning the volume control counterclockwise until it clicks.
2. If the tail end of the film is still attached to the supply reel, you can quickly rewind the film by turning the master control switch counterclockwise to . When the film is completely rewound onto the supply reel, turn the master control switch clockwise to OFF. Go to step 5.
3. If the tail end of the film has come off the supply reel, turn the take-up reel clockwise by hand

until all the film is on the take-up reel. Then attach the tail end to the supply reel hub as shown in Figure 11. Often the tail end is threaded into a slot in the hub, but it may instead be fastened with a small piece of tape, or simply wound onto the hub and kept there by winding more film over it.

4. Turn the master control switch counterclockwise to . When the film is completely rewound onto the supply reel, turn the master control switch clockwise to OFF.
5. Unlatch the supply reel and take it off the projector. Handle it carefully so you don't spill the film off the reel. Put the reel of film in its container.

## Storing the Projector

1. Unlatch and remove the take-up reel. If you are using the 800-foot reel supplied with the projector, snap the reel over the retaining pin in the reel-storage compartment in the back of the projector.
2. Push the arm release buttons and turn the reel arms to their storage position. (An accessory lens or lens attachment, such as the *KODAK EKTAGRAPHIC CT Bifocal Converter*, may keep the supply-reel arm from returning fully to its storage position.) Snap the reel latches to the locked position.
3. Check that the elevation foot is retracted all the way. (Turn the elevation control, Figure 1, to the left.) Take hold of the power cord plug and pull it out of the receptacle. (*Do not* unplug the projector by pulling on the power cord.) Put the cord in its storage compartment.
4. Put the dust cover over the projector. Along one side of the cover is a convenient pouch for storing brushes, extra reels, and this manual.





Figure 10



## CONVENIENT FEATURES

### High-Normal Lamp Switch

With this switch in the HIGH position, the projection lamp delivers maximum brightness. When this switch is in the NORMAL position, projection lamp brightness is reduced by approximately 20 percent, but lamp life is extended by approximately 240 percent, from 50 to 120 hours. (See SPECIFICATIONS on the inside back cover.) The high-normal lamp switch is under the front cover, above the exciter lamp. See Figure 27 on page 8.

### External Speaker Jack

When you have a large audience, or a high level of noise to overcome, you may want to use an external speaker. Plugging an external speaker into this jack (see Figure 12) automatically shuts off the built-in speaker. See SPECIFICATIONS on the inside back cover.




### Microphone Jack

You can use this projector as a public address system if you choose, by plugging a suitable microphone (see SPECIFICATIONS on the inside back cover) into the projector, plugging the projector into 110- to 125-volt 60 Hz source, and turning the amplifier volume up. (See Figure 10 on page 3.) It is not necessary that the projector be running in forward, although it can be.

It is necessary that the microphone have a straight plug (see Figure 13) rather than a right-angle one, because the tip of the plug must extend approximately 1¼ inches inside the surface of the projector.

Since plugging the microphone into the jack disconnects the input from the film's sound track, you can use the microphone to provide your own commentary or narration while a film is being projected. Unplugging the microphone restores the connection between sound track input and the projector amplifier.



# TAKING CARE OF THE PROJECTOR

## Access

Cleaning the projector components and replacing the projection and exciter lamps requires removal of the projector lens cover or the front cover, as described below.

**NOTE:** Normal operation and care do *not* require the removal of the *back* (gray) cover of the projector.

## Removing and Replacing the Projector Lens Cover

To remove, grasp cover as shown in Figure 14 and pull top first.



Figure 14




Figure 15



Figure 16

To replace, put the bottom of the cover between the guides, as shown in Figure 15, and gently push the top of the cover until it snaps into place.

## Removing and Replacing the Front Cover

To remove, grasp cover as shown in Figure 16, and gently pull it off.

To replace, rest the left guide pin in its hole as shown in Figure 17, then align the right guide pin with its hole and the frame control notch around the frame control as shown in Figure 18. Push gently on the cover until it snaps into place.




Figure 17




Figure 18

## Cleaning the Film Gate, Film Path, and Sound Optics

Clean the film gate whenever the screen image shows moving hairs or dust. This will depend upon how clean the films are before they are projected.

The entire film path should be inspected and cleaned whenever you have to replace a projection or exciter lamp, perhaps more often if the films being projected are dusty or dirty.

### *Cleaning the Film Gate*

1. Remove all film from the film path.
2. Turn the master control switch to OFF, and turn down the amplifier volume control until it "clicks."
3. Remove the projector lens cover, as described on page 5.



Figure 19

4. Hold the film gate pressure pad with your left hand, as shown in Figure 19, and pull the pressure pad out. When the projector is new and the spring is stiff, it may be necessary to pull firmly.
5. Use the small plastic brush with the stiff black bristles—supplied with the projector—to clean the film channel area of the pressure pad, and then wipe the entire pad with a lint-free cloth.
6. Use the wire-handled brush with white bristles—supplied with the projector—to clean the aperture and mask and rear of the projector lens, as shown in Figure 21.
7. Put the bottom pressure pad guide pin into the bottom slot as shown in Figure 22, and then gently push the top pin all the way into its slot.
8. Replace the projector lens cover, as described on page 5.




Figure 20




Figure 21




Figure 22

### *Cleaning the Film Path and Sound Optics*

1. Remove and clean the pressure pad, as described in steps 1 through 7 on page 6.
2. Remove the front cover, as described on page 5.
3. Use the wire-handled brush with white bristles—supplied with the projector—to clean the rollers, capstan, sprockets, sound optics, and solar cell as shown in Figure 23. Keep the brush itself clean with canned air or another brush.
4. Replace the projector lens cover and front cover, as described on page 5.

### **Cleaning the Projector Lens**

1. Raise the supply-reel arm to the operating position. Then remove the projector lens cover, as described on page 5.




Figure 23

2. Pull the focus-control knob away from the projector and slip the lens out of its housing as shown in Figure 24.
3. It is not necessary to disassemble the lens. Clean the glass surfaces with a soft lint-free cloth, KODAK Lens Cleaning Paper, or equivalent. If moisture is required, use a drop of KODAK Lens Cleaner or breathe on the lens. Do not use a wet cloth or treated paper or cloth—they could harm the coating on the lens surface.
4. Clean the lens barrel with a brush or cloth.
5. Replace the lens by pulling on the focus-control knob and sliding the lens back into its housing. Move the lens in and out until you hear the pin on the focus control click into the groove in the lens barrel. Turn the focus-control knob and check that the lens moves back and forth.
6. Replace the projector lens cover, as described on page 5.



Figure 24



Figure 25

## Replacing the Projection Lamp

1. Unplug the projector! See Figure 26.
2. Remove the front cover, as described on page 5.
3. Gently touch the housing covering the projection lamp. If it is hot, wait for it to cool.
4. Using a flat-blade screwdriver, loosen the lamp cover retaining screw (under the high-normal lamp switch) until the cover can be removed easily. See Figure 27.
5. Remove the cover, being careful not to damage the exciter lamp.
6. Be careful not to burn yourself on the projection lamp! Move the lamp out of its socket by pushing the ejector to the left, as shown in Figure 28, then slide the lamp out from under its retaining springs.
7. Be careful not to touch the small bulb or the inside reflective surface of the lamp; hold the new projection lamp so the pins line up with the socket, and slide the lamp between the holder and the retaining springs, as shown in Figure 29.



Figure 26




Figure 27




Figure 28




Figure 29

8. Push the base of the lamp into the socket until the lamp is stopped by the retaining pins, as shown in Figure 30. It is important that the lamp is firmly in its socket—otherwise, lamp performance may suffer, and the lamp and socket may overheat.
9. Be careful to not damage the exciter lamp when replacing the projection lamp cover. It will probably be easier if you put the guide at the bottom of the cover into the projector frame, as shown in Figure 31.




Figure 30




Figure 31

Then gently work the cover up against the projector frame, fitting the pin near the top of the cover into its hole in the projector frame. Tighten the retaining screw with the screwdriver until it holds the lamp cover firmly onto the projector.

10. Replace the front cover, as described on page 5.

**NOTE:** There is a convenient spare-lamp storage area, with retaining spring, inside the front cover, as shown in Figure 32.




Figure 32

## Replacing the Exciter Lamp

1. Unplug the projector!
2. Remove the front cover, as described on page 5.
3. Be sure the lamp is cool, then remove it by turning it counterclockwise (see Figure 33) until it is released from the three pins in its socket, and working it out of the recessed socket.
4. Hold the new exciter lamp (ANSI Code BRK) so that the notch on its base flange is in approximately the 1 o'clock position, as shown

in Figure 34. Gently work the lamp base over the three pins in the socket, push the lamp base flat against the bottom of the socket, and turn the lamp clockwise until it locks in place.

5. Replace the front cover, as described on page 5.

**NOTE:** Spare BRK lamps can be purchased in individual boxes. The bottom of the cord storage compartment makes a convenient place to store a spare lamp in its box. A piece of tape will keep it there until you want it. See Figure 35.




Figure 33




Figure 34



## Replacing Fuses

**NOTE:** There are spare fuses under the front cover, as shown in Figure 27. You may want to read **HAVING PROBLEMS?** on page 12, for indications of a possible blown fuse.

1. Unplug the projector!
2. Loosen the fuse holder by turning it counterclockwise with a Phillips screwdriver, then take the holder in your fingertips and pull it out of the projector. Check the fuse filament for a break.
3. If the fuse is open (break in filament, see Figure 36), replace it with one of the same amperage rating. Using a fuse with a higher amperage rating may allow damage to the projector.
4. Put the fuse holder back in the projector and tighten with the screwdriver.
5. Correct the condition that caused the fuse to open. If you cannot find the condition and the replacement fuse also opens, have the projector examined by a qualified technician.




Figure 36

## HAVING PROBLEMS?

---

- If** The motor will not turn on,
- Then** Is the projector properly plugged into a "live" receptacle?  
Is main control switch on , , or ?  
Check the main fuse.
- If** The projection lamp will not light,
- Then** Is there power to the projector? (See "The motor will not turn on" above.)  
Is main control switch on ?  
Check that projection lamp is properly seated in its socket.  
Check the projection lamp filament.
- If** There is no sound from the speaker,
- Then** Is there power to the projector? (See "The motor will not turn on," above.)  
Is there a microphone plugged into the microphone jack?  
Does the exciter lamp come on when the amplifier volume is turned up? Check the exciter lamp filament (see page 10) and the exciter lamp fuse (see page 11).  
Check the amplifier fuse (see page 11).
- If** Sound quality is poor,
- Then** Check that the optical sound track on the film is not dirty or scratched.  
Clean the sound optics (see page 7).
- If** Image quality is poor,
- Then** Check that the film is not dirty or scratched.  
Clean the projection lens (see page 7).
- If** You cannot properly focus the image,
- Then** Check that the projection lens is properly installed (see page 7).
- If** The picture is jerky and the projector chatters,
- Then** The loop restorer may be operating continuously. Turn the main control switch to OFF, pause briefly, and turn it back through  to .  
Check the film for damaged perforations.

## ACCESSORIES

---

These products, for use with the *KODAK EKTAGRAPHIC CT1000 16 mm Projector*, are available through dealers in Kodak audiovisual equipment.

**KODAK EKTAGRAPHIC CT Bifocal Converter**, converts a 50 mm projection lens to a 40 mm and a 63 mm lens, making it more convenient to fit the image size to the screen size without moving the projector.

**KODAK Projection EKTAGRAPHIC Lens, 50 mm f/1.2**. Same as lens furnished with projector.

**ELC Projection Lamp**, 24 volts, 250 watts, 50 hours average life

**EJL Projection Lamp**, 24 volts, 200 watts, 50 hours average life

**BRK Exciter Lamp**, 4 volts, 0.75 amperes, 50 hours average life

## KODAK PUBLICATIONS

---

*The Communicator's Catalog from Kodak* (KODAK Publication No. S-4) contains detailed descriptions of and ordering instructions for over 250 Kodak publications on topics of interest to those producing and presenting audiovisual programs. The contents of *The Communicator's Catalog* range from the *Film Technology Packet* (KODAK Publication No. H-300), \$49.95, which covers the finances, aesthetics, and mechanics of making motion pictures, to *Audiovisual Projection* (KODAK Publication No. S-3) which is concise, specific, and free (single copies). In addition, *The Communicator's Catalog* includes movie and slide-tape programs on equipment use and applications. Some of these programs are available for rental only, but many are offered for both rental and sale.

Request your free copy of *The Communicator's Catalog from Kodak* from Eastman Kodak Company, Dept. 412L, 343 State St., Rochester, NY 14650. Please include both the title and the publication number (S-4) in your request.

You can order a service manual for the *KODAK EKTAGRAPHIC CT1000 16 mm Projector* (KODAK Publication No. S-81-2, approximately \$15 plus handling charge) and a parts price list (no charge) from Eastman Kodak Company, Dept. 625, 343 State Street, Rochester, NY 14650.

Prices are subject to change without notice.

# SPECIFICATIONS

## Approximate Weight:

Projector in dust cover—34 lb (16 kg)  
Projector packaged for shipping 40 lb (18 kg)

## Elevation:

Approximately 2.5 in. (64 mm), 12.5°, upward tilt.

## Power Required:

110 to 125 V ac, 60 Hz, 4 A.

**Power Consumed by Projector and Amplifier on 120 V, 60 Hz Power line:** 400 watts when used with ANSI Code ELC, 250-watt, projection lamp.

**Power Cord:** Attached, approximately 8 ft (2.5 m), terminating in molded 3-prong plug.

**Projection Lens:** KODAK Projection EKTAGRAPHIC Lens, 50 mm f/1.2

**Projection Lamp:** ANSI Code ELC lamp is supplied. It is a 24 V ac, 250 W, halogen lamp rated for 50 hours average life at the high setting, approximately 120 hours average life at the normal setting.

**Amplifier:** Rated continuous average sine-wave power of 10 watts into an 8-ohm load (internal or external speaker) at a total harmonic distortion of 5% maximum throughout a bandwidth of at least 50 Hz to 7 kHz, when measured with an rms 120 V ac 60 Hz power input.

**Sensitivity:** 7.40 mV microphone input.


**Microphone Jack:** 3.5 mm mini, for microphone with impedance of 500 to 10,000 ohms.

**Speaker:** Built-in 5 in. (127 mm) diameter, 8-ohm.

**Speaker Jack:** ¼ in. (6.35 mm) phone jack, for 8-ohm load.

**Exciter lamp:** ANSI Code BRK, 4 V, 0.75 A, rated for 50 hours average life.

**Sound Pickup:** Silicon photovoltaic cell.



# NEW AUDIOVISUAL EQUIPMENT WARRANTY

---

## **KODAK EKTAGRAPHIC CT1000 16 mm Projector**

Kodak warrants this *KODAK EKTAGRAPHIC* CT1000 16 mm Projector to function properly for three years from the date of purchase. This warranty does not cover the projection lamp or the exciter lamp. Kodak makes no other warranties, express, implied, or of merchantability, for this equipment. This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.

Carefully read and follow the instructions in this manual to get the best results and to prevent damage to your sound projector.

If this projector does not function properly within three years after purchase, Kodak will repair or replace the projector at its option and at no charge unless damaged by misuse or other circumstances beyond Kodak's control.

REPAIR OR REPLACEMENT IS KODAK'S ONLY OBLIGATION. KODAK WILL NOT BE RESPONSIBLE FOR ANY CONSEQUENTIAL OR INCIDENTAL DAMAGES RESULTING FROM THE SALE OR USE OF THIS 16 mm PROJECTOR, EVEN IF LOSS OR DAMAGE IS CAUSED BY THE NEGLIGENCE OR OTHER FAULT OF KODAK.

For assistance in using this projector, contact a dealer in Kodak audiovisual products. Such dealers are listed in the Yellow Pages of your local telephone directory under Audiovisual Equipment and Supplies. For service on this sound projector, return it through a dealer in Kodak audiovisual products, or one of the Kodak Equipment Service Centers below. To help us get your sound projector back to you promptly, please enclose a note giving details of the problem, date of purchase, and your complete name and address.

### **Eastman Kodak Company Service Centers**

**Atlanta/Chamblee, GA 30341:**  
5315 Peachtree Industrial Blvd.

**Chicago/Oak Brook, IL 60521:**  
1901 West 22nd St.

**Country Club, Carolina, PR 00630:**  
Kodak Caribbean, Ltd.  
Campo Rico Ave. & 246 St.

**Dallas, TX 75234:**  
2800 Forest La.

**Honolulu, HI 96819:**  
1122 Mapunapuna St.  
(P.O. Box 17007, ZIP 96817)

**Los Angeles/Whittier, CA 90606:**  
12100 Rivera Rd.

**Montreal, PQ H3E 1A1:**  
Kodak Canada, Inc.  
2 Place du Commerce  
Ile des Soeurs

**New York, NY/Dayton, NJ 08810:**  
Rt. 130, P.O. Box 1334

**North Vancouver, BC V7J 1J3:**  
Kodak Canada, Inc.  
1125 East Keith Rd.

**Rochester, NY 14650:**  
800 Lee Road

**San Francisco/San Ramon, CA 94583:**  
9100 Alcosta Blvd.

**Toronto, ON M6M 1V3:**  
Kodak Canada, Inc.  
3500 Eglinton Ave. West




**MOTION PICTURE AND AUDIOVISUAL MARKETS DIVISION  
Rochester, New York 14650**

*16mm*  
**CHANNEL LOADING  
SOUND PROJECTOR**

**ELMO**

**16-CL**

**Instruction Manual**



# IMPORTANT SAFEGUARDS

When using your photographic equipment, basic safety precautions should always be followed, including the following:

1. Read and understand all instructions.
2. Close supervision is necessary when any appliance is used by or near children. Do not leave appliance unattended while in use.
3. Care must be taken as burns can occur from touching hot parts.
4. Do not operate appliance with a damaged cord or if the appliance has been dropped or damaged — until it has been examined by a qualified serviceman.
5. Do not let cord hang over edge of table or counter or touch hot surfaces.
6. If an extension cord is necessary, a cord with a suitable current rating should be used. Cords rated for less amperage than the appliance may overheat. Care should be taken to arrange the cord so that it will not be tripped over or pulled.
7. Always unplug appliance from electrical outlet when not in use. Never yank cord to pull plug from outlet. Grasp plug and pull to disconnect.
8. Let appliance cool completely before putting away. Loop cord loosely around appliance when storing.
9. To protect against electrical shock hazards, do not immerse this appliance in water or other liquids.
10. To avoid electric shock hazard, do not disassemble this appliance, but take it to a qualified serviceman when some service or repair work is required. Incorrect reassembly can cause electric shock hazard when the appliance is used subsequently.

**SAVE THESE INSTRUCTIONS**

Congratulations and thank you on joining the large nation-wide family of ELMO 16-CL sound projector owners.

You have selected a precision-engineered projector that will give you the quality picture and sound reproduction you expected from ELMO. However, to enjoy your ELMO projector be sure to read this entire manual for important, helpful information.

## CONTENTS




Major parts descriptions .....	2
Preparation for projection .....	4
Film threading .....	6
Projection .....	8
Various projections .....	9
When using extension speaker .....	10
Public address system .....	11
Rewinding .....	12
Maintenance .....	13
Replacing lamp and fuse .....	17
Trouble-shooting hints .....	20
Accessories .....	22
Specifications .....	25

### PLEASE NOTE

The instructions in this manual applies to both Model 16-CL optical/magnetic reproduction and to Model 16-CL optical only reproduction.


Note information as applies to specific model.

# Major parts descriptions




# Preparation for projection


- 1** Set up your projector and screen properly.  
For steady projection, place the projector on a sturdy support at right angle to the screen.
- 2** Making sure the master control power switch is at OFF, connect the built-in power cord, which is stored in the top side receptacle of the projector, to the AC electrical outlet.
- 3** Pull up the feed reel arm and take-up reel arm to maximum stop position.



- 4** Turn the master control switch clockwise to  through , which will turn the projector on forward and switch on the lamp. Then make adjustment for the projector and screen positions for appropriate picture size. After the set-up is completed, turn the master control switch counter-clockwise to OFF position.




- 5** Install the take-up reel 240m (800ft.), which is stored on the rear of the projector, on the rear reel spindle. The reel capacity of the projector is max. 600m (2,000ft.). Also install the feed reel on the front reel spindle. At this time, be sure to set the reel in correct position by turning down the reel locks.




- 6** Set the M-O switch in accordance with the film to be projected. Set it to M position for magnetic sound film and O position for optical sound film, respectively.

**Note:** Not applicable to 16-CL optical model.

Optical sound film




Magnetic sound film




# Film threading


- 1 Hold the tip of the film leader between thumb and index finger — then pull the leader first through the slot-in roller, next over the No. 1 and No. 2 rollers and finally over the tension roller.




Slot-in roller    Threading guide No.1    Threading guide No.2



- 2** After the film threading is completed, wind the leader on the take-up reel.



- 3** Make sure the film is properly threaded through the channel by turning the take-up reel clockwise with hand.




# Projection

- 1 Turn the master control switch clockwise to  , then turn it further to  , and the lamp is switched on and simultaneously the projector starts forward.

- 2 Adjust focusing by turning the focusing knob.

Focusing knob



Framing knob

- 3 If a frame line appears on the screen, adjust the framing knob to left or right.

- 4 Adjust the sound volume by turning the outer volume control knob clockwise. Adjust the sound tone by turning the inner tone control knob: Turn it clockwise or counterclockwise for treble control.


Volume control

Tone control



## Note :

If the film breaks during projection, a safety mechanism of the projector removes the broken film from the film path automatically. In the event a film breaks, turn the projector to OFF and then remove the broken film for splicing.





# Various projections

## ■ Quick review

This feature is used to see specific frames you wish to review. Turn the control switch counter clock-wise from  all the way to  and the film is quickly rewound through the gate. Then turn the control switch to OFF, as soon as you get the desired frame for re-projection.

After making sure the film has stopped, turn the control switch from OFF all the way to  through .




### Note:

- 1** When the operation switch is set to  from OFF, the projector may start rewinding only after a few seconds' pause depending on the film volume on the reel to be rewound. This is not a fault but safety mechanism for rewinding. The projector is designed to increase motor torque gradually for the protection of film.
- 2** When the operation switch is turned from  to OFF, the film may stop with some length of slackened loop. In such a case, wind up the loose portion by turning the take-up reel clockwise by hand and then turn the operation switch to .
- 3** Be sure not to turn the operation switch from OFF, to  before the film is brought to a complete stop.

## ■ When using extension speaker


In the event you have occasion to use an accessory extension speaker for a large audience in a large auditorium, connect the speaker jack to the receptacle at the rear of the projector. This procedure will automatically shut off the built-in speaker circuit.

Extension speaker jack




### Note :


Use optional adapter cord SC-004 for connecting Elmo extra speaker to your projector.



Elmo extra speaker (A)





Elmo extra speaker (S)



## ■ Public address system

---

You can utilize your ELMO sound projector as a public address system during projection when an accessory microphone is inserted into the microphone jack at the rear left side of the projector. Use the microphone with an impedance of 500 ~ 10k. Public address through a microphone during projection supercedes the sound from the projected film.




---

## ■ HIGH-LOW lamp switch

---

The switch is originally set to High position.


With the switch set to Low, a little lower voltage is applied to the lamp to prolong the lamp service life. When especially bright image is required, set the switch to High to apply the rated voltage to the lamp. (Refer to How to remove and install lamp cover, page 13.)



# Rewinding


- When the projection is completed, rewind the film as follows.

- 1 Insert the film end into the slot of the front reel hub.



- 2 Turn the operation switch to .

In this case the projector may start rewinding only after a few seconds' pause depending on the length of film on the reel to be re-wound. The projector is designed to increase motor torque gradually for the protection of film.




- 3 After the film is rewound, turn the operation switch to OFF.

## ■ Stowing

Disconnect the power cord first.

- 1 Fold the front and rear arms by depressing the folding buttons.
- 2 Return the power cord and take-up reel to their stowing receptacles.
- 3 Turn the elevation control knob fully counterclockwise. Never transport the projector with the elevation leg extended.





# Maintenance

Clean the film channel and lens prior to projection; accumulation of dust and film particles in the film channel gate will scratch the film and decrease the projected image quality.

## ■ How to remove and install covers


### ● Projection lens cover

To remove, hold the cover as shown in the picture and pull it out toward yourself. To install, align the guides at the lower side and push the upper part of the cover into place as shown in the picture.



### ● Front cover



To remove, hold the cover as shown in the picture and pull it out toward yourself.



Continued on page 14

To install the cover, align the framing knob with the cover notch and the guide pins at the upper left and lower right with the corresponding holes and push the cover into position.

(Cover shown in reverse)




Guide pin hole

Framing knob

Guide pin hole

## ■ Cleaning film gate

Be sure to remove the film from the channel when cleaning the film gate.




Remove the projection lens cover.

Hold the pressure plate as shown in the picture and pull it out toward yourself, and the pressure plate can be removed.




Use the stiff cleaning brush (supplied) to clean film channel gate, then wipe clean with lint-free cloth.

After the cleaning is over, align the two pins at the upper and lower parts of the pressure plate holder with the corresponding slots on the pressure plate base and push it back to place.



## ■ Cleaning rollers

Brush off the rollers with the clean soft brush supplied.




## ■ Cleaning projection lens


To remove the projection lens, pull it out straight while pulling the focusing knob toward yourself.



To remove the dust, wipe the lens surface gently with soft, clean, lint-free cloth.



To put the lens back, push it all the way to position while pulling the focusing knob toward yourself, and pull it until a click is heard. This click sound means that the pin at the end of the focusing knob is positively inserted into the groove of the lens holder.



Make sure the lens can move back and forth by turning the focusing knob.

# Replacing lamp and fuse


**BE SURE TO DISCONNECT THE POWER CORD WHEN REPLACING LAMP AND FUSE.**

## ■ Replacing projection lamp


Replacing projection lamp

The type of projection lamp to be replaced is JCR24V-250W or ANSI ELC or Oslam 64653.

- 1** Remove the front cover.
- 2** Remove the lamp cover by loosening the screws counterclockwise.




- 3** Eject the blown lamp by pushing down the ejector lever to the left.



It is advisable to keep a spare projection lamp handy for immediate replacement, should an unexpected break or burn-out develop during projection.

- 4** To replace a new lamp, push it into the socket as shown in the picture. At this time, be sure to insert the lamp firmly into its socket. If it is inserted halfway into the socket, the optimum projection performance can't be achieved or the socket may be burned out.




## ■ Replacing exciter lamp

The type of exciter lamp to be replaced is KE-04 or ANSI BRK.

- 1** Remove the blown exciter lamp by turning its head counterclockwise.




- 2** To replace the new exciter lamp, align the three prongs on the socket with the holes on the lamp flange and turn the lamp head clockwise until it locks into place.



## ■ Replacing fuse

To remove the fuse holders, turn the holder heads counterclockwise with a Philips head screwdriver.



### IMPORTANT

Use the fuse with specified value for each of the three as indicated above.

- Check the exciter lamp fuse for blow-out when no sound is reproduced when projecting optical sound film. At this time, be sure also to check the exciter lamp filament for blow-out.
- Check the amplifier fuse for blow-out when no sound is reproduced when projecting either magnetic or optical film.
- When the power (main) fuse is blown out, no power is supplied to any part of the projector. Check the power (main) fuse for failure when the projector does not operate even with the power cord properly connected and the operation switch set to 

# Trouble-shooting hints

When the motor fails to operate:

- Check the power cord for proper connection.
- Check the power (main) fuse for blow-out.

When the lamp is not lit on:

- Check the lamp filament for blow-out.
- Check the lamp for proper connection with its socket.

When no sound is reproduced:

- Check the M-O switch for the correct position corresponding to the film type used. (Not applicable to 16-CL optical)
- Check the exciter lamp if lighted (only in case of optical sound film).
- Check the exciter lamp fuse for blow-out.
- Check the amplifier fuse for blow-out.

When the image can't be properly focused:

- Check the projection lens for correct alignment, with the pin at the rear of the focusing knob, with the groove in the projection lens.

When the loop restorer operates continuously during projection:

- This may result from the damaged perforations of several frames, which make the slack length of the film between the two sprockets so short that no loop can be restored. In such


## When changing the projection speed from 24 fps to 18 fps or to change electric current cycles (50Hz – 60Hz)

- The projector is originally fixed for 24 fps. operation.  
To change to 18 fps., remove the rear cover by loosening four screws and change the projection speed as shown in the picture.
- Electric current cycles are adjusted at the factory for specific destined countries. But to change electric current cycles (50Hz ~ 60Hz) remove the rear cover by loosening four screws and change the belt position as indicated.

### Note:

One belt is utilized to change electric cycles or projection film speed. When belt is used to change electric current cycles, the same belt cannot be used for change of film speed – or vice versa.

The power cord should be detached from electric outlet **WITHOUT FAIL**, before removing rear cover.



## When changing voltage

When changing voltage, the power cord should be detached from electric outlet – **WITHOUT FAIL**.


After removing rear cover, take out the connection wire and plug it into the indicated voltage terminal to be used.

There is a single voltage model projector available to comply with electrical regulations in specific countries. For this model, the above instructions are not applicable.




# Accessories

## ■ Scope lens



Holder for Elmo scope lens

This lens is used for projecting Cinemascope movies. It can be installed in front of the projection lens simply by mounting it on the accessory socket of the projector. The projected image is horizontally magnified twice.



The image size when using Elmo scope lens in combination with 50mm standard projection lens.


Projection distance m		3	5	10	15	20	25	30	40
Lens									
50mm	Length	0.4	0.7	1.4	2.1	2.9	3.6	4.3	5.8
	Width	1.1	1.9	3.8	5.7	7.6	9.5	11.4	15.2

## ■ Zoom lens F1.7 f = 50 ~ 100mm




This wide range zoom lens eliminates the necessity of moving projector to or from screen for desired size of picture.

## ■ Telephoto projection lens F1.8 f = 75mm




This telephoto lens is for projection in a large auditorium.

## ■ Wide-angle projection lens F1.8 12.5mm



This is a unique super wide-angle lens for 16mm film projection and very effective when combined with a daylight projection device in schoolroom or display window etc.

## ■ Wide-angle projection lens F1.4 20mm



This wide-angle lens is designed for projection in a small room.

## ■ Conversion lens



This attachment lens converts the focal length of the projection lens to either x0.8 or x1.25, i.e., the standard 50mm lens plus this accessory serves as a 40mm wide-angle lens or by reversing it a 63mm telephoto lens. You can make use of it when the projected image is too small or large.


### PROJECTION DISTANCE AND IMAGE SIZE

The projection distance refers to the distance between the film plane and the screen.

In meter.


		3	6	7	10	15	20	25	30	40
Standard lens (F/1.5, 50 mm)	Length	0.4	0.7	1.0	1.4	2.1	2.9	3.6	4.3	5.8
	Width	0.6	0.9	1.3	1.9	2.9	3.8	4.8	5.8	7.7
Standard lens with Conversion lens (X 0.8)	Length	0.5	0.9	1.2	1.8	2.7	3.6	4.5	5.4	7.2
	Width	0.7	1.2	1.7	2.4	3.6	4.8	6.0	7.2	9.6
Standard lens with Conversion lens (X 1.25)	Length	0.3	0.6	0.8	1.1	1.7	2.3	2.9	3.4	4.6
	Width	0.4	0.8	1.1	1.5	2.3	3.1	3.8	4.6	6.2

## ■ Zoom converter



When this converter is used with the projection lens, the focal length is converted continuously from  $\times 0.8$  to  $\times 1.25$ , i.e., the standard 50mm lens plus this accessory serves as a 40mm – 63mm zoom lens. Using it, you can vary the size of the projected image without changing the projector-to-screen distance.

## ■ Extra speaker




Due to the continuous change feature of the zoom converter, you should refer to the chart on the preceding page in order to determine projected image size.

Especially useful for projection in a large auditorium.


Two types, separate type S and box type A, are available.

## ■ Daylight projection mirror



This accessory mirror provides a clear projection image in a bright area in combination with a special translucent screen.

## ■ Translucent screen



The projection in a bright room is possible with this special screen. Two types of screen (80 x 60cm, 52 x 39cm) are available.

# Specifications

Power source:	Single phase AC 50 Hz and/or 60 Hz
Reel capacity:	Max. 600m (2000 ft) by accessory reel. 240m (800 ft) standard reel with automatic take-up.
Projection speed:	24 fps. (18 fps. is also available according to the model requirement.)
Usable film:	16mm optical/magnetic (Optical only for 16CL Optical) sound and silent film.
Projection lens:	Elmo F1.2, 50mm
Projection lamp:	24V-250W halogen lamp (replacement code ELC) with cold mirror, Hi-Low brightness switch.
Motor:	Induction motor
Film loading:	Elmo channel loading system
Loop restorer:	Automatic
Rewinding:	Quick-rewinding reel to reel.
Quick review:	Quick reviewing through the gate only with up to 480m (1600 ft) reel.
Reproduction:	Optical/magnetic playback (Optical only for 16CL Optical)
Photoelectric Element:	Solar battery
Exciter lamp:	4V, 0.75A KE-04, ANSI BRK
Amplifier:	All IC circuit Continuous power output (5%); 12W (8 $\Omega$ ) Music power output ; 15W (8 $\Omega$ )
Tone control:	Adjustable
Public address system:	Available with an accessory microphone (500 $\Omega$ – 10k $\Omega$ )
Speaker:	Built-in, 12.5cm dia.
Extension speaker:	Extension speaker receptacle (8 $\Omega$ ) is provided.
Dimensions:	35 x 29 x 22cm (1 $\frac{3}{8}$ x 1 $\frac{5}{32}$ x $\frac{7}{8}$ in.)
Weight:	14kg (30 lbs.)

Specifications and designs are subject to change without prior notice.



## **ELMO CO., LTD.**

Nagoya, Japan

### **OVERSEAS SUBSIDIARY COMPANIES**

- West Germany** Elmo (Europe) G.m.b.H.  
Elmo-Haus, Steinstr. 23,  
4, Düsseldorf  
Tel. (0211) 326867, 326870, 326895
- Canada** Elmo Canada Mfg Corp.  
44 West Drive Brampton, Ontario L6T 3T6  
Tel. (416) 453-7880
- U.S.A.** Elmo Mfg Corp.  
70 New Hyde Park Road  
New Hyde Park, NY11040, U.S.A.  
21220 Erwin Street, Woodland Hills, CA91367  
Tel. (213) 346-4500

# **SERVICE MANUAL**

## **16-CL**

**ELMO CO., LTD.**

Nagoya, Japan

# I N D E X

## I. DISASSEMBLY & ASSEMBLY

	Page
A. COVER .....	1
B. TAKE-UP REEL ARM .....	3
C. FEED REEL ARM .....	5
D. REWINDING MECHANISM .....	7
E. MACHINE FRAME - LINK .....	9
F. MACHINE FRAME - LEVER SPROCKET SHOE .....	11
G. MACHINE FRAME - LOOP RESTORER .....	13
H. MACHINE FRAME - SPROCKET .....	15
I. MACHINE FRAME - TILTING .....	17
J. MACHINE FRAME - UNIVERSAL JOINT .....	17
K. MAIN SWITCH .....	19
L. CLAW SECTION .....	21
M. PROJECTION LENS .....	25
N. PROJECTION LAMP .....	25
O. MOTOR .....	27
P. TRANSFORMER .....	29
Q. SOUND BASE PLATE .....	31
R. AMPLIFIER .....	35

## II. ADJUSTMENT

S. TAKE-UP REEL ARM .....	37
T. REWINDING MECHANISM .....	38
U. LEVER .....	43
V. LOOP RESTORER .....	45
W. CLAW SECTION .....	48
X. SOUND BASE PLATE .....	51

## III. TROUBLE SHOOTING

TAKE-UP & FEED REEL ARMS .....	55
CLAW SECTION & MACHINE FRAME .....	56
PROJECTION LAMP & LENS .....	58
MOTOR & TRANSFORMER .....	59
SOUND .....	60




Fig. 1

Illustration No.	Parts No.	Parts Name
2	4P10322	Front cover 3
3	P412228	Knob M-0 switch
5	P414770	Screw front cover 12
7	P414741	Screw front cover 4
8	P412230	Knob amplifier
9	P412229	Knob amplifier
10	4P20732	Front cover 12
14	4P8CL0030	Lamp house assy.
15	4P8CL0129	Rear cover assy.
16	4P55646	Screw (2) lamp house
17	6M60300605	Screw truss M630-6
18	4P20570	Front cover 2
19	4P20571B	Front cover 4
22	P412227	Knob main
23	4P20731	Front cover 11

# I. DISASSEMBLY & ASSEMBLY

## A. COVERS

### 1. Disassembly

- (1) Pull out Fig. 1-2 & 18 by hand.
- (2) Remove Fig. 1-19 by detaching Fig. 1-7.
- (3) Remove Fig. 1-10 by removing Fig. 1-3, 8, 9, 5x2.
- (4) Remove Fig. 1-23 by removing Fig. 1-22.
- (5) Remove Fig. 1-15 by removing Fig. 1-17x4.
- (6) Remove Fig. 1-14 by removing Fig. 1-16.

### 2. Assembly

Follow the reverse way of the above steps.




Fig. 2

Illustration No.	Parts No.	Parts Name
1	4P8CL0007	Take-up arm assy.
7	6M6300605	Screw truss M630-6
8	P412190	Rear cover plate
9	P412127	V belt guide roller assy.
10	6M7B30081	Screw sems-B M730-8
11	P412203	V belt take-up
12	P412170	V pulley (2) take-up
13	P412156	Lock spring boss arm
14	6MT4400605	Set screw hexagon M40-6
15	6M7B401001	Screw sems-B M740-10
50	4P55578	Brake spring take-up
55	P412126	Lever arm take-up assy.
58	P412441	Shaft take-up assy.
59	P412289	Belt take-up arm
60	4P20576	Arm (2) take-up
61	6M60300605	Screw truss M630-6

B. TAKE-UP REEL ARM

1. Disassembly

- (1) Remove Fig. 2-60 by detaching Fig. 2-61x2.
- (2) Remove Fig. 2-59 by pushing up Fig. 2-55.
- (3) Remove Fig. 2-1 in the following order.
  1. Remove Fig. 1-15.
  2. Remove Fig. 2-8 by removing Fig. 2-7x2.
  3. Remove Fig. 2-11 by loosening Fig. 2-10x2.
  4. Remove Fig. 2-13 by loosening Fig. 2-15.
  5. Remove Fig. 2-12 by removing Fig. 2-14.

2. Assembly

Follow the reverse way of the above steps, paying attention to the following points.

- (1) Adjust the tension of Fig. 2-11 by moving Fig. 2-9 (tight).
- (2) Check the tension of Fig. 2-59 and adjust it by adjusting the tension of Fig. 2-50 by Fig. 2-62.




Fig. 3

## C. FEED REEL ARM

### 1. Disassembly

- (1) Remove Fig. 1-19 and set Fig. 1-22 at "●" position.
- (2) Remove Fig. 3-1 by detaching Fig. 3-2x2.
- (3) Remove Fig. 3-4 by detaching Fig. 3-6, 3.
- (4) Remove Fig. 3-8 in the following order:
  - \* Remove Fig. 1-15 and set Fig. 1-22 at "●" position.
  - \* Remove (a) in Fig. 3 together by detaching Fig. 3-9.
  - \* Remove Fig. 3-11 by detaching Fig. 3-10.

### 2. Assembly

Follow the reverse way of the above steps, paying attention to the following point.

- (1) Check the tension of Fig. 3-4, and adjust it by changing the position of Fig. 3-5, if necessary.
  - \* Loaded film should not hang down beyond the projection lens during projection and when projection is stopped.
  - \* The belt should not slip during rewinding.

Illustration No.	Parts No.	Parts Name	
1	4P20575	アーム(2)巻返	Arm (2) rewind
2	6M60300605	トラス小ネジ M630-6	Screw truss M630-6
3	4P8CL0039	巻返角棒シャフト組立品	Rewind square shaft assy
4	P412321	シンクロベルト206XL016G	Synchro belt (206XL016G)
5	P412384	組立アームガイドローラ巻返	Guide roller rewind assy
6	4P47107	ネジランソケットホルダ	Lamp socket holder screw
7	6M60300601	トラス小ネジ M630-4	Screw truss M630-6
8	4P8CL0004	巻返アーム組立品	Rewind arm assy
9	6J1251801	ワリピン2.5-18	Split pin 2.5-18
10	6M60400801	ナベ小ネジセムスB M740-10	Screw truss M640-8
11	P412156	ロックバネボスアーム	Lock spring boss arm
12	4P55623	制動バネ巻返	Brake spring rewind




Fig. 4

## D. REWINDING MECHANISM

### 1. Disassembly

- (1) Set Fig. 1-22 at "OFF" position.
- (2) Remove Fig. 4-9, (z) by detaching Fig. 4-8x2,5.
- (3) Remove Fig. 4-6 by detaching Fig. 4-7x4.
- (4) Remove Fig. 4-9 by loosening 2 rotor attaching screws of Fig. 4-9 and remove (b) in Fig. 4 together.
- (5) After Fig. 4-2,3 are detached, remove Fig. 4-10 by loosening Fig. 4-11x2.

### 2. Assembly

Follow the reverse way of the above steps, paying attention to the following points.

- (1) After Fig. 4-2,3 are attached, check the movement of Fig. 4-1,4, connecting the power cord to power source.
- (2) After the assembly is completed, adjust the gap between clutch plate and rotor of Fig. 4-9 and movement of clutch of Fig. 4-9. (Refer to T-2)
- (3) The terminal of Fig. 4-6 should be at the side of Fig. 1-15.
- (4) Fig. 4-9 should be always replaced as a unit.

Illustration No.	Parts No.	Parts Name	
1	P412237	摩擦車(2)ルーフセッタ	Friction wheel 2
2	6M60250601	トラス小ネジ M625-4	Screw truss M625-6
3	4P55616	間座摩擦車	Washer friction wheel
4	4P31849	リンク(1)ルーフセッタ	Link (1) loop setter
5	6M7B00601	トラス小ネジ M630-4	Screw sems M730-6
6	5V1024	スピーカ8Ω	Speaker
7	6M60400601	ナベ小ネジセムスB M740-8	Screw M740-6
8	6M60300601	トラス小ネジ M630-4	Screw truss M630-6
9	6Y49491003	電磁クラッチ	Magnet clutch (ZCF-10B)
10	P412270	ウォームギヤ(1)組立品	Worm gear (1) assy
11	6MT4400805	六角穴止メネジ M40-8	Set screw hexagon M40-8




Fig. 5

Illustration No.	Parts No.	Parts Name	
1	6M60200501	トラス小ネジ M620-5	Screw truss M620-5
2	6M60200501	トラス小ネジ M620-5	Screw truss M620-5
3	P412367B	シュー第2スプロケット	Shoe second sprocket
4	4P55661	バネレバーガイドローラ(4)	Spring guide roller 4
5	P412935	ストッパ軸前カバー(3)	<b>Stabilizer lever GR4</b>
6	P412051C	レバーガイドローラ(4)	Lever guide roller 4
7	6M80300805	トラス小ネジ M640-6	Screw 830-5
8	P412221	ローラ第2スプロケット押エ	Roller second sprocket
9	4P55573	バネレバー(1)第2スプロケット押エ	Spring second sprocket
10	4P44463	16mmスプロケット	Sprocket
11	6M60402501	トラス小ネジ M640-20	Screw truss M640-25
12	P412057C	レバープレッシャローラ	Lever pressure roller
13	4P55551	バネプレッシャローラ	Spring pressure roller
14	P412059C	レバー(1)第2スプロケット押エ	Lever (1) second sprocket
15	6QE(A)0060	EリングER-6	E-ring ER-6

## E. MACHINE FRAME - LINK

### 1. Disassembly

- (1) Set Fig. 1-22 at "●" position.
- (2) Remove Fig.1-2,10,23,18 and attach Fig.1-22.
- (3) Remove Fig. 5-6 by detaching Fig. 5-4,5.
- (4) Remove Fig. 5-14 by detaching Fig. 5-4,9,11.
- (5) Remove Fig. 5-16 by detaching Fig. 5-15,17.
- (6) Remove Fig. 5-21 by detaching Fig. 5-7x3.
- (7) Remove Fig. 5-12 by detaching Fig. 5-13.
- (8) Remove Fig. 5-8 by detaching Fig. 5-2x2.  
Do not loose Fig. 5-1x2.

### 2. Assembly

Follow the reverse way of the above steps, paying attention to the following points.

- (1) After the assembly is completed, check the movement of levers which are interlocked with Fig. 5-21.
- (2) Adjust the position of Fig. 5-3 so that the space between Fig. 5-3 and 10 comes to the thickness of three laminated films.
- (3) When Fig. 5-18 is removed or replaced, check and adjust the related movement of Fig. 5-21,18 and 23 by moving Fig. 5-18.  
(Refer to U-1)
- (4) When Fig. 5-20 is removed or replaced, check and adjust the related movement of Fig. 5-20 and 22 by turning Fig. 5-19x2.  
(Refer to V-1)

16	P412058	レバー中間テンション	Lever middle tension
17	4P55608 B	バネ中間テンションローラ	Spring tension roller
18	P412166 B	ホルダリンク(3)	Holder link 3
19	4P55575	間座押エ板ガイドローラ(3)	Washer guide roller 3
20	P412206 B	押エ板レバーガイドローラ(3)	Plate guide roller 3
21	4P31836 C	連桿(1)	Link 1
22	P412179	レバー組立ガイドローラ(3)	Lever guide roller 3
23	P412173	カム連桿(1)	Cam link 1




Fig. 6

Illustration No.	Parts No.	Parts Name	
1	4P55580	段付ネジ第1スプロケットシュー	Screw sprocket shoe
2	4P31838	シュー第1スプロケット	Shoe first sprocket
3	4P55579	段付ネジレバーシュー	Screw lever shoe
4	P412344	押エ板レバーガイドローラ(2)	Plate guide roller 2
5	P412216 B	ストッパガイドローラ(2)	Stopper guide roller 2
6	4P31827 B	レバースプロケットシュー	Lever sprocket shoe
7	6M70402501	ナベ小ネジ M740-25	Screw pan M740-25
8	4P55571	間座取付板ガイドローラ(1)	Washer holder roller 1
9	4P55583	バネ取付板ガイドローラ(1)	Spring holder roller 1
10	P412174	取付板ガイドローラ(1)	Holder guide roller 1
11	6M70402501	ナベ小ネジ M740-25	Screw pan M740-25
12	P412200	ガイドローラ(1)	Guide roller 1
13	6M6300605	トラス小ネジ M630-6	Screw truss M630-6

F. MACHINE FRAME - LEVER SPROCKET SHOE

1. Disassembly

- (1) Remove Fig.1-2,19,14,18,15.
- (2) Remove Fig. 6-12 by detaching Fig. 6-13,14,11.
- (3) Remove Fig. 6-10 by detaching Fig. 6-7.
- (4) Remove Fig. 6-2 by detaching Fig. 6-1.
- (5) Remove Fig. 6-6 by detaching Fig. 6-17,16,3.
- (6) Remove Fig. 6-15 in the following order:
  - \* Remove Fig. 12-15.
  - \* Remove Fig. 14-12.
  - \* Remove Fig. 6-21 by detaching Fig. 6-18,22,20,19,23.
  - \* Remove Fig. 6-15 by detaching Fig. 6-17,16,24.

2. Assembly

Follow the reverse way of the above steps, paying attention to the following points.

- (1) When Fig. 6-7 is loosened, turn Fig. 6-8,9 so that the tension on Fig. 6-10 may comes to 50-80 gr., measuring the tension at the attaching position of Fig. 6-11 by the tension guage. (Refer to U-1)
- (2) When Fig. 6-6 is removed or replaced, adjust the position of Fig. 6-4,5. (Refer to U-1)

14	4P31886	カバンガイドローラ(1)	Cover guide roller 1
15	4P31850B	リンク(1)スプロケットシュー	Link (1) sprocket shoe
16	4P55055B	間座アオリバネ	Tilting spring washer
17	6NM11040F	ナットM4.0	Nut M4.0
18	6M60250601	トラス小ネジ M625-4	Screw truss M625-6
19	P412237	摩擦車(2)ループセッタ	Friction wheel 2
20	6M60250401	トラス小ネジ M625-4	Screw truss M625-4
21	4P31849	リンク(1)ループセッタ	Link (1) loop setter
22	4P55616	間座摩擦車	Washer friction wheel
23	4P55230	ネジ(1)ループフォーマ	Loop former screw 1
24	4P55598	段付ネジリンク(1)スプロケットシュー	Screw link 1




Fig. 7

Illustration No.	Parts No.	Parts Name	
1	6M70300401	六角穴止メネジ M30-3	Screw M730-4
2	P412129	ホルダ組立リンク(2)	Holder link (2) assy
3	P412352	レバー組立ループセッタ	Lever loop setter assy
4	P412202	リンク(2)ループセッタ	Link (2) loop setter
5	6M60300401	トラス小ネジ M630-5	Screw truss M630-4
6	4P31831B	シャッターカバー組立品	Shutter cover (2)
7	6M60402001	トラス小ネジ M640-20	Screw truss M640-20
8	P412179	レバー組立ガイドローラ(3)	Lever guide roller 3
9	4P55597	バネガイドローラ(3)	Spring guide roller 3
10	6M60250401	トラス小ネジ M625-4	Screw truss M625-4
11	P412237	摩擦車(2)ループセッタ	Friction wheel 2
12	4P31849	リンク(1)ループセッタ	Link (1) loop setter
13	4P55616	間座摩擦車	Washer friction wheel
14	6M60250601	トラス小ネジ M625-4	Screw truss M625-6
15	4P55230	ネジ(1)ループフォーマ	Loop former screw 1

G. MACHINE FRAME - LOOP RESTORER

1. Disassembly

- (1) Remove Fig. 1-2, 19, 14, 10, 23, 18, 15.
- (2) Remove Fig. 7-6, 4 by detaching Fig. 7-5x2, after Fig. 7-2 is removed by loosening Fig. 7-1.
- (3) Remove Fig. 7-3.
- (4) Remove Fig. 7-8 in the following order:
  - \* Remove Fig. 5-21.
  - \* Remove Fig. 7-8 by detaching Fig. 7-7, 9.
- (5) Remove Fig. 7-12 in the following order:
  - \* Remove Fig. 12-15.
  - \* Remove Fig. 7-12 by detaching Fig. 7-14, 13, 15.
- (6) Remove Fig. 7-11 in the following order:
  - \* Remove (b) in Fig. 4 and Fig. 4-10.
  - \* Remove Fig. 7-14, 13, 15.
  - \* Remove Fig. 7-11 by detaching Fig. 7-10.

2. Assembly

Follow the reverse way of the above steps.  
After the assembly is completed, check the function of Loop Restorer.




Fig. 8

Illustration No.	Parts No.	Parts Name	
1	6M70250401	ナベ小ネジ M725-4	Screw pan M725-4
2	P412181	巻込ヨケスプロケット	Film guide sprocket
3	P412159	第1スプロケット	First sprocket
4	4P55577	バネ第1スプロケット	Spring first sprocket
5	P412338	歯第1スプロケット	Cog first sprocket
6	P412141	キャップスプロケット	Cap sprocket
7	6M60400601	トラス小ネジ M640-6	Screw truss M640-6
8	P412161	ウォームギヤ(2)組立品	Worm gear (2) assy
9	P412183	第2スプロケット	Second sprocket
10	P412181	巻込ヨケスプロケット	Film guide sprocket
11	6M70250401	ナベ小ネジ M725-4	Screw pan M725-4
12	4P44463	16mmスプロケット	Sprocket
13	P412141	キャップスプロケット	Cap sprocket
14	6M60400601	トラス小ネジ M640-6	Screw truss M640-6

## H. MACHINE FRAME - SPROCKET

### 1. Disassembly

- (1) Remove Fig. 1-18
- (2) Remove Fig. 8-5 by detaching Fig. 8-7,6.
- (3) Remove Fig. 8-3 in the following order:  
(Use care not to make scratch on bearing.)
  - \* Remove Fig. 8-2 by detaching Fig. 8-1.
  - \* Remove Fig. 8-3 by detaching (c) in Fig. 8. (Refer to D-1)
- (4) Remove Fig. 8-12 by detaching Fig. 8-14,13.
- (5) Remove Fig. 8-9 in the following order:  
(Use care not to make scratch on bearing.)
  - \* Remove Fig. 8-10 by detaching Fig. 8-11.
  - \* Remove Fig. 8-9 by detaching Fig. 8-8. (Refer to B-1)

### 2. Assembly

Follow the reverse way of the above steps, paying attention to the following point.

- (1) Use best care to prevent damage to cogs of gears which are attached to Fig. 8-3 when tightening Fig. 8-7 and also to cogs of Fig. 8-8 when tightening Fig. 8-14.




Fig. 9

Illustration No.	Parts No.	Parts Name	
1	6M7A300801	ナベ小ネジセムスA M730-6	Screw sems-A M730-8
2	P412243	取付金具アオリ棒	Metal tilting leg
3	P412178 B	アオリ棒	Tilting leg
4	P412146	アオリツマミ	Tilting knob
5	P412153 B	前足	Front leg
6	6FM3050125	六角穴付ボルト M5 - 12	Hexagon hole bolt M5 - 12
7	6M7B300801	ナベ小ネジセムスB M730-8	Screw sems-B M730-8
8	P412191 B	メタル押エ	Metal presser
9	P412203	Vベルト巻取	V belt take-up

## I. MACHINE FRAME - TILTING

### 1. Disassembly

- (1) After Fig. 1-15 is removed, remove (1) in Fig. 14 as a unit.
- (2) Remove (d) in Fig. 9 by detaching Fig. 9-1x4,2.
- (3) Remove Fig. 9-3,4,5 by detaching Fig. 9-6.  
Detach only Fig.9-6 when only Fig. 9-5 is to be removed.

### 2. Assembly

Follow the reverse way of the above steps.

## J. MACHINE FRAME - UNIVERSAL JOINT

### 1. Disassembly

- (1) Remove Fig. 1-15.
- (2) Remove Fig. 9-9. (Refer to B-1)
- (3) Remove Fig. 9-8 by detaching Fig. 9-7.
- (4) Pull out (e) in Fig. 9 as a unit toward the rear side of projector.

### 2. Assembly

Follow the reverse way of the above steps.  
After the assembly is completed, be sure to adjust the tension of Fig. 9-9. (Refer to B-2)




Fig. 10

Illustration No.	Parts No.	Parts Name	
1	6T74300601	ナベタッピングネジ 730-6	Tapping pan 730-6 (2L)
2	P412340	コード押エ	Cord supporter
3	6M7A300611	ナベ小ネジセムスB M730-8	Screw sems-B M730-6
4	P412173	カム連桿(1)	Cam link 1
5	6NM11030F	ナット M3.0	Nut M3.0
6	6M70306001	ナベ小ネジ M730-60	Screw pan M730-60
7	6J625140A	スパイロールピン	Spyrol pin
8	6M7A300601	ナベ小ネジセムスA M730-6	Screw sems-A M730-6
9	P412187	ストップピンスイッチカム	Cam switch
10	6G2040	スチールボール 4D	Steel ball 4mm
11	1P55593	クリックバネスイッチカム	Click spring switch cam
12	P412142	レバークリックバネ	Lever click spring

## K. MAIN SWITCH

### 1. Disassembly

- (1) Remove Fig. 1-18,10,23.
- (2) Remove Fig. 5-21. (Refer to E-1)
- (3) Remove Fig. 10-2 by detaching Fig. 10-1.
- (4) Remove (f) in Fig. 10 by detaching Fig. 10-3x3 and disconnect lead wires of (g) in Fig. 10.  
Use care not to touch Fig. 10-8.
- (5) Remove (g) in Fig. 10 by detaching Fig. 10-5x2,6x2.
- (6) Remove Fig. 10-7.  
(Fig. 10-4 can be removed before Main Switch is disassembled)
- (7) Remove Fig. 10-10,12 by detaching Fig. 10-11.
- (8) Remove Fig. 10-9 by detaching Fig. 10-8x2.

### 2. Assembly

Follow the reverse way of the above steps.




Fig. 11

Illustration No.	Parts No.	Parts Name	
1	P411686	中間軸(1)	Universal joint
2	4P55081	ネジフレーム給送部	Frame fix screw
3	1P46460	メタル中間軸	Middle shaft metal
4	P412285	ウォーム(2)	Worm 2
5	1P49039	開座主軸	Main shaft washer
6	6MT4300305	六角穴止メネジ M30-3	Set screw hexagon M30-3
7	1P46460	メタル中間軸	Middle shaft metal
8	6VV3M375	Vベルトメイン3M375	V belt main 3M375
9	5DJ0172211	コンデンサ10 $\mu$ F-220V	Polyest film 10 $\mu$ F-220wV
10	6M70300401	ナベ小ネジ M730-4	Screw pan M730-4

## L. CLAW SECTION

### 1. Dismounting

- (1) Remove Fig. 1-15.
- (2) After (j) in Fig. 11 is raised up, remove Fig. 11-9 by detaching Fig. 11-10.
- (3) After Fig. 2-8 is removed, loosen Fig. 11-6x2 and disconnect the joint between Fig. 11-1 and (h), pushing Fig. 11-1 toward the rear side of projector by screwdriver. (Refer to B-1)
- (4) Remove Fig. 11-8 from (i) in Fig. 11.
- (5) Set Fig. 1-22 at "⊙" position and remove (i) in Fig. 11 by detaching Fig. 11-2x2.

### 2. Mounting

Follow the reverse way of the above steps, paying attention to the following point.

- (1) Be sure that there are no clearances between Fig. 11-3 and 4, and between Fig. 11-5 and 7.

Illustration No.	Parts No.	Parts Name	
1	4P41729D	マスキングカム	Masking cam
2	6M70300401	ナベ小ネジ M730-4	Screw pan M730-4
3	4P41731	アパーチュアプレート取付板	Aperture plate holder
4	P412199	押エ板アパーチュアプレート	A. P pressing plate
5	4P41884 C	マスキングカムガイド	Masking guide
6	4P32265	アパーチュアプレート	Aperture plate 2
7	P412347	組立フィルムガイド(1)	Film guide (1) assy
8	P412345	組立フィルム横押エ(1)	Film side presser 1
9	P412346	組立フィルム横押エ(2)	Film side presser 2
10	P412143	押エ板プレッシャプレート	Holder pressure plate
11	6M7B300801	ナベ小ネジセムスB M730-8	Screw sems-B M730-8
12	P412348	組立ホルダ(1)プレッシャプレート	Holder (1) presser plate
13	6MT4500805	六角穴止メネジ M50-8	Set screw hexagon M50-8
14	P412284	ウォーム(1)	Worm 1
15	P414075	間欠給送装置フレーム	Frame claw unit
16	P411318 B	三角カム	Triangle cam
17	P412993B	送り爪(1)組立品	Claw (1) assy
18	P411324	送り爪(2)	Claw 2
19	P411325	送り爪枠	Slide plate claw
20	6M70300501	ナベ小ネジ M730-5	Screw pan M730-5
21	4P31692	蓋給送部	Frame lid
22	6M80300601	平小ネジ M830-6	Screw FL-PLS M830-6
23	6MT4500805	六角穴止メネジ M50-8	Set screw hexagon M50-8
24	4P31852	組立シャッター(1)	Shutter (1) assy
25	P411335 C	三角カム軸組立品	Triangle cam shaft assy
26	P411317B	面カム	Face cam
27	6M70250801	ナベ小ネジ M725-8	Screw pan M725-8
28	P411323	ピン送り爪	Claw pin
29	P411326	バネ送り爪枠	Spring slide plate claw
30	P411327 B	バネ送り爪	Spring claw
31	P412350B	プレッシャプレート組立品	Pressure plate assy
32	4P55653	プレッシャプレートバネ	Spring pressure plate




Fig. 12

### 3. Disassembly

- (1) Remove (k) in Fig. 12 by detaching Fig. 12-2x2,3.
- (2) Remove Fig. 12-10,12 by detaching Fig. 12-11x2.
- (3) Remove Fig. 12-24 by detaching Fig. 12-23x2.
- (4) Remove Fig. 12-21 by detaching Fig. 12-22x5.
- (5) Remove Fig. 12-17 by detaching Fig. 12-20.
- (6) Remove Fig. 12-14 by detaching Fig. 12-13x2.  
Fig. 12-14 can be removed without disassembling Claw Section.

### 4. Assembly

Follow the reverse way of the above steps, paying attention to the following points. (Refer to W-1)

- (1) When attaching Fig. 12-7, make certain that center of aperture opening (Fig. 12-6) coincide with that of film frame.
- (2) Keep approx. 0.3mm clearance between Fig. 12-8 and 9 when film is loaded.
- (3) Fig. 12-1 should not only closely contact with (y) in Fig. 12 but also smoothly move.
- (4) When Fig. 12-4 is attached, Fig. 12-6 should not only closely contact with Fig. 12-15 but also smoothly move.
- (5) Fig. 12-16 should not only closely contact with Fig. 12-19 but also smoothly move.
- (6) When Fig. 12-17,16 are replaced, check the following points:
  - \* Protrudent length of tip of Fig. 12-18 from film surface. (1mm)
  - \* Position of claw tip in a film perforation.
  - \* Position of claw during the framing.
  - \* Stroke of claw.
- (7) When attaching Fig. 12-24, adjust the timing of Fig. 12-24 and 18 so that pictures may not flow.
- (8) Apply liquid Gasket (semi drying type) on contacting surfaces of Fig. 12-21,15 and fix them with Fig. 12-22x5.




Fig. 13

Illustration No.	Parts No.	Parts Name	
1	5L42402514	映写ランプ JCR 24V-250W	Lamp 24V-250W ELC
2	5N1022	ランプソケット QEX-7	Lamp socket QEX-7
3	4P47107	ネジランプソケットホルダ	Lamp socket holder screw
4	4N02033	銘板(2)フォーカシングツマミ	Focusing plate 2
5	6M60250501	トラス小ネジ M625-6	Screw truss M625- 5
6	P412186	ツマミフォーカシング	Knob focusing
7	6M70250401	ナベ小ネジ M725-4	Screw pan M725-4
8	P415229	映写レンズフォーカシング座	Focusing mount
9	4P35631	バネフォーカシングツマミ	Spring focusing knob
10	P412175	軸フォーカシングツマミ	Shaft focusing knob
11	6M70250801	ナベ小ネジ M725-6	Screw pan M625-8
12	4P31824	ホルダ映写レンズ	Holder projection lens
13	4LB0514	映写レンズ F1.3-50mm	Lens (F1.2-50mm)

## M. PROJECTION LENS

### 1. Disassembly

- (1) Remove Fig. 1-18,14.
- (2) Remove Fig. 13-13 by pulling out Fig. 13-6.
- (3) After Fig. 13-4 is detached from Fig. 13-6, remove Fig. 13-6 by detaching Fig. 13-5.
- (4) Remove Fig. 13-9,10 by detaching Fig. 13-7x3,8.
- (5) Remove Fig. 13-12 by detaching Fig. 13-11x4.

### 2. Assembly

Follow the reverse way of the above steps, paying attention to the following points:

- (1) First attach Fig. 13-12 slightly with Fig. 13-11x4. Then fix Fig. 13-12 by tightening Fig. 13-11x4 and pushing it downward.
- (2) When Fig. 13-4 is removed, be sure to replace it with new one.

## N. PROJECTION LAMP

### 1. Disassembly

- (1) Remove Fig. 1-2.
- (2) Remove Fig. 13-2 by detaching Fig. 13-1,3x2.

### 2. Assembly

Follow the reverse way of the above steps, paying attention to the following point.

- (1) When Fig. 13-2 is re-attached, be sure to check and adjust the leveled screen brightness.




Fig. 14

## 0. MOTOR

### 1. Disassembly

- (1) Remove Fig. 1-10, 23, 18, 15.
- (2) After Fig. 10-2 is removed, disconnect lead wires of the motor.
- (3) Raising (m) in Fig. 14 up, remove Fig. 14-13 by loosening Fig. 14-15.
- (4) Remove Fig. 14-3 by detaching Fig. 14-2x2.
- (5) Remove Fig. 14-10x4.
- (6) Remove Fig. 14-9 by detaching Fig. 14-8.
- (7) Remove (l) in Fig. 14 as a unit, unfastening Fig. 14-1 from (l).
- (8) Remove Fig. 14-5 by detaching Fig. 14-4.
- (9) Remove Fig. 14-7 by detaching Fig. 14-6x2.
- (10) Remove Fig. 14-12, 14 by detaching Fig. 14-11x4.

### 2. Assembly

Follow the reverse way of the above steps, paying attention to the following point.

- (1) Adjust the position of (l) in Fig. 14 so that the adequate belt tension is obtained.  
And be sure that (l) in Fig. 14 does not interfere with other parts.

Illustration No.	Parts No.	Parts Name	
1	6VV3M375	Vベルトメイン3M375	V belt main 3M375
2	6M7B300801	ナベ小ネジセムスB M730-8	Screw sems-B M730-8
3	4P31837	ファンケーシング	Fan casing
4	6Z0006	スナップピン	Snap pin
5	6Z0005	ファン	Motor fan
6	6MT4400605	六角穴止メネジ M40-6	Set screw hexagon M40-6
7	P412240	プーリ(1)モータ	Pulley (1) motor
8	6MT4400605	六角穴止メネジ M40-6	Set screw hexagon M40-6
9	P412292	ファン	Fan
10	6M7B501201	ナベ小ネジセムスB M750-12	Screw sems-B M750-12
11	6M7A300601	ナベ小ネジセムスA M730-6	Screw sems-A M730-6
12	P411613	ホルダー(3)モータ	Holder (3) motor
13	5DJ0172211	コンデンサ 10 $\mu$ F-220V	Polyest film 10 $\mu$ F-220wV
14	P412320	ホルダコンデンサ	Holder condenser
15	6M70300401	ナベ小ネジ M730-4	Screw pan M730-4




Fig. 15

Illustration No.	Parts No.	Parts Name	
1	6M7B501201	ナベ小ネジセムスB M750-12	Screw sems-B M750-12
2	6M70250401	ナベ小ネジ M725-4	Screw pan M725-4
3	4E20446	電源トランス(1)組立品	Transformer (1) assy
4	5E6009	波動スイッチ WD-31019	Seesaw switch WD-31019
5	P412203	Vベルト巻取	V belt take-up
6	P112190	アテ板裏カバー	Rear cover plate

P. TRANSFORMER

1. Disassembly

- (1) Remove Fig. 1-10, 23, 18, 15.
- (2) Remove Fig. 15-6, 5.
- (3) Disconnect lead wires of Fig. 15-3.
- (4) Remove Fig. 15-3 by detaching Fig. 15-1x4.
- (5) Remove Fig. 15-4 by detaching Fig. 15-2x2.

2. Assembly

Follow the reverse way of the above steps, paying attention to the following point.

- (1) Adjust the tension of Fig. 15-5.




Fig. 16 - 31 -

## Q. SOUND BASE PLATE

### 1. Dismounting

- (1) Remove Fig. 1-2,14,18,10,13,15.
- (2) Remove Fig. 16-13 by detaching Fig. 16-12.
- (3) Unsolder the end of lead wire of Fig. 16-1.
- (4) Set lead wires of Fig. 16-4 free by detaching their cord pressers and connector, Fig. 18-5.
- (5) Remove Fig. 16-8 by detaching Fig. 5-21 and Fig. 16-9. (Refer to E-1)
- (6) Remove Fig. 16-3 by detaching Fig. 16-2,10.
- (7) Remove Fig. 16-6 by detaching Fig. 16-5,11,7x2.

### 2. Mounting

Follow the reverse way of the above steps, paying attention to the following point.

- (1) When attaching Fig. 16-6, tighten Fig. 16-5,11 after the position of Fig. 16-6 is fixed with Fig. 16-7x2.

Illustrator No.	Parts No.	Parts Name	
1	P412092B	端子押エエキサイタランプ	Terminal exciter lamp
2	4P55978	バネパッドローラ	Spring lever (1) M-O cha.
3	P412104B	レバー(1)M-O切換	Lever (1) M-O switch
4	4E42720B	端子板ヘッド	Terminal head
5	6M70402001	ナベ小ネジ M740-18	Screw pan M740-20
6	4P20566C	ホルダフライホイール	Holder fly wheel
7	6M80402501	平小ネジ M840-20	Screw FL-PLS M840-25
8	P412057C	レバープレッシャローラ	Lever pressure roller
9	4P55551	バネプレッシャローラ	Spring pressure roller
10	4P55230	段付ネジ M-O 切換レバー(1)	Loop former screw 1
11	6M70401001	ナベ小ネジ M740-10	Screw pan M740-10
12	6Z0006	スナップピン	Snap pin
13	4P48612	フライホイール	Fly wheel
14	4P46467	バネフライホイール	Fly wheel spring




Fig. 17

Illustrator No.	Parts No.	Parts Name	Parts Name
1	P412107	軸組立フライホイール	Shaft fly wheel assy
2	6M60200401	トラス小ネジ M620-4	Screw truss M620-4
3	P412103	押エ板ボールベアリング	Pressing plate bearing
4	6B20801201	ボールベアリング L-1280ZZ	Ball bearing SSL-1280ZZH
5	6M71200405	ナベ小ネジ M7120-4	Screw pan M7120-4
6	4P31862	サウンドレンズ組立品	Sound lens assy
7	5S4PD520UA	シリコンフォトダイオード	Photo diode PD-520UA
8	P412099	カバーフォトダイオード	Cover photo diode
9	6M70200401		Screw pan M720-4
10	6NM19040F	特殊ナット M4.0	Special nut M4.0
11	P412050B	ホルダエキサイタランプ	Holder exciter lamp
12	6MT0200305	止メネジ M20-3	Set screw M20-3
13	6B20601201	ボールベアリング SSL-1260ZZ	Ball bearing SSL-1260ZZ
14	P412722	ナットホルダフライホイール	Ring nut sound drum.
15	6MT4300305	六角穴止メネジ M30-3	Set screw hexagon M30-3

### 3. Disassembly

- (1) Remove Fig. 17-1,4 by detaching Fig. 17-2,3.
- (2) Remove Fig. 17-13 by loosening Fig. 17-12 and detaching Fig. 17-14.
- (3) Remove Fig. 17-26 by detaching Fig. 17-25.
- (4) Remove Fig. 17-29 by detaching Fig. 17-27,28.
- (5) Remove Fig. 17-19 by detaching Fig. 17-18,17.
- (6) After ends of lead wires of Fig. 17-21 are unsoldered, remove Fig. 17-23 by detaching Fig. 17-24,22.
- (7) Remove Fig. 17-21 by detaching Fig. 17-20x2.
- (8) Remove Fig. 17-11 by detaching Fig. 17-9,10.
- (9) After Fig. 17-5x2 are detached, remove Fig. 17-7 by detaching Fig. 17-8.
- (10) Remove Fig. 17-6 by loosening Fig. 17-15.

Note: Above (1) - (4) four steps can be done without dismounting of Sound Base Plate.

Do not remove Fig. 17-16 as it is impossible to restore it to the original position without using special tool.

### 4. Assembly

Follow the reverse way of the above steps, paying attention to the following point.

- (1) Adjust the position of Fig. 17-6,7,11,21,26. (Refer to X-1)

16	P412233	ホルダサウンドレンズ	Holder sound lens
17	6QEA0060	Eリング ER-6	E-ring ER-6
18	4P55549	バネパッドローラ	Spring pad roller
19	P412056 C	レバーパッドローラ	Lever pad roller
20	P412095 B	ネジヘッド	Screw head
21	4E42473	録音再生ヘッド WY-020	Sound head MH-16
22	4P54451	セレクタレバー軸	Selector lever shaft
23	P412093 B	レバー組立ヘッド	Lever head assy
24	4P55540	バネヘッドレバー	Spring head lever
25	6NML9030F	特殊ナット M4.0	Special nut M3.0
26	P414947	制動ローラ(1)	Brake roller 3 assy
27	6M60402501	ナベ小ネジ M740-20	Screw truss M640-25
28	4P55547	バネ制動ローラ(2)レバー	Spring brake roller 2
29	P412049C	レバー制動ローラ(2)	Lever brake roller 2




Fig. 18

Illustration No.	Parts No.	Parts Name	
1	6M70300401	六角穴止メネジ M30-4	Screw pan M730-4
2	P412207	組立レバー(2) M-O切換	Lever (2) M-O switch assy
3	6M7A300601	トラス小ネジ M630-6	Screw sems-A M730-6
4	6M80300601	ナベ小ネジセムスA M730-6	Screw M830-6
5	5N204122	4Pコネクタ S-I 2502	4P connector S-I 2502 2
6	4P8CL0041	11Pコネクタ 5065-11	11P connector cord
7	6777300608	ナベ小ネジセムスA M730-6	Screw T730-6
8	4P8CL0008	アンプ組立品	Amplifier assy
9	6777300608	平小ネジ M830-6	Screw T730-6
10	6777301208	ナベ小ネジセムスA M730-12	Screw T730-12

## R. AMPLIFIER

### 1. Disassembly

- (1) Remove Fig. 1-3, 8, 9, 15.
- (2) Remove Fig. 18-5, 6.
- (3) Remove (n) in Fig. 18 by detaching Fig. 18-3x3.
- (4) After Fig. 18-1, 2 are detached, remove (o) in Fig. 18 by turning it counterclockwise.
- (5) Remove Fig. 18-10x2.
- (6) Remove (p) in Fig. 18 by turning it counterclockwise.
- (7) Remove Fig. 18-7x3.
- (8) Remove Fig. 18-8 by detaching Fig. 18-4x2, 9x2.

### 2. Assembly

Follow the reverse way of the above steps.

## II. ADJUSTMENT

### S. TAKE-UP REEL ARM

Take-up Reel Arm of 16-CL has following two functions, which can be adjusted at a time with the below-mentioned adjustment.

- \* Function to take up film.
- \* Function to give a sufficient back-tension to rewind film safely and smoothly.




Fig. 19

#### 1. Measurement:

- (1) As illustrated in Fig. 19, set Main Knob (Fig.1-22) at "OFF" position. And wind film on attached 800 ft Reel through Channel, and turn the reel for about 10 times by hand.
- (2) While pulling out the film in the direction of the arrow illustrated in Fig. 19, measure the tension by a tension gauge. The tension is to be 200-250gr.

#### 2. Adjustment:

- (1) When Fig. 2-4 is damaged or stained with oil, etc., replace it.
- (2) Adjust the take-up tension of Fig. 2-4 by changing the tension of Fig. 2-6.
- (3) If Fig.2-16 is stained with oil, etc., remove stains.

## T. REWINDING MECHANISM

Rewinding mechanism of 16-CL makes it possible to rewind the film through Channel quickly without any film damage as well as Reel-to-reel rewinding.

This rewinding mechanism consists of Feed Reel Arm, Delay Device (Delay Circuit, Magnet Clutch, etc.) and Slipping Mechanism.

16-CL is designed to rewind film with 70-80% lower torque than the normal torque only for 3-4 sec. after motor starts rewinding in order to prevent film damage. (Hereinafter this 3-4 sec. period is called "Delay Time".)




Fig. 20

### 1. Measurement:

- (1) As shown in Fig. 20, wind film on attached Reel until the diameter of wound film comes to 20cm.
- (2) Set Main Knob at "⊙" position and measure the tension as illustrated in Fig. 20.

The rewinding tension is to be the following:

- \* 100-200gr. during the delay time of 3-4 sec.
- \* 600-700gr. after this period.

2. Adjustment:

- (1) Adjust the tension of Fig. 3-4 by changing the position of Fig. 3-5 so that it may not slip.
- (2) Adjustment of clutch friction during the delay time of 3-4 sec:
  - \* Fix the position of Fig. 22-2 by tightening Fig. 22-4 to keep 0.3mm clearance between Fig. 22-1 and 2.
  - \* Rewinding tension is limited by the clutch friction, which is electrically controlled by R22 (Specified value: 560 ohms, Fig. 23). Large value of R22 results in less friction.
- (3) Adjustment of Delay Time:
  - \* Delay time of 3-4 sec. is originally decided by the delay circuit and no adjustment is requested.
  - \* When replacing the parts, be sure to use specified spare parts.
- (4) Adjustment of clutch friction after the delay time:
  - \* Loosen Fig. 21-1 by turning it counterclockwise.
  - \* Change the pressure of Fig. 21-3 by turning Fig. 21-2 in order to adjust the tension to 600-700gr. (Refer to Fig. 20)
  - \* After adjustment is completed, be sure to lock Fig. 21-1,2 by turning Fig. 21-1 clockwise.




Fig. 21

Illustration No.	Parts No.	Parts Name	
1	4P55599	ナット摩擦板	Nut friction plate
2	4P55599	ナット摩擦板	Nut friction plate
3	4P55600	バネ摩擦板	Spring friction plate

### 3. Magnet Clutch:




Fig. 22

Illustration No.	Parts No.	Parts Name	
1		クラッチ板	Clutch plate
2		ローター	Rotor
3		マグネット	Magnet
4	6MT4400305	六角穴止メネジ M40-3	Set screw hexagon M40-3

Magnet Clutch works in accordance with applied voltage to the clutch as follows:

- (1) Approx. 12V (for the delay time of 3-4 sec.):

Due to Delay Circuit, attractive force of Fig. 22-3 is weaker than regular force. And, for smooth and safe rewinding, slip occurs between Fig. 22-1 and 2 so that the rewinding tension may come to 100-200gr.

- (2) 37V (after the delay time):

As attractive force comes to the regular level, Fig. 22-1 rotates together with Fig. 22-2 without slip. In this instance, the tension depends on the pressure of Fig. 21-3.

4. Delay Circuit:





Fig. 23

The nature of Zener Diode is put to use in Delay Circuit.

- Zener Diode:
- \* Current flows in forward direction.
  - \* Current does not flow in reverse direction when applied voltage is lower than a certain level which is called "Zener Voltage (VD)".
  - \* Current starts to flow in reverse direction when applied voltage exceeds the Zener Voltage (VD).

Immediately after S-5 is switched on, most of current flow through R22 (Route (1)).

At this time, voltage applied to Magnet Clutch (Voo) is about 12V.

(Voo is calculated as  $V_{oo} = V_{cc} \times \frac{R_o}{R_o + R_{22}}$ ).

After S-5 is switched on, C29 is charged with the current through R20 and when the terminal voltage of C29 exceeds the Zener Voltage of ZD1, current starts to flow through ZD1, Tr1 and Tr2.

The current, which flows through R22 during the delay time, turns to flow through Tr2.

In the end, all current flow through Tr2 as the Equivalent Resistance of Tr2 comes to nearly zero.

At this time, Voo is calculated as  $V_{oo} = 37 \times \frac{270}{0 + 270} = 37V$ ,

i.e., Vcc of 37V is supplied to Magnet Clutch.

16-CL is so designed that it takes about 3-4 seconds to increase Voo from 12V to 37V (Delay Time).




Illustration No.	Parts No.	Parts Name	
1	4P31827B	レバースプロケットシュー	Lever sprocket shoe
2		メタルスプロケット	Metal sprocket
3	4P31836C	連桿(1)	Link 1
4	P412173	カム連桿(1)	Cam link 1
5	P412166B	ホルダリンク(3)	Holder link 3
6	6M7B400801	ナベ小ネジセムスB M740-8	Screw sams-B M740-8
7	P412344	押エ板レバーガイドローラ(2)	Plate guide roller 2
8	P412157	レバー組立ガイドローラ(2)	Lever guide roller 2
9	6M60300601	トラス小ネジ M630-6	Screw truss M630-6
10	P412216B	ストッパガイドローラ(2)	Stopper guide roller 2
11	6M60250401	トラス小ネジ M625-4	Screw truss M625-4
12	P412204C	ストッパレバーガイドローラ(2)	Stopper lever roller 2
13	4P55791	ピンアームロック	Screw cover machine
14	4P31886	カバーガイドローラ(1)	Cover guide roller 1
15	4P55571	間座取付板ガイドローラ(1)	Washer holder roller 1
16	P412123	ホルダ(1)スイッチカム	Holder (1) switch cam




Fig. 24

## U. LEVER

When Main Knob is set at "☉" or "☾" position, levers in 16-CL are pressed to each specified direction only by springs and do not interfere each other. So movable rollers at "☉" or "☾" keep correct position even after long use. Therefore, no adjustment of levers interlocked with Link (1) is requested except for Fig. 24-3,5,7,10.

### 1. Adjustment:

Check and adjust levers in the following order.

- (1) Location of Lever Sprocket Shoe (Fig. 24-1) when Main Knob is set at "☉" position:

- \* Set Main Knob at "☉" position.
- \* Fix Fig. 24-5 with Fig. 24-6x2, pushing Fig. 24-3 towards Fig. 24-4 and Fig. 24-5 towards the opposite direction of Fig. 24-4.
- \* And after Main Knob is turned several times, make certain that there is no excessive clearance than 0.4mm between Fig. 24-1 and 2 at "☉" position.

- (2) Location of Lever Sprocket Shoe (Fig. 24-1) when Main Knob is set at "OFF" or "☾" position:

- \* After the adjustment (1) is completed, set Main Knob at "OFF" position.
- \* Fix Fig. 24-7 by tightening Fig. 24-9 at the position that Fig. 24-8 may slightly touch Fig. 24-13.
- \* Location of Lever Sprocket Shoe at "☾" position can be automatically adjusted with the above steps.

- (3) Location of Stopper Guide Roller 2 (Fig. 24-10):

- \* Fig. 24-8 forms the upper film loop, and Fig. 24-10 sets Fig. 24-8 free from Fig. 24-12.
- \* Adjust the position of Fig. 24-10 by moving it to right or left so that, when turning Main Knob clockwise from "OFF", Main Knob may be held in "☉" position just after film perforation fits onto the tooth of First Sprocket (Fig. 8-5).

- (4) When attaching Fig. 24-14, adjust the position of Fig. 24-14 so that it may not touch 2000 ft Reel when Main Knob is set at "OFF" position.

- (5) Turn Fig. 24-15 counterclockwise so that the tension on Fig. 24-14 may come to 50-80gr. (Refer to F-2)

Note: If tension on Fig. 24-14 is not enough, film gets out of First Sprocket and it causes the length of upper film loop to be shortened.

- (6) When Fig. 24-16 is removed or replaced, fix Fig. 24-16, pushing it in the direction of the arrow illustrated in Fig. 24.




Fig. 25

## V. LOOP RESTORER

Loop Restorer works as under:

- \* The length of lower Film Loop is shortened.
- \* Fig. 25-7 is pushed up by film.
- \* Free-end of Fig. 25-5 is pushed up by Fig. 25-7.
- \* Claw of Fig. 25-9 moves upwards.
- \* Fig. 25-11 is set free from the claw of Fig. 25-9 and at the same time Fig. 25-10 pushes Fig. 25-11. Then Fig. 25-11 rotates slightly.
- \* Fig. 25-11 touches Fig. 25-12 which is rotating, and rotates one revolution.
- \* Fig. 25-1, which is interlocked with Fig. 25-11, is pushed down.
- \* Fig. 25-8, which is interlocked with Fig. 25-1, is pushed down and reforms an adequate loop.

### 1. Adjustment:

#### (1) Spring Link 1 (Fig. 25-3):

- \* Set Main Knob at "⊙" position.
- \* Adjust the position of Fig. 25-3 to keep approx. 1mm distance in (q) in Fig. 25 and fix Fig. 25-3 with Fig. 25-4.
- \* Make certain that the distance (q) in Fig. 25 is maintained after Loop Restorer works several times.

#### (2) Holder Link (2) Assy (Fig. 25-5):

- \* Shorten the length of the lower film loop by pulling up the upper film loop by finger, while feeding the film.
- \* Adjust the position of Fig. 25-5 so that film may touch the lower end of Fig 25-7 before Fig. 25-8 starts rotating and that loop restorer may work smoothly.
- \* In practice, push Fig. 25-5 up to the highest position and fix Fig. 25-6 slightly.
- \* Shorten the length of lower film loop by finger so that film may be about to touch Fig. 25-8.
- \* Then bring down Fig. 25-7 by hitting Fig. 25-5 slightly with screwdriver, etc. to the position that Loop Restorer starts working, and fix Fig. 25-6.

- \* If Loop Restorer does not work at the time Fig. 25-7,8 vibrate even after the said adjustment, firstly adjust Fig. 25-7 so that it may smoothly move.
- \* And loosen Fig. 8-14 and adjust the position of Fig. 8-12 (Sprocket) by turning it clockwise or counterclockwise. (Refer to H-1)
- \* Be sure to check the function of Loop Restorer at both "M" and "0" reproductions.

Note: Loop Restorer should start working when about 20gr. pressure is given to the lower end of Fig. 25-7.

(3) Plate Guide Roller 3 (Fig. 25-13):

- \* Fig. 25-8 forms the lower film loop when Main Knob is turned from "OFF" to "●" positions.
- \* Adjust the position of Fig. 25-13 so that Fig. 25-8 may locate at the lowest position in order to form sufficient lower film loop.
- \* In practice, adjust Fig. 25-13 by turning Fig. 25-14x2 and fix it with Fig. 25-15x2 at the position that Fig. 25-13 locates at the lowest position and that Fig. 25-13 moves smoothly.
- \* Check and adjust the position of Fig. 25-13 so that, when turning Main Knob from "OFF" to "●", Fig. 25-8 may be set free after film is engaged in Sprocket.

Illustration No.	Parts No.	Parts Name	
1	4P31849	リンク(1)ループセッタ	Link (1) loop setter
2	4P31850B	リンク(1)スプロケットシュー	Link (1) sprocket shoe
3	4P55592	バネリンク(1)スプロケットシュー	Spring link 1
4	6M60300601	トラス小ネジ M630-5	Screw truss M630-6
5	P412129	ホルダ組立リンク(2)	Holder link (2) assy
6	6M70300401	六角穴止メネジ M30-3	Screw pan M730-4
7	P412202	リンク(2)ループセッタ	Link (2) loop setter
8	P412209	ガイドローラ(3)	Guide roller 3
9	P412352	レバー組立ループセッタ	Lever loop setter assy
10	P412352	レバー組立ループセッタ	Lever loop setter assy
11	P412237	摩擦車(2)ループセッタ	Friction wheel 2
12	P412270	ウォームギヤ(1)組立品	Worm gear (1) assy
13	P412206B	押エ板レバーガイドローラ(3)	Plate guide roller 3
14	4P55575	間座押エ板ガイドローラ(3)	Washer guide roller 3
15	6M7A400801	トラス小ネジ M640-6	Screw sems A M740-8

## W. CLAW SECTION

### 1. Adjustment:

- (1) Adjust the attaching position of Fig. 12-14 so that Fig. 12-25 may smoothly rotate without end-play to (r) direction.
- (2) Adjust the pressure of Fig. 12-29 or replace Fig. 12-16,29 so that Fig. 12-16 may closely contact with Fig. 12-19 and may smoothly move.
- (3) Adjust the pressure of Fig. 12-30 so that Fig. 12-28 may always contact with Fig. 12-26.
- (4) Measure the tension to (s) direction in Fig. 12 at the attaching position of Fig. 12-18 by a tension guage.

Adjust the pressure of Fig. 12-30 so that the said tension may be 300gr.

The measurement and adjustment should be done without attaching Fig. 12-16.

- (5) Adjust the protrudent length of tip of Fig. 12-18 from Fig. 12-6 to be 1mm. Then Fig. 12-18 should be at the center of film perforations.
- (6) Adjust the attaching position of Fig. 12-5 or bend (y) in Fig. 12 so that momentums of a picture in the both directions may be equal. Then Fig. 12-1 should not only closely contact with (y) in Fig. 12 but also smoothly move.
- (7) Adjust the timing between Fig. 12-18 and 24 so that Fig. 12-24 may intercept the projection light when Fig. 12-18 feeds film. Make certain that picture does not flow.
- (8) Fig. 12-17,18 should be replaced as a unit because Fig. 12-18 is fixed to Fig. 12-17 tightly with adhesive.
- (9) Stroke of Fig. 12-18 is to be 7.65-7.67mm.

Use undeveloped film for check and adjustment of the stroke.

Just before Fig. 12-18 starts feeding the film, protrudence of Fig. 12-18 from Fig. 12-6 should be maximum, and two tips of Fig. 12-18 should be closest to the lower edge of film perforations. And when two tips of Fig. 12-18 go into and out film perforations, they should not touch film perforations.

To adjust the stroke, change the attaching position of Fig. 12-16 by enlarging its center hole with a reamer or file.




Fig. 12

For example, when the position of Fig. 12-16 is changed by  $1/100\text{mm}$ , the stroke of Fig. 12-18 becomes longer or shorter by  $4/100\text{mm}$  (4 times of changed distance).

Shorter stroke than the proper one causes film jumping, and longer stroke causes loud feeding mechanism noise.

- (10) When attaching Fig. 12-21, apply Liquid Gasket (semidrying type) on contacting surfaces of Fig. 12-21,15.
- (11) When attaching Fig. 12-4, adjust the position of Fig. 12-4 so that Fig. 12-6 may closely contact with Fig. 12-4 and move smoothly.
- (12) When attaching Fig. 12-7, adjust the position of Fig. 12-7 so that the center of aperture opening of Fig. 12-6 may coincide correctly with that of film frame, using standard test film such as SMPTE TEST FILM 16RT RP20 (REGISTRATION TARGET).
- (13) Fig. 12-8,9 should work independently without any interference. So keep about 0.3mm clearance between Fig. 12-8 and 9 when film is loaded between Fig. 12-7 and 8,9.
- (14) Adjust Fig. 12-8,9,12 so that Fig. 12-8,9 may move as follows:

When Main Knob is set at "OFF" position, Fig. 12-8,9 move in the opposite direction of Fig. 12-7 for easy film loading.

When Main Knob is set at "●" or "◁" position, Fig. 12-8,9 move towards Fig. 12-7 to press the film-side.

X. SOUND BASE PLATE

1. Adjustment:

Adjust Sound Base Plate as follows:

(1) Location of Brake Roller 1 (Fig. 26-1):




Fig. 26


Illustration No.	Parts No.	Parts Name	
1	P414947	制動ローラ(1)	Brake roller 3 assy
2	6NM19030F	特殊ナット M4.0	Special nut M3.0

Adjust the position of Fig. 26-1 to keep 27mm distance from the perforation-side end of film to the attaching mount of Fig. 26-1 ((t) in Fig. 26).  
 (To claw section and both sprockets, above 27mm distance is applied.)

In practice, adjust the position of Fig. 26-1 by turning special Nut M4.0 so that the distance from the perforation-side end of film to Base Frame ((u) in Fig. 26) may come to 28mm.

Note: Fig. 26-1 also functions as Impedance Roller and maladjustment of Brake Roller 1 gives bad influence upon Sound Quality (Wow & Flutter, etc.).

(2) Adjustment of Bazz Track:



Set the volume control at maximum position, and run a Bazz Test Film such as SMPTE TEST FILM (P16BT BUZZ TRACK).

Loosen Fig. 27-7 and adjust the position of Fig. 27-1 by turning Fig. 27-6 clockwise or counter-clockwise so that the level of output power may be minimized.

After the adjustment, tighten Fig. 27-7 and fix it by applying adhesive.

Fig. 27

Illustration No.	Parts No.	Parts Name	
1	P412050	ホルダエキサイタランプ	Holder exciter lamp
2	4E41580	エキサイタランプ KE-04 4V-0.75A	Exciter lamp KE-04 4V-0.75A
3	4P31862	サウンドレンズ組立品	Sound lens assy
4	P412233	ホルダサウンドレンズ	Holder sound lens
5	6MT4300305	六角穴止メネジ M30-3	Set screw hexagon M30-3
6	6NM19040F	特殊ナット M4.0	Special nut M4.0
7	6M7020040	止メネジ M20-2.5	Screw pan M720-4

(3) Adjustment of Azimuth for Optical Reproduction:

Load 7,000Hz Test Film such as SMPTE TEST FILM (P16SFA SOUND FOCUSING) and set Main Knob at "●" position.

First, adjust the protrudent length of Fig. 27-3 from Fig. 27-4 to be about 9mm ((v) in Fig. 27).

Adjust the position of Fig. 27-4 by turning Fig. 27-3 so that the maximum output power may be obtained, and fix Fig. 27-3 by tightening Fig. 27-5.

Do not move Fig. 27-4 as it is originally fixed at correct position, using standard optical axis gauge.




Fig. 28

Illustration No.	Parts No.	Parts Name	
1	4E42473	録音再生ヘッド WY-020	Sound head <b>MH16</b>
2	P412114	パッドローラ組立品	Pad roller assy
3	P412107	軸組立フライホイール	Shaft fly wheel assy
4	6M71200701	ナベ小ネジ M712-7	Screw pan M712-7
5	P412251	フィルムガイドホルダサウンドレンズ	Film guide sound lens
6	6M71200701	止メネジ M02-6	<b>Screw pan M720-7</b>
7	6MT0200601	止メネジ M02-6	Set screw M02-6
8	P412543	取付板ヘッド	Holder head

(4) Adjustment of Azimuth of Magnetic Recording/Playback Head:

- \* Adjust the position of Fig. 28-1 so that Fig. 28-1 may position about 0.2mm lower from the assumed film path.

In practice, put a plastic ruler on Fig. 28-3 and 5, and adjust Fig. 28-1 by turning Fig. 28-6 so that Fig. 28-1 may slightly touch the ruler.

Next, move Fig. 28-1 about 0.2mm towards Fig. 28-2 by turning Fig. 28-6 counterclockwise.

Note: Unless Fig. 28-1 is fixed at proper position, it causes the below-mentioned troubles and gives bad influence upon Sound Quality (Wow/Flutter, Frequency Response, etc.).

- (a) Film sags
- (b) Untouch or unstable head-touch of Sound Track

So use best care to keep proper position of Fig. 28-1.

- \* Adjust the position of Fig. 28-1 by turning Fig. 28-4 so that the center of Fig. 28-1 may coincide with the center line of Fig. 28-2 ((w) in Fig. 28).
- \* Adjust the distance between Fig. 28-1 and 8 ((x) in Fig. 28) to be about 2.5mm by turning Fig. 28-7x3, and load a film.

Readjust the position of Fig. 28-1 by turning Fig. 28-7x3 slightly so that Fig. 28-1 may locate at the correct position against magnetic sound track.

Make certain that Fig. 28-1 may not interfere with picture.

- \* Running 7,000Hz Test Film such as SMPTE TEST FILM (M16AL AZIMUTH ALIGNMENT, 7,000HZ), adjust the position of Fig. 28-1 by turning Fig. 28-7x3 so that the maximum output power may be achieved.

After the adjustment, fix Fig. 28-7x3 with adhesive.

### III. TROUBLE SHOOTING

#### TAKE-UP & FEED REEL ARMS

Case	Checking Point	Step	Ref.
Take-up torque is insufficient	Belt Take-up Arm (Fig.2-59)	If Fig.2-59 is defective, replace it.	B, S
	Brake Spring Take-up (Fig.2-50)	If the pressure of Fig.2-50 is insufficient, increase it.	B
	Shaft Take-up Assy (Fig.2-58)	If the friction of Fig.2-58 is not proper, replace it.	S
	V Belt Take-up (Fig.2-11)	If the tension of Fig.2-11 is insufficient, increase it	B
	Rewind Square Shaft Assy (Fig.3-3)	If the friction of Fig.3-3 is not proper, adjust it by Fig.3-5 or replace Fig.3-4.	C
Film hangs down in front of the Projection Lens during projection or when projection is stopped.	Synchronous Belt 206 (Fig.3-4)	If the tension of Fig.3-4 is insufficient, increase it.	C
	Brake Spring Rewind (Fig.3-12)	If the pressure of Fig.3-12 is insufficient, increase it.	Fig.3
	(b) in Fig.4	If (b) in Fig.4 sticks to the shaft, remove stains from them.	Fig.4
Rewinding torque is insufficient.	Synchronous Belt 206 (Fig.3-4)	If the tension of Fig.3-4 is insufficient, increase it.	C
	Brake Spring Rewind (Fig.3-12)	If the pressure of Fig.3-12 is insufficient, increase it.	Fig.3
	Take-up Arm Assy (Fig.2-1)	If the rewinding friction is too strong, reduce it.	S
	Magnet Clutch (Fig.4-9)	Adjust the slip of Fig.4-9.	T
	Spring Friction Plate (Fig.21-3)	If the pressure of Fig.21-3 is insufficient, increase it.	T

CLAW SECTION & MACHINE FRAME

Case	Checking Point	Step	Ref.
Film Jumping	Claw Assy (Fig.12-17)	Adjust the position of Fig.12-18 against Fig.12-6.	W
		Adjust the pressure of Fig.12-30.	W
	Triangle Cam (Fig.12-16)	Adjust Fig.12-19 so that Fig.12-16 may closely contact with Fig.12-19 and also smoothly move.	W
	Triangle Cam Shaft Assy (Fig.12-25)	Adjust the position of Fig.12-14 so that Fig.12-25 may closely contact with Fig.12-15 and also smoothly rotate.	W
	Aperture Plate (Fig.12-6)	Check the flatness of Fig.12-6. If not flat, replace it.	Fig. 12
	Pressure Plate Assy (Fig.12-31)	Adjust the pressure of Fig.12-31 by changing the pressure of Fig.12-32.	W
		Adjust the position of Fig.12-12 so that Fig.12-31 may keep correct position against Fig.12-6.	Fig. 29
Film Side Pressure (1),(2) (Fig.12-8,9)	Adjust the spring effects of Fig.12-8,9 and the relation between them.	W	
Picture Flow	Shutter (1) Assy (Fig.12-24)	Adjust the timing between Fig.12-24 and 18.	W
Film Flow	Claw 2 (Fig.12-18)	Adjust the protrudent length of tip of Fig.12-18 from Fig.12-6 to be 1mm.	W
		Adjust Fig.12-18 to keep correct position against film perforation. If Fig.12-18 is damaged, replace it.	W Fig. 12
	Triangle Cam (Fig.12-16)	If the claw does not have specified stroke, adjust the attaching position of Fig.12-16 or replace it.	W
	Film Side Pressure (1),(2) (Fig.12-8,9)	Adjust the spring effects of Fig.12-8,9 and the relation between them.	W Fig. 29
	Pressure Plate Assy (Fig.12-31)	Make certain that Fig.12-31 closely contacts with Fig.12-6.	W

CLAW SECTION & MACHINE FRAME (Cont'd)

Case	Checking Point	Step	Ref.
Loud Feeding Noise	Triangle Cam (Fig.12-16)	Adjust the stroke of claw by changing the attaching position of Fig.12-16 or by replacing it.	W
	Claw 2 (Fig.12-18)	Adjust Fig.12-18 so that Fig.12-18 may make a right angle with film perforation by bending the free-end of Fig.12-17.	W
	Slide Plate Claw (Fig.12-19)	Adjust Fig.12-19 so that Fig.12-16 may closely contact with Fig.12-19 and also smoothly move.	W
	Spring Claw (Fig.12-30)	Adjust the pressure of Fig.12-30.	W
Masking	Masking Guide (Fig.12-5)	Adjust Fig.12-5 so that Fig.12-1 may closely contact with (y) in Fig.12 and also smoothly move.	W
Film Scratching	Aperture Plate, etc. (Fig.12-6), etc.	Check all parts which contact with loaded film. They should be neither injured nor stained.	
Upper Film Loop increases in length	Claw 2 (Fig.12-18)	If claw does not feed the film smoothly because of short protrudent length of tip of Fig.12-18, adjust the protrudent length to be 1mm.	W
Upper Film Loop decreases in length	Lever Guide Roller 2 (Fig.24-8)	Adjust Fig.24-8 to work properly.	U
	Cog First Sprocket (Fig.8-5)	Adjust Fig.8-5 so that Fig.8-5 may coincide with the center of film perforation.	U
Lower Film Loop decreases in length	Claw 2 (Fig.12-18)	Adjust the protrudent length of tip of Fig.12-18 from Fig.12-6 to be 1mm.	W
	Link (2) Loop Setter (Fig.25-7)	Adjust Loop Restorer so that it may work properly.	O

PROJECTION LAMP & LENS

Case	Checking Point	Step	Ref.
Lamp does not light	Lamp (Fig.13-1)	If lamp itself is defective, replace it.	Fig.13
	Lamp Socket QEX-7 (Fig.13-2)	If Fig.13-2 has insufficient contact, replace it.	Fig.13
	Lamp Switch S4	If S4 is defective, replace it.	Fig.15 30 31
	Lamp Switch S6 (Fig.15-4)	If Fig.15-4 is defective, replace it.	Fig.15 30 31
	Transformer (1) Assy (Fig.15-3)	If Fig.15-3 is defective, replace it.	P
Dark Image	Lamp (Fig.13-1)	If brightness is not enough due to long-use, replace Fig.13-1.	Fig.13
	Lamp Socket QEX-7 (Fig.13-2)	Adjust the position of lamp by moving Fig.13-2. If the terminal voltage of Fig.13-2 is less than the rated value, check Fig.15-3, etc. and replace the defective parts.	Fig.13
Uneven Screen Brightness	Lamp Socket QEX-7 (Fig.13-2)	Adjust the position of Fig.13-2 so that most bright and leveled screen brightness may be achieved.	Fig.13
Uneven Screen Focusing	Aperture Plate (Fig.12-6)	Adjust the position of Fig.12-6 so that Fig.12-6 may be attached to Fig.12-15 properly and also film may be pressed to Fig.12-6 properly by Fig.12-31. (Film should closely contact with Fig.12-6)	Fig.12
	Holder Projection Lens (Fig.13-12)	If correct optical axis cannot be achieved due to damaged Fig.13-12, replace it.	Fig.13

MOTOR & TRANSFORMER

Case	Checking Point	Step	Ref.
Projector does not run.	Power Cord, Main Fuse (F1)	If Power Cord or Main Fuse is defective, replace it.	Fig. 30 31
	Transformer (1) Assy (Fig.15-3)	If the terminal voltage of Fig.15-3 which is applied to motor is less than the rated value (100V), replace it.	"
	Motor Switch (S1, S2, S3)	If motor switch is defective, replace it.	"
	Starting Condenser (CM1, CM2)	If starting condenser or resistor is defective, replace it.	"
	Relay (RY)	If relay is defective, replace it.	"
	Motor	If motor is defective (insufficient torque, broken wire, etc.), replace it.	0
Projector runs slowly.	Transformer (1) Assy (Fig.15-3)	If the terminal voltage of Fig.15-3 which is applied to motor is less than the rated value (100V), replace it.	Fig. 30 31
	Motor	If motor torque is insufficient, replace it.	0
	Pulley (1) Motor (Fig.14-7)	If slip occurs between Fig.14-1 and 7, adjust it.	0
	V Belt Main 3M375 (Fig.14-1)	If the tension of Fig.14-7 is too tight, adjust it.	0
	Claw Section, etc.	Adjust the load at main parts such as Claw Section, if over-loaded.	
Projector does not run inversely.	Motor Switch (S2, S3)	If motor switch is defective, replace it.	Fig. 30 31

SOUND

Case	Checking Point	Step	Ref.
Neither Optical nor Magnetic Film can be reproduced.	Power Cord, Fuse (F1)	If power cord or fuse is defective, replace it.	Fig.30 31
	Amplifier Fuse (F2)	If amplifier fuse is defective, replace it.	"
	Transformer (1) Assy (Fig.15-3)	If the terminal voltage of Fig.15-3 which is applied to Amplifier is less than the rated voltage (29V) due to broken wire, etc., replace Fig.15-3.	"
	Speaker 8 ohms (Fig.4-6)	If Fig.4-6 is defective, replace it.	Fig.4
	Connector (CN1-5,7,8; CN2-1,2,3,4,5), Switch (SW1-2, SW2-1)	Check the conduction of connectors and switches. If not conduct, replace it.	Fig.31 32
	Amplifier	Check the voltages in comparison with the voltage checking points. If the unusual voltage would be measured, replace amplifier.	Fig.29
	REC1	If REC1 is defective, replace it.	Fig.32
Optical Film cannot be reproduced.	Exciter Lamp (Fig.27-2)	If Fig.27-2 is defective, replace it.	
	Fuse (F3), Connector (CN1-9,10,11), Switch (SW1-3, SW2-2)	Check the conduction of fuse, connectors and switches. If not conduct, replace it.	Fig.31 32
	REC2, Exciter Lamp Circuit	If REC2 or exciter lamp circuit is defective, repair or replace it.	Fig.32
	Amplifier	Check the voltages in comparison with the voltage checking points. If the unusual voltage would be measured, adjust or replace amplifier.	Fig.29
	Sound Lens (Fig.27-3)	If Fig.27-3 is dusty or defective, brush away dust or replace it. If Fig.27-3 is out of position, adjust it.	X
	Silicon Photo Diode (Fig.17-7)	If Fig.17-7 is dusty or defective, brush away dust or replace it. If Fig.17-7 is out of position, adjust it.	Q
	Knob M-0 Switch (Fig.1-7)	If Fig.1-7 is defective, replace it.	A, R

SOUND (Cont'd)


Case	Checking Point	Step	Ref.
Output level is low at Optical reproduction.	Amplifier	Check the voltages in comparison with the voltage checking points. If the unusual voltage would be measured, adjust or replace amp.	Fig. 29
	Sound Lens (Fig.27-3)	If the attaching position of Fig.27-3 is not proper, adjust it by using 7,000Hz Test Film. Remove stains from the surface of sound lens.	X
	Exciter Lamp (Fig.27-2)	If the attaching position of Fig.27-2 is not correct, adjust it. If Fig.27-2 is defective, replace it.	X
Magnetic Film cannot be reproduced.	Sound Head WY-020 (Fig.28-1)	If Fig.28-1 is defective (broken wire, etc.), replace it.	X
	Canceling Coil L1	If canceling coil is defective, replace it.	Fig. 32
	Connector (CN2-3,4)	Check the conduction of connectors. If not conduct, replace it.	Fig. 31 32
	Knob M-0 Switch (Fig.1-7)	If Fig.1-7 is defective, replace it.	A,R
	Amplifier	Check the voltages in comparison with the voltage checking points. If the unusual voltage would be measured, adjust or replace amp.	Fig. 29
Output Sound is low at Magnetic reproduction	Sound Head WY-020 (Fig.28-1)	If Fig.28-1 is worn out by long use, replace it.	X
	Amplifier	Check the voltages in comparison with the voltage checking points. If the unusual voltage would be measured, adjust or replace amp.	Fig. 29
Amplifier Noise	Canceling Coil L1 (Magnetic Reproduction)	If canceling coil is out of position, adjust it.	Fig. 32
	Silicon Photo Diode (Fig.17-7) (Optical Reproduction)	If Fig.17-7 vibrates, adjust amp. so as not to vibrate.	Q
	Amplifier	If parts in amplifier is defective, replace it.	

SOUND (Cont'd)

Case	Checking Point	Step	Ref.
Wow & Flutter (Magnetic & Optical reproduction)	Sprocket (Fig.8-12)	If Fig.8-12 touches film perforation-side, adjust the position of it. If Fig.8-12 has defective such as distortion or disfigurement, replace it.	E,X
	Shaft FlyWheel Assy (Fig.17-1)	If Fig.17-1 has defective such as disfigurement or eccentricity, replace it.	Q
		If there is end-play in Fig.17-1, adjust it by turning Fig.17-14.	Q
		If there is unnecessary clearance between Fig.17-1 and Fig.17-4,13 due to defect of Fig.17-4 or 13, replace Fig.17-4 or 13.	Q
		If Fig.17-1 does not rotate smoothly, adjust Fig.17-14 or replace Fig.17-14,13.	Q
	Worm 2 (Fig.11-4)	If Fig.11-4 has disfigurement, replace it.	L
		If there is end-play in Fig.11-4, adjust it by moving the position of Fig.11-5.	L
		If Fig.11-4 unnecessarily moves in right-angled direction against axis, replace Fig.11-3,7.	L
	Worm Gear (2) Assy (Fig.8-8)	If Fig.8-8 has defective such as distortion or disfigurement, replace it.	E
	Fly Wheel Spring (Fig.16-14)	If the pressure of Fig.16-14 is insufficient, increase it.	Q
	Belt Take-up Arm (Fig.2-4)	If take-up tension is unstable, replace Fig.2-4.	B
	V Belt Take-up (Fig.2-11)	If the tension of Fig.2-11 is not enough and Fig.2-11 slips, increase the tension of Fig.2-11.	B
	Brake Roller 1 (Fig.26-1)	If Fig.26-1 does not rotate smoothly, adjust it.	X
If Fig.26-1 has eccentricity, replace it.		X	
(1) in Fig. 14	If vibration of motor and Fig.14-9 are too big, adjust or replace them.	0	

SOUND (Cont'd)

Case	Checking Point	Step	Ref.
Wow & Flutter (Magnetic Reproduction)	Sound Head WY-020 (Fig.28-1)	If position of Fig.28-1 is not correct, adjust the position by turning Fig.28-6.	X
	Pad Roller Assy (Fig.28-2)	If Fig.28-2 is defective, replace it.	X
		If Fig.28-2 does not rotate smoothly or the pressure to Fig.28-1 does not become stable, adjust it.	X
Wow & Flutter (Optical Reproduction)	Silicon Photo Diode (Fig.17-7)	If Fig.17-7 vibrates, adjust amplifier so as not to vibrate.	Q



Circuits for "Magnetic" are not applied to "Optical" type.

SCHEMATIC DIAGRAM FOR MACHINE FOR ELMO 16-CL (M-O & O) E31007

# ELECTRIC PARTS LIST

E30983

Item	Parts No.	Parts Name	Circuit Diagram No.	Item	Parts No.	Parts Name	Circuit Diagram No.
IC	5ALD3115	IC (LD3115)	IC1	200K Ω	5R1C002541	C film fix R. 200K Ω ½W	R5
	5ALD3141	(LD3141)	IC2				
	5ATA7210P	(TA7210P)	IC3	30PF	5DQ0310511	Ceramic con. 30PF/50WV	C20
Tr	5S12SC945	Transistor (2SC945)	Tr1	47PF	5DQ4700511	47PF/50WV	C6
	5S12SC1098	(2SC1098)	Tr2	500PF	5DQ0520511	500PF/50WV	C1
D	5S2RD62E	Zener diode (RD6.2E)	D1	1000PF	5DJ0130511	Polyest film 1000PF/50WV	C9 C23
	5S2SR1K2	Si diode (SR1K-2)	D2	2000PF	5DJ0230511	2000PF/50WV	C2
REC	5S2S1RBA20	Si rectifier (S1RBA20)	REC 1 REC2	4700PF	5DJ4720511	4700PF/50WV	C8
	5R4Z0014A1	VR 10K A-type+10K B-type	VR	6800PF	5DJ6820511	6800PF/50WV	C26
0.47 Ω	5R5B047K71	Metal film R. 0.47 Ω 2W		0.01MF	5DJ0140511	0.01MF/50WV	C11
1.5 Ω	5R1C015141	C film fix R. 1.5 Ω ¼W	R16	0.022MF	5DJ2230511	0.022MF/50WV	C14
5.1 Ω	5R2B051J81	Cement R. 5.1 Ω 5W	R17	0.033MF	5DJ3330511	0.033MF/50WV	C12 C13
22 Ω	5R1C022042	C film fix R. 22 Ω ¼W	R23 R24	0.1 MF	5DJ0150514	0.1MF/50WV	C25
100 Ω	5R5B001271	Metal film R. 100 Ω 2W	R15	0.15MF	5DJ1540511	0.15MF/50WV	C27
560 Ω	5R5B056171	560 Ω 2W	R25	1MF	5DB0163501	Al elect con. 1MF/35WV	C10 C19
1 K Ω	5R5B001371	1 K Ω 2W	R22	4.7MF	5DB4753502	4.7MF/35WV	C21
1.5 K Ω	5R1C001341	C film fix R. 1.5 K Ω ¼W	R18	10MF	5DG0170111	Ta solid con. 10MF/10WV	C3
	5R1C015241	1.5 K Ω ¼W	R14	47MF	5DB4760111	Al elect con. 47MF/10WV	C7
1.8 K Ω	5R5B018261	Metal film R. 1.8 K Ω 1W	R9	100MF	5DB01863J1	100MF/6.3WV	C15 C16
2 K Ω	5R1C002341	C film fix R. 2 K Ω ¼W	R1		5DB0182501	100MF/25WV	C4 C5 C17 C18
3 K Ω	5R1C003341	3 K Ω ¼W	R19	220MF	5DB0180511	100MF/50WV	C24
5.6 K Ω	5R1C056241	5.6 K Ω ¼W	R10		5DB2270111	220MF/10WV	C29
10 K Ω	5R1C001441	10 K Ω ¼W	R6 R7 R12		5DB2272501	220MF/25WV	C22
12 K Ω	5R1C012342	12 K Ω ¼W	R3	1000MF	5DB0193501	1000MF/35WV	C28
18 K Ω	5R1C018342	18 K Ω ¼W	R4		5DB0190511	1000MF/50WV	C30 C33
27 K Ω	5R1C027341	27 K Ω ¼W	R20	3300MF	5DB3380111	3300MF/10WV	C32
50 K Ω	5R1C005441	50 K Ω ¼W	R21		5DB3381601	3300MF/16WV	C31
51 K Ω	5R1C051341	51 K Ω ¼W	R8				
100 K Ω	5R1C001541	100 K Ω ¼W	R2 R11 R13				

\*Metal film R. .... Metal film fixed resistor \* C film fix R. .... Carbon film fixed resistor \* con. .... condenser \* Polyester .... Polyester \* Al elect. .... Aluminum electrolytic \* Ta ..... Tantalum

STANDARD VALUE OF PRESSURE

When measuring pressures, set Main Knob at "P" position.  
 When measuring pressure at (e), put two sheets of films between Sprocket and Roller Sprocket. And measure it, while pulling out films.

a.	(P412350)	....	45 ± 10 gr.	h.	(P410607)	....	80 ± 20 gr.
b.	(P412349)	....	230 ± 70 gr.	i.	(P412114)	....	250 ± 50 gr.
c.	(P412345)	....	50 ± 10 gr.	j.	(P412112)	....	50 ± 20 gr.
d.	(P412346)	....	55 ± 15 gr.	k.	(P412368)	....	370 ± 70 gr.
e.	(P412338)	....	350 ± 100 gr.	l.	(P412339)	....	200 ± 50 gr.
f.	(P412209)	....	40 ± 20 gr.	m.	(P412112)	....	370 ± 100 gr.
g.	(P412114)	....	50 ± 10 gr.	n.	(4P31886)	....	65 ± 15 gr.





Fig. 29





EXC LAMP POSS. IC4

See BLUE SKH-



This circuit is not applied to 16-CL O-type.

Fig. 32 Schematic diagram for amplifier for 16-CL

E30983

\*Measure the voltage at each checking point by Vacuum-tube Voltmeter.

Values surrounded by  $\square$  are specified voltages measured under following steps.

1. Turn Volume Control Knob fully clockwise.
2. Set Tone Control Knob at the center position.
3. Apply 4.8mV-400Hz signal oscillated by Oscillator to Mic. receptacle (Fig.33,J2).
4. Set Volume Control Knob so that the output level measured by Vacuum-tube Voltmeter may be 11.5dB lower than its maximum level.

If use a Tester instead of Vacuum-tube Voltmeter, be sure to use one whose internal impedance is more than 1 Kohms/volt at AC.

\*Other voltages mentioned in this circuit diagram are DC voltages when no signal is applied. If use a Tester, be sure to use one whose internal impedance is more than 10 Kohms/volt at DC.

\*If the internal impedance is less than the above-mentioned value, proper value would not be measured.






Fig. 33 Amplifier circuit plate for 16-CL

E20454



Circuits enclosed with long and short lines are not applied to "Optical" type.

SCHMATIC DIAGRAM FOR AMPLIFIER FOR ELMO 16-CL (M-080) E31503 (NEW TYPE E20667 printed)



SCHEMATIC DIAGRAM FOR AMPLIFIER FOR ELMO 16-CL (H) E31485

