

FILM-TECH

THE INFORMATION CONTAINED IN THIS ADOBE ACROBAT PDF FILE IS PROVIDED AT YOUR OWN RISK AND GOOD JUDGMENT.

THESE MANUALS ARE DESIGNED TO FACILITATE THE EXCHANGE OF INFORMATION RELATED TO CINEMA PROJECTION AND FILM HANDLING, WITH NO WARRANTIES NOR OBLIGATIONS FROM THE AUTHORS, FOR QUALIFIED FIELD SERVICE ENGINEERS.

IF YOU ARE NOT A QUALIFIED TECHNICIAN, PLEASE MAKE NO ADJUSTMENTS TO ANYTHING YOU MAY READ ABOUT IN THESE ADOBE MANUAL DOWNLOADS.

WWW.FILM-TECH.COM

INSTA-LOAD™ XL

16 MM PROJECTORS

SERIES 2200



OPERATOR

INSTRUCTIONS

IMPORTANT SAFEGUARDS

When using the projector, basic safety precautions should always be followed, including the following:

1. Read and understand all instructions.
2. Close supervision is necessary when the projector is used by or near children. Do not leave the projector unattended while in use.
3. Care must be taken as burns can occur from touching hot parts.
4. Do not operate the projector with a damaged cord or if the projector has been dropped or damaged — until it has been examined by a qualified serviceman.
5. Do not let cord hang over edge of table or counter or touch hot surfaces.
6. If an extension cord is necessary, a cord with a suitable current rating should be used. Cords rated for less amperage than the projector may overheat. Care should be taken to arrange the cord so that it will not be tripped over or pulled.
7. Always unplug projector from electrical outlet when not in use. Never yank cord to pull plug from outlet. Grasp plug and pull to disconnect.
8. Let projector cool completely before putting away. If cord storage area is not included on unit, loop cord loosely around the projector when storing.
9. To protect against electrical shock hazards, do not immerse this projector in water or other liquids.
10. To reduce the risk of electric shock, do not disassemble this projector, but take it to a qualified serviceman when service or repair work is required. Incorrect reassembly can cause electric shock when the projector is subsequently used.

SAVE THESE INSTRUCTIONS

TABLE OF CONTENTS

Introduction	4	Film Footage Counter	16
Model Features	5	Microphone Use	17
Reference Guide	6	Maintenance	18
Setup	7	Malfunctions	25
Supplying Power	8	International Model Conversions	27
Film Threading	9	Optional Accessories	29
Operation	11	Service	30

Model No. _____

Serial No. _____

Mfg Code _____

Purchase Date _____

For security purposes, record in this booklet the above information which is found on the data label on the bottom side of the projector.

INTRODUCTION

Thank you for selecting the Telex Insta-Load™ XL as your new 16 mm sound projector. The Telex quality engineering that is designed into your projector and your attention to periodic preventive maintenance will assure you of years of trouble-free performance. Please take the time to read this booklet. Become familiar with all of the many outstanding features of your new Telex Insta-Load XL, and you'll find the projector easy to operate and enjoy.

Make sure to keep this booklet handy, as you may want to refer to it from time to time.

™ Insta-Load is a trademark of Telex Communications, Inc.

MODEL FEATURES


This booklet makes reference to projector features that are unique to certain models. Other models are included in the 2200 Series, but only nine models will be discussed. These nine models are provided with features that also exist in varying configurations with other models in the 2200 Series. Some of the distinguishing features are shown in the chart that follows. The model number of your projector appears at the bottom of the unit.

Series 2200 Projector Features

Model Number	Hi/Lo Lamp	Still Frame Project	Optical/Magnetic Sound	In-Path Fast Forward	Film Footage Counter	Mic Input	Xenon Lamp	Voltage Requirements	
								120	220/240
2210	X							X	
2211	X								X
2220	X	X						X	
2221	X	X							X
2251*	X	X	X						X
2270	X	X		X	X	X		X	
2271	X	X		X	X	X			X
2280		X		X	X	X	X	X	
2281		X		X	X	X	X		X

*. The Model 2251 quickly converts to a different line voltage and frequency for use as a domestic projector.

REFERENCE GUIDE



Model 2270 Insta-Load XL 16 mm Projector

SETUP

CAUTION

Make sure that air flow to and from the ventilation slots on the projector is not blocked.

1. Position the projector according to the Screen Size Chart.

Screen Size Chart

Lens Focal Length	Screen Width in Inches/(Meters)*									
	40 (1.02)	50 (1.27)	60 (1.52)	70 (1.78)	84 (2.13)	96 (2.44)	108 (2.74)	120 (3.05)	144 (3.66)	168 (4.27)
	Projection Distance in Feet/(Meters)**									
5/8 in. (16 mm)	5.6 (1.71)	7.0 (2.13)	8.3 (2.53)	9.7 (2.96)	11.6 (3.54)	13.3 (4.05)	14.9 (4.54)	16.6 (5.06)	19.8 (6.04)	23.1 (7.04)
1.0 in. (25 mm)	8.9 (2.71)	11.1 (3.38)	13.3 (4.05)	15.5 (4.72)	18.6 (5.67)	21.2 (6.46)	23.9 (7.28)	26.5 (8.08)	31.7 (9.66)	37.0 (11.3)
1.5 in. (38 mm)	13.4 (4.08)	16.7 (5.09)	20.0 (6.10)	23.3 (7.10)	27.9 (8.50)	31.8 (9.69)	35.8 (10.9)	39.7 (12.1)	47.6 (14.5)	55.5 (16.9)
2.0 in. (50 mm)	17.9 (5.46)	22.3 (6.80)	26.7 (8.14)	31.0 (9.45)	37.2 (11.3)	42.4 (12.9)	47.7 (14.5)	53.0 (16.2)	63.5 (19.4)	74.0 (22.5)
2.5 in. (64 mm)	22.3 (6.80)	27.8 (8.47)	33.3 (10.1)	38.8 (11.8)	46.5 (14.2)	53.0 (16.2)	59.6 (18.2)	66.2 (20.2)	79.4 (24.2)	92.5 (28.2)
3.0 in. (75 mm)	26.8 (8.17)	33.4 (10.8)	40.0 (12.2)	46.6 (14.2)	55.8 (17.0)	63.7 (19.4)	71.6 (21.8)	79.4 (24.2)	95.2 (29.0)	111.0 (33.8)
4.0 in. (100 mm)	35.8 (10.9)	44.5 (13.6)	53.3 (16.3)	62.1 (18.9)	74.5 (22.7)	84.9 (25.9)	95.4 (29.1)	105.9 (32.3)	127.0 (38.7)	148.0 (45.1)

* Width of screen needed = 16 mm film aperture width (0.380-inch) multiplied by the projection distance (in inches) and divided by the lens focal length (in inches). Substitute millimeters for inches to obtain metric equivalents. The screen width-to-height ratio should be 1-1/3:1.

** Projection distances are measured from the projector film gate to the screen.

NOTE

The projector should be placed high enough to center the image without tilting the projector more than 12 degrees. Pictures at greater angles will exhibit excessive "keystone" effects.

2. Arrange viewing seats no closer to the screen than three times the width of the picture.
3. Remove the projector cover.
4. Depress the STOP film control button.

SUPPLYING POWER


1. Plug all domestic models into a 120-volt ac power source.
2. Plug all international models into a 220/240-volt ac power source.

NOTE

Power cords for international models must be user-supplied or ordered from Telex (catalog number 2990). The Telex cord is supplied with a plug on one end which matches the receptacle on the projector base and three wires on the other end stripped for connection to the correct mains or line plug. The wires are color-coded as follows: green and yellow (earth), blue (neutral), and brown (live).

(Except Models 2280/81)


1. Set the LAMP switch to LO (low) for normal lighting and extended lamp life.
2. Set the LAMP switch to HI (high) if greater brightness is desired.



Lamp Switch

(Models 2270/71)

Set the power switch to ON. The red MAINS POWER indicator above the film control buttons will light.



Power Switch

(Models 2280/81)

1. Position the projector on top of the arc lamp power supply, and plug it into the large 6-pin receptacle on the end.
2. Set the power, lamp, and douser switches to ON.

NOTE

To cool the lamp without running the projector, turn the lamp switch OFF and press the FAN button with the power switch ON.

FILM THREADING


1. Attach the take-up reel as follows:
 - a. Swing the take-up reel arm up until it locks in position.
 - b. Place an empty take-up reel on the take-up reel arm spindle.
 - c. Snap the reel locking lever back to captivate the take-up reel.
2. Attach the supply reel as follows:
 - a. Swing the supply reel arm up until it locks in position.
 - b. Place the film supply reel on the supply reel arm spindle with the film feeding forward (film perforations facing outward toward operator).
 - c. Snap the reel lock lever back to captivate the supply reel.

3. Thread the film as follows:
 - a. Set the master control lever in the LOAD (down) position.
 - b. Take the end of the film leader between the thumb and index finger of one hand, and pull it along the film path (which is easily discerned by the routing arrows on the projector).


NOTE

Keep the film taut as it is routed along the film path.


- c. Insert the film leader into the hub of the take-up reel and turn the reel several times in the clockwise direction to remove slack and secure the film leader.
- d. Set the master control lever in the PROJECT (up) position.
- e. Check for proper threading by turning the manual advance knob in the clockwise direction.



**Master Control Lever
(in LOAD position)**



Film Threading Sequence



**Master Control Lever
(in PROJECT position)**


(Model 2251)

1. Place the OPT/MAG control in the OPT position when playing optical sound track film. (This holds the magnetic head away from the film and turns on the exciter lamp.)
2. Place the OPT/MAG control in the MAG position when playing magnetic sound track film. (This allows the magnetic head to contact the magnetic sound track on the film and turn the exciter lamp off.)

OPERATION

FOCUSING/FRAMING


1. With power applied and the projector master control lever in the PROJECT position, press the FWD (forward) button to advance the film to a projected picture.
2. Focus the image by turning the FOCUS control.
3. If a black strip (frame line) appears at the top or bottom of the screen, rotate the FRAME knob until the frame line disappears.



Film Control Buttons

ELEVATION


1. Turn the elevation knob clockwise to raise the image on the screen.
2. Turn the elevation knob counter-clockwise to lower the image on the screen.



Lens Focus Control

VOLUME AND TONE

1. Slide the VOL (volume) control to the right to increase volume.
2. Slide the TONE control to the left or right for the desired tonal quality.



Framing Knob


NORMAL REVERSE

1. With the master control lever in the PROJECT position, press the STOP button.
2. Press the REV/REW (reverse/rewind) button to run the film back as far as desired. (The sound is muted in reverse.)
3. Press the STOP button to discontinue reverse motion.
4. Press the FWD button to resume film operation.


FAST MODE REVERSE/REWIND

To return quickly to previously projected scenes or to rewind the film "in-path":

1. Press the STOP button before the film leaves the supply reel.
2. Set the master control lever to the FAST MODE position.
3. Press the REV/REW button for fast mode reverse/rewinding.
4. Press the STOP button to discontinue reverse motion.



Elevation Knob and Foot



Volume and Tone Controls


To resume projection:

1. Move the master control lever to the PROJECT position.

NOTE

It will be impossible to raise the master control lever to the PROJECT position on projectors that have the "fast-forward" feature until the FAST MODE INTERLOCK light just above the FWD/FF (forward/fast forward) film control button turns off.

2. Check for proper film threading by turning the manual advance knob in the clockwise direction.
3. Press the FWD (forward) button to resume normal projection.



Fast Mode Interlock Indicator

REEL-TO-REEL REWINDING

NOTE

It is not necessary to switch reels or to move reel arms when rewinding from the take-up reel to the supply reel.

1. Attach the loose end of the film from the take-up reel directly to the empty supply reel, and turn the supply reel counterclockwise several revolutions to secure the film to the reel.
2. Set the master control lever to the FAST MODE position.
3. Press the REV/REW (reverse/rewind) button to return the film to the supply reel.
4. Press the STOP button when the film has been completely rewound.

FAST FORWARD

(MODELS 2270/71, 2280/81)

The "fast-forward" feature permits rapid forward movement of the film to a predetermined spot. The film counter permits accurate measurement of film footage.

1. Depress the STOP button.
2. Set the master control lever to the FAST MODE position.
3. Press the FWD/FF (forward/fast forward) button and observe the film counter. (The projection lamp is off and the sound is muted when running in the fast-forward mode.)
4. Press the STOP button a few feet before the desired footage reading is reached. (The momentum of the projector will carry the film to approximately the right point.)
5. Move the master control lever to the PROJECT position after the "fast-mode" interlock light (above the FWD/FF button) goes out.

NOTE

It will be impossible to lift the master control lever to the PROJECT position until the FAST MODE INTERLOCK light goes out.

6. Check for proper film threading by turning the manual advance knob in the clockwise direction.
7. Press the FWD/FF button to resume normal projection.

STILL PROJECTION

(Except Model 2210)

To stop the film for "still" projection of one frame:

1. Press the STILL film control button with the master control lever in the PROJECT position.
2. If only part of the picture appears on the screen, rotate the manual advance knob until a full picture appears.

3. If necessary, focus again for maximum sharpness.

NOTE

Brightness will be reduced because the safety shutter holds back some light.

To resume normal projection:

1. Press the FWD/FF (forward) button.
2. Adjust the FOCUS control.

ENDING THE SHOW

1. Rewind the film to the supply reel, and depress the STOP button.
2. Set the power switch to OFF (Models 2270/71 and 2280/81).
3. Set the lamp and douser switches to OFF (Model 2280/81).
4. Unplug the projector from the arc lamp power supply (Models 2280/81).
5. Unplug the projector from the ac power source.

STORAGE

1. Remove the supply and take-up reels, and lower the reel arms.
2. Retract the elevation leg.
3. Place the power cord in the projector storage compartment.
4. Assemble the projector cover to the projector.


FILM FOOTAGE COUNTER

(Models 2270/71, 2280/81)

The counter measures film footage and works in reverse as well as forward. Thus, you can return to the beginning of the scene by running the projector in reverse or fast forward until the desired number in the counter window has been reached.

If you are previewing for a later presentation, use the counter numbers to plan your program.

1. Always set the counter to zero (0000) at the beginning of the film.
2. Run the projector in the fast mode and watch the counter.
3. Press the STOP button shortly before the desired footage number is reached.



Film Footage Counter

The lead footage will vary slightly depending on the size and amount of film on one reel, but this will be only a few seconds of projection time. With some experience, you will soon be able to stop the fast forward or reverse travel at the desired point.

MICROPHONE USE

(Models 2270/71, 2280/81)


A 400-ohm microphone (Telex part number 46262-P1) with a standard ¼-inch (6.35 mm) phone plug is supplied with the projector.

To use the microphone to talk over the sound on film:

1. Run a film with a sound message.
2. Plug the microphone into the MIC jack.
3. Turn the MIC volume control on and adjust the level to be heard over the film sound message.

To use the microphone with the projector as a PA system:

1. Press the STOP button on the projector.
2. Turn the power switch ON.
3. The microphone can be used with the internal speakers in the projector. If an external speaker (Telex catalog number 2238) is desired, plug the speaker into the SPKR (speaker) jack.
4. Plug the microphone in the MIC jack.
5. Adjust the MIC volume control for a comfortable listening level.



Microphone Connection

MAINTENANCE

COVER REMOVAL/REPLACEMENT

Operator maintenance procedures sometimes require removal of the two covers on the operator side of the projector. To remove and replace covers:

WARNING

Always disconnect the power cord prior to removal of the covers.

Lens Cover

1. To remove the lens cover, position the master control lever to LOAD, loosen the captive lens cover screw, and pull the cover outward.
2. To replace the lens cover, position the lens cover, and tighten the lens cover screw.

Lamphouse Cover

1. To remove the lamphouse cover, position the master control lever to LOAD, pull out on the "film routing" knobs (with directional arrows) at the base of the cover, and lift up and out on the cover.

NOTE

On Models 2280/81, this releases an interlock switch which disables the projector lamp.

2. To replace the lamphouse cover, align the top of the cover so the two clips on the projector are visible through the widest grille openings. Press down on the cover to engage the clips, and push both knobs of the cover toward the projector until the cover snaps into the locked position.

CLEANING

Film Gate Area


The film gate should be cleaned periodically (if used regularly, a weekly cleaning is recommended). To clean the film gate:

1. Remove the lens cover.
2. Thoroughly clean the pressure shoe (which is connected to the removed lens cover) using the aperture brush (Telex catalog number 3694) dampened with a suitable solvent such as isopropyl alcohol.

CAUTION

Take care not to scratch the polished surfaces of the pressure shoe and aperture plate with the metal shaft of the aperture brush.

3. Thoroughly clean the aperture plate using the aperture brush dampened with a suitable solvent such as isopropyl alcohol.
4. Replace the lens cover.



Cleaning Film Gate Area

Lens

The lens should be cleaned periodically. To clean the lens:

1. Remove the lens cover.
2. Remove the lens by loosening the lens screw and rotating the lens focus thumbwheel to the left (clockwise).

3. Remove dust from the front and rear lens surfaces by gently brushing with a soft brush.
4. Wipe the lens gently with a clean lens tissue (slightly moistened with lens cleaner if necessary).

CAUTION

Do not use silicon-impregnated eyeglass tissues on coated projection lenses.

5. Replace the lens in the projector by rotating the lens focus thumbwheel to the right (counterclockwise) until the thumbwheel can be rotated no longer and the lens is fully retracted.
6. Tighten the lens screw. (The screw retains the lens in a captive range.)
7. Replace the lens cover.

Sound Optics

The sound optics should be cleaned periodically (if used regularly, a weekly cleaning is recommended). To clean the sound optics:

1. Remove the lamphouse cover.
2. Moisten a cotton swab with isopropyl alcohol, and clean the dust off of the top lens (just below the exciter lamp).
3. Replace the lamphouse cover.



Cleaning Sound Optics

LAMP REPLACEMENT

Projection Lamp (Except 2280/81)

1. Remove the lamphouse cover.

WARNING


Allow the lamp to cool prior to replacement.

2. Pull back on the lamp release lever to remove the defective lamp, and return the release lever to the original position.
3. Position a new ELC-type lamp (Telex part number 42762-P4), and push it carefully into the lamp receptacle. The lamp reflector rim must be fully seated in the recess of the lamp socket frame.

CAUTION

Handle the lamp by the base and/or outside of the reflector, as skin oils will discolor the reflector and reduce lamp life.

4. Replace the lamphouse cover.



Projection Lamp Replacement

Projection Lamp (Models 2280/81)


1. Remove the lamphouse cover.
2. Check the fuse in the lamp power supply before replacing the lamp. Replace if necessary.
3. If the fuse is good, remove the defective lamp by unplugging the lamp, drawing the lamp shield off its support rod, holding the lamp retainer clip away from the lamp, and lifting the lamp out of the lamp holder.
4. Install the new lamp (Telex part number 46554-P1) with the longer wire terminal away from the projector and the lamp seated all the way down in the holder.
5. Replace the lamp house cover.

CAUTION

Be careful not to pinch the lamp wires between the cover shield and the main casting of the projector.

Exciter Lamp

1. Remove the lamphouse cover.
2. Turn the lamp counterclockwise. (It will turn more easily if the lamp is rocked or wiggled rapidly from side to side).
3. To replace the lamp, align the three slots in the new BSW-type lamp (Telex part number 38386-P2) with pins in the socket, push lamp inward, and turn clockwise to lock in place.
4. Wipe the lamp clean to remove fingerprints.
5. Replace the lamphouse cover.



Exciter Lamp Replacement

REEL BELT REPLACEMENT

1. Disconnect the hooked ends of the old belt, pull the belt out, and discard.

NOTE

Replace old belts with Telex belts only: supply arm belt (part number 42981-P1), and take-up arm belt (part number 42981-P2). The supply arm belt is approximately 20¾ inches long, and the take-up arm belt is approximately 24 inches long.

2. Push one end of the new belt through the projector opening on the inner side of the reel arm into the groove of the lower pulley until it appears through the opening on the other side of the reel arm. (When replacing the take-up arm belt, the master control lever must be in the LOAD position.)




Reel Belt Replacement

3. Hook the two ends together, and route the belt around the upper pulley.

LENS REPLACEMENT

Install a lens replacement in the projector as follows:

1. Remove the lens cover.
2. Loosen the lens screw through approximately four counterclockwise turns.
3. Remove the existing lens from the projector by rotating the lens FOCUS thumbwheel to the left (clockwise).
4. Insert the replacement lens into the projector and rotate the lens FOCUS thumbwheel to the right (counterclockwise) until the thumbwheel can be rotated no longer and the lens is fully retracted.
5. Tighten the lens screw. (The screw retains the lens in a captive range.)
6. Replace the lens cover.



Lens Replacement

FILM CARE PRECAUTIONS

1. Never pull the film tight on the reel because the emulsion may become scratched with "cinch" marks. (The projector rewinds film with just the right amount of tension.)
2. For storage and film protection, secure the loose end of film with masking tape. To form a tab for easy removal, make a small loop with the masking tape (sticky side out), and place it about one inch from the end of the film.
3. Protect the film from dust by placing the reel in a storage can promptly after showing.
4. Store film cans away from heat.

FUSE REPLACEMENT

If it becomes necessary to change a fuse (international models only):

1. Unscrew the fuse, using a small flat-blade screwdriver.
2. Replace the defective fuse with a fuse rated for 3.5 amps, 250 volts (Telex part number 410-14).

LUBRICATION

The projector is factory-lubricated and needs only periodic maintenance. It is highly recommended that preventive maintenance be performed every 500 hours of operation or every 12 months (or sooner if the projector is used in an unusually dirty environment). The projector should be serviced by an authorized Telex projector service facility.

MALFUNCTIONS

MALFUNCTION

WHAT TO DO

Projector doesn't run.

Plug power cord into live outlet.

Depress FWD (forward) button completely.

Raise master control lever completely.

Check fuse (international models).


MALFUNCTIONS (CONT)

No picture on screen.	Raise master control lever completely. Replace projection lamp with ELC type. Set power switch to ON (Models 2270/71, 2280/81). Rotate manual advance knob (when operated in STILL mode).
Projected picture unsteady.	Check film for damage. Check for proper threading.
No sound.	Adjust volume control. Check OPT/MAG switch position (Model 2251). Replace exciter lamp with BSW type. Try another film.
Poor sound.	Check for proper threading. Try another film. Clean sound optics. Replace exciter lamp with BSW type.
Microphone doesn't work.	Insure that power is on. Turn microphone control on and adjust level. Insure that microphone plug is fully seated. Try another microphone.

INTERNATIONAL MODEL CONVERSIONS

International models are wired for 220/240-volt, 50 Hz operation. If the projectors are to be used with a 100- or 120-volt, 60 Hz power source, it will be necessary for a qualified technician to perform the following modification steps.

1. Disconnect the power cord from the power source.
2. Replace the 3.15-amp, 250-volt, time-lag fuse (Telex part number 410-14) with a 5.0-amp, FST time-lag fuse (Telex part number 410-20).
3. Change frequency by "rolling" the drive belt off the pulley into the alternate groove. (See Frequency Conversion.)
4. Make transformer wiring changes. (See Transformer Wiring Conversions.)




Frequency Conversion

TRANSFORMER WIRING CONVERSIONS

100-VOLT POWER INPUT


CONNECT MAINS TO



CHANGE LINE FUSE TO 5 AMP, FST, TIME LAG.

120-VOLT POWER INPUT


CONNECT MAINS TO



CHANGE LINE FUSE TO 5 AMP, FST, TIME LAG.


220-VOLT POWER INPUT

CONNECT MAINS TO



240-VOLT POWER INPUT

CONNECT MAINS TO



NOTE: OTHER WIRES AND CONNECTIONS ELIMINATED FOR CLARITY.

OPTIONAL ACCESSORIES

Description	Catalog No.
Lens Adapter	2900A
16 mm ($\frac{5}{8}$ -inch), f/1.9 Lens	2906
25 mm (1-inch), f/1.9 Lens	2910
38 mm ($\frac{1}{2}$ -inch), f/1.6 Lens	2915
50 mm (2-inch), f/1.2 Lens (standard)	2212
64 mm (2 $\frac{1}{2}$ -inch), f/1.6 Lens	2925
75 mm (3-inch), f/2.0 Lens	2930
100 mm (4-inch), f/1.6 Lens	2940
Zoom Converter	2900Z
16D Lens Bracket (for anamorphic lens)	2901
16D Anamorphic Lens (wide screen)	2902
Lift-Off Speaker Cover	2238
Power Cord (for international models)	2990
Aperture Brush	3694
Dust Cover	2239
Service Instructions Manual	2200A
Parts Listing Manual	2200B

SERVICE

Sometime during the life of any projector, repair or adjustment may be required. When this becomes necessary, we suggest that you return the projector to the dealer from whom it was purchased or to one of the approved dealers shown in the Authorized Regional Warranty Service Stations directory which was packed with this projector.

We also maintain these factory service departments:

CENTRAL/WESTERN U.S. REGION:

Telex Communications, Inc.
West First Steet
Blue Earth, MN 56013 U.S.A.
Phone: (507) 526-3205

EASTERN U.S. REGION:

Telex Communications, Inc.
1406 Bergen Blvd.
Ft. Lee, NJ 07024 U.S.A.
Phone: (201) 947-0666

CANADA:

Telex Communications, Ltd.
705 Progress Avenue, Unit 10
Scarborough, Ontario M1H-2X1 Canada
Phone: (416) 431-4975

For further information regarding these products, contact the Visual Product Sales Department at the following address:

HOME OFFICE:

Telex Communications, Inc.
9600 Aldrich Ave. So.
Minneapolis, MN 55420 U.S.A.
Phone: (612) 887-5531

TELEX[®]

TELEX COMMUNICATIONS, INC.

9600 Aldrich Ave. So., Minneapolis, MN 55420 U.S.A.

SERVICE MANUAL

INSTA LOAD/XL 2200 SERIES

SERVICE INSTRUCTIONS

CUSTOMER SERVICE
1-800-828-6107



TELEX COMMUNICATIONS, INC.

9600 Aldrich Ave. So., Minneapolis, MN 55420 U.S.A.

INSTA LOAD/XL
2200 SERIES

SECTION I GENERAL INFORMATION

SECTION II PREVENTIVE MAINTENANCE

SECTION III DISASSEMBLY and REASSEMBLY ADJUSTMENTS

SECTION IV ELECTRICAL SYSTEM

SECTION V ELECTRICAL CIRCUIT ADJUSTMENT

SECTION VI TROUBLE SHOOTING

FOR CHANGEOVER SYSTEM SEE
BULLETIN # 19-520

SECTION I GENERAL INFORMATION

A. PRINCIPLES OF OPERATION

All Telex Insta Load/XL projectors may be divided into eight basic functions:

1. The Main Drive System.
2. The Feed and Rewind System.
3. The Gate and Lens Mount.
4. The Auto-Loop Restorer.

5. The Sound Drum and Optic.
6. The Take-Up System.
7. The Flywheel Drive System.
8. The Electrical System.

A thorough understanding of each function and its relationship with the other functions will be a great assistance in servicing these projectors.

THE MAIN DRIVE SYSTEM

All functions are driven from a single drive shaft (34) which is turned by a reversible motor through a drive belt (Figure 1). Two worm gears (20) & (32) (drive gears), pinned to the shaft, drive the Take-Up Clutch gear and the Feed Sprocket Clutch gear. The Shutter (26) and the Safety Shutter (24) (in models which have the still feature) are mounted on this same drive shaft. Reverse operation of the projector is accomplished by changing the direction of rotation of the drive shaft by reversing the drive motor. (See Power Supply and Motor Drive Circuits.)




Figure 1

FEED AND REWIND SYSTEM

The feed and rewind system consists of three clutches: the Feed Sprocket Clutch (37), the Rewind Clutch (27) and the Fast Forward Clutch (32) (on models having that feature). (Figure 2).

The Feed Sprocket Clutch is driven by the front worm gear on the main drive shaft (Figure 1). It, in turn, drives the Fast Forward and Rewind Clutches. The drive it supplies is direct in all forward modes and in Rewind, and clutched in Reverse.

The Rewind Clutch slips freely in all forward modes, but is locked in direct drive in Reverse and Rewind by the Rewind Solenoid. It, therefore, provides no drive to the supply reel in forward modes but always supplies direct drive to the supply reel through the reel arm belt in Reverse and Rewind.

The Fast Forward Clutch slips freely in every mode but Fast Forward. In the Fast Forward mode, it is locked into direct drive by the Fast Forward Solenoid and drives the take-up reel through the Fast Forward Drive Belt and the Take-up Reel Arm Belt.




Figure 2

FORWARD (Figure 3)

The tail of the Clutch Spring (6) is permanently trapped in a notch (N) in the Clutch Gear (14). The coil of the spring wraps around the arbor of the Clutched Gear (3). When the projector runs in any forward mode, the clutch gear rotates in a clockwise direction (as viewed from the back of the projector) pushing the tail of the spring to clamp it tightly around the arbor so the Clutched Gear (3) is directly driven by the clutch gear through the clamping action of the spring. The drive of the worm gear on the main shaft is thus directly connected to the Rewind and Fast Forward clutches (Figure 4, 27 & 32) through the clutch gear (14), clutch spring (6) and clutched gear (3).

Since the Rewind Clutch is not locked in direct drive in any forward mode, it does not drive the supply reel. Film is pulled from the supply reel by the feed sprocket, which is fastened to the shaft of the Clutch Gear (14).

The Fast Forward Clutch also slips and does not drive the take-up reel

REVERSE (Figure 3)

When the projector runs in reverse, the notch (N) in the clutch gear (14) moves in a counterclockwise direction moving the tail of the clutch spring (6) to open the spring coil and allow the spring to slip on the arbor of the clutched gear (3). This provides a clutched drive to the Rewind Clutch, which is locked in direct drive in both reverse and rewind. This is necessary so the Rewind Clutch will drive the supply reel in reverse only as fast as film is supplied to it from the feed sprocket.

FAST FORWARD (Figure 4)

In the Fast Forward mode, the Feed Sprocket Clutch is locked into direct drive as described above. Now the Fast Forward solenoid and the Interlock solenoid operate to lock the Fast Forward clutch (32) into positive drive and freeze the gate closing mechanism respectively. Film is thus transported rapidly forward either "In-Path" or Reel to Reel.




Figure 3

REWIND (Figure 3)

When the projector is operated in the Rewind mode, the interlock solenoid operates and pushes the Guide Pin (2) in. Since the Spring (1) is threaded through the Guide Pin (2) and into the Gear Pin (11), both the spring and the gear are also pushed in. The gear pin strikes the side of the Roll Pin (R) in the Clutch Gear (14) and locks the clutched gear and the clutch gear together to provide direct drive in the rewind mode.

The interlock solenoid also pushes an interlock pin through the main casting into the film gate closing mechanism to prevent the gate from being closed on the film when film is being rewound rapidly "In-Path".




Figure 4

GATE AND LENS MOUNT

The film is held securely in place against the aperture plate by the film pressure shoe (Figure 5). It is fed into this channel from the feed sprocket which is just above the lens mount.

When the Master Control Lever is moved from LOAD to PROJECT, the loop setting cables turn the front sprocket approximately 3/4 turn counterclockwise to establish the upper loop.

The pins on the claw arm enter the sprocket holes from behind the aperture plate and pull the film down through the channel one frame at a time (Figure 6). When the framing adjustment is properly made, each picture frame will line up exactly in front of the hole in the aperture plate through which the projection lamp shines. The light shines through the film and the image is projected onto a screen and focused by means of the projection lens.

The film is moved through the film gate at the rate of 24 frames/second by moving the claw arm into the sprocket holes, then down, then out of the sprocket holes and then up to start the cycle over again. During the actual movement of the film through the gate area by the claw arm, light is prevented from being projected onto the screen by one of the shutter blades which moves between the projection lamp and the film. As soon as the claw arm has moved the film into position in front of the hole in the aperture plate, the shutter blade moves out of the way to allow light to pass through the film and project an image on the screen. This momentary interruption of light by the shutter blade while the film is moving prevents what would appear to be streaming of the picture. However, the light interruption is so rapid that only a small amount of flicker is discernible by the human eye. The claw arm and shutter are synchronized by a cam which is part of the shutter assembly and turns at the same rate of speed as the main shaft.




Figure 5




Figure 6

AUTOMATIC LOOP RESET THEORY

The automatic loop reset is driven by a neoprene drive belt from the flywheel drive shaft.




Figure 7

The small pinion gear and idler gear run continuously while the projector is operating. The large loop resetting gear turns only when the lower loop is being reset.




Figure 8

**IDLE
POSITION**




Figure 9

In the idle position, the ramp on the back edge of the loop resetting gear holds the Idler Gear away from the Resetting Gear. The loop resetting gear is prevented from turning by the engagement of the gear latch tab on the loop resetting arm with the raised lip on the eccentric stud of the loop resetting gear. The loop resetting gear is held under tension by the kick spring which is cocked against the upper corner of the "D" shaped mounting hub of the loop setting gear.

When the lower film loop is lost, the loop reset arm is pulled up, lifting the gear latch tab away from the raised lip on the eccentric stud. The kick spring forces the loop reset gear to turn slightly counterclockwise to the flat of the "D" shaped shaft. This rotation forces the ramp set gear down allowing the idler gear to engage the loop reset gear and start it turning. The eccentric stud forces the loop reset arm down and up to reset the lower film loop. At the end of the cycle, the ramp forces the idler gear away from the loop reset gear and the raised lip on the eccentric stud latches against the gear latch tab on the loop reset arm.




Figure 10

SOUND DRUM AND OPTIC

After leaving the gate and lens mount area, the film passes over the sound drum. It is here that the sound information recorded on the sound track portion of the film is detected.

Sound information is recorded on the film by causing an audio signal to vary the intensity of a beam of light which is focused on the sound track portion of the film. The varying intensity of the light exposes the film in varying degrees corresponding to the frequency and amplitude of the audio signal itself.

To replay the audio track, a beam of light from an exciter lamp is passed through this exposed part of the film and onto a light sensitive device which transforms it into electrical energy (Figure 11). The electrical energy will then vary at the same rate and with the same amplitude as the exposed portions on the film sound track. These electrical variations are fed into the audio amplifier where they are amplified and eventually drive the speakers to reproduce the original sound.

A pressure roller in front of the sound drum holds the film firmly against the sound drum and a dampening roller behind the sound drum maintains a constant film speed over the sound drum for maximum fidelity of sound reproduction.

The movement of film over the sound drum causes the sound drum to rotate. A balanced flywheel mounted on the end of the sound drum shaft maintains a constant rotational speed of the sound drum which also insures maximum fidelity of sound reproduction.

TAKE UP SYSTEM

Film is drawn through the sound drum portion of the projector by the take-up sprocket, then passed over the reel tension arm pulley and is gathered on the take-up reel (Figure 12). The take-up sprocket turns at a constant rate of speed since it is attached to the shaft of the take-up gear which is driven by the rear worm gear on the main drive shaft. Film is thus fed to the take-up reel at a constant rate of speed. However, the take-up reel must be able to turn at a variable speed since the diameter of its take-up surface varies continuously as film is gathered on it. The drive mechanism which drives the take-up reel with the reel arm belt is, therefore, continuously clutched and self-adjusting to compensate for the increased diameter and weight of the take-up reel.





Figure 11



Take-Up Sprocket



Take-Up Clutch

Figure 12

INSTA LOAD/XL
2200 SERIES

The clutching action is provided by the interaction of the take-up clutch arm and pulley (9), the take-up clutch liner (16), and the take-up clutch gear (17). (Figure 13). The liner fits snugly inside the gear and the pulley fits inside the liner.

The clutch is adjusted so the top part of the pulley contacts the liner when the projector is run in the forward mode. The gear is driven by the worm gear on the main shaft and rotates continuously while the machine is running. The liner rotates along with the gear and turns the pulley. The pulley drives the reel arm pulley by means of the reel arm belt. The surface of the clutch pulley is polished and can slip on the liner when necessary to provide the clutching action.

The system is designed so the take-up reel is capable of taking the film faster than the film is fed to it by the take-up sprocket, so film will not be spilled when the clutch is working properly. Since the take-up reel tries to take up film faster than the film is being fed to it, the mechanism which drives it must provide a sufficient amount of drive while at the same time be able to slip to prevent film from being pulled through the take-up sprocket. The fact that the take-up clutch pulley can slip inside the take-up clutch liner allows for this to happen.




Figure 13

The mechanism is self-adjusting during the entire take-up cycle because of the way the take-up reel arm is attached to the take-up clutch arm. The shaft of the take-up reel arm passes through a hole in the take-up clutch arm. A roll pin is inserted in a hole in the reel arm shaft and pushes down on the upper end of the clutch arm causing the arm to pivot and push up on the lower portion. This forces the pulley against the clutch liner which is inside the clutch gear. More weight placed on the reel arm causes more downward pressure on the roll pin and upper end of the clutch arm, resulting in more upward pressure of the pulley against the clutch liner. This results in more friction between the clutch liner and the pulley producing more take-up drive. Thus when the film take-up reel gets heavier because it is taking on more film, it causes greater force between the clutch pulley and liner resulting in the increased torque needed to drive the heavier reel.




Figure 14

FLYWHEEL DRIVE SYSTEM

When the projector is operated in the Reverse mode, the friction of the film traveling over the sound drum is not sufficient to drive the sound drum. This causes increased drag on the film resulting in the loss of the lower loop with a consequent increase in noise in the film gate area. The flywheel drive system eliminates this problem by driving the flywheel in reverse to reduce the drag on the film and maintain the lower loop.

The Flywheel Drive mechanism is driven by a gear mounted on the main shaft. In the forward modes, the gear friction forces the drive tire away from the Flywheel preventing the mechanism from driving it. However, in the reverse modes, the gear friction forces the drive tire onto the flywheel causing it to rotate.




Figure 15.

B. SPECIFICATIONS


Height;	14.5"	36.83cm	Depth;	17.75	45.08cm
Width;	11.625"	29.53cm			
Weight	Simplified Control Models:		Approximately 36 lbs., 16.20kg.		
	Fast Forward Models:		Approximately 38 lbs., 17.10kg.		
	International Models:		Approximately 40 lbs., 18.20kg.		
Base to Optical Centerline	8"	20.32cm			
Film Speed:	24 frames per second				
Auto-Loop Reset:	Automatically maintains image to sound synchronization when film has damaged perforations.				
Exciter Lamp:	ANSI Code "BSW" P/N 38386-P2				
Projection Lamp :	ANSI Code "ELC" P/N 42762-P2 (24 volt, 250 watt)				
	ARC Models: "EZG" P/N 46554-P1 (Common-3cc)				
Lamp Position			Lamp Life		
"Hi"			Approx. 50 hours		
"Lo"			Approx. 150 hours		
Amplifier:	25 watt RMS, continuous power per ANSI Standard PH 7.2				
Speakers:	Twin 3" x 5" (7.69cm x 12.82cm) Oval, case mounted.				
External Speaker:	Standard 1/4" (6.35mm) jack. Use 8 ohm speaker for optimum performance. Internal speakers are bypassed when using an external speaker.				
Microphone:	Standard 1/4" (6.35mm) jack, 400 ohm impedance.				
Power Requirement:					
Standard Model:	120V, 60 Hz., 4 amp.				
International Models:	100V, 50/60 Hz., 4 amp.				
	120V, 50/60 Hz., 4 amp.				
	220V, 50/60 Hz., 2 amp.				
	240V, 50/60 Hz., 2 amp.				

INSTA LOAD/XL
2200 SERIES


TERMINALS

PART NUMBER	WIRE SIZE	INSULATION	STRIPPING	TAB SIZE	SCREWS
39338	16-22 AWG	140 max	.155-.215		#8
41004	16-22 AWG	140 max	.155-.215		#6


ILLUSTRATION




38298	18-22 AWG	.050-.115	.125-.185		
-------	-----------	-----------	-----------	--	--



39321	20-24 AWG	.048-.071	1/8"		
-------	-----------	-----------	------	--	--




38998	18-22 AWG	.090-.132	1/4"	.250	
-------	-----------	-----------	------	------	--




42423	20-22 AWG	.075 max	.125-.185		
-------	-----------	----------	-----------	--	--



49042	14-18 AWG	.120-.170	.210-.240	.250	
42737	18-22 AWG	.060-.100	.185-.225	.250	



43457	18-24 AWG	.100 max	.125-.155		
-------	-----------	----------	-----------	--	--




41338	18-20 AWG	.080-.120	.156-.219	.103	
-------	-----------	-----------	-----------	------	--



43965P1	14-18 AWG	.105-.145	.220-.280		
---------	-----------	-----------	-----------	--	--



45144P1	20-26 AWG	.035-.060	.125-.185		
---------	-----------	-----------	-----------	--	--



44549P1	20-22 AWG	.060-.100	.155-.185	.100	
41098P1	18-22 AWG	.060-.100	.155-.185	.110	
38994P1	16-20 AWG	.090-.130	.125-.185	.187	



44508P1	24-30 AWG		.100-.125		
---------	-----------	--	-----------	--	--






44360P1	18-24 AWG	.060-.120	.125-.155		
---------	-----------	-----------	-----------	--	--



44360P2	18-24 AWG	.060-.120	.125-.155		
---------	-----------	-----------	-----------	--	--



INSTA LOAD/XL
2200 SERIES

PART NUMBER	WIRE SIZE	INSULATION	STRIPPING	TAB SIZE	ILLUSTRATION
41438	14-18 AWG	.100-.130	.140-.170		
43225	20-22 AWG	.080-.100	.125-.185		
41440	14-18 AWG	.100-.130	.140-.170		
37583	16-22 AWG		7/32	#3 or #4 Screw	
43497	18-22	.136 max	.250-.280	#6 Screw	

INSTA LOAD/XL
2200 SERIES

C. MATERIALS

ADHESIVES

39490-P2 Glyptal No. 1276; Clear (General Electric Co., Schenectady, New York) 3 oz.
39490-P1 Glyptal No. 7526; Blue (General Electric Co., Schenectady, New York) 3 oz.
LP A-963-B Cement (W. J. Ruscoe Co., Akron Ohio)
LP Hysol R9-2039 Resin (Hysol Corp., Olean, New York)
LP Hysol H2 -3404 Hardener (Hysol Corp., Olean, New York)

LUBRICANTS

39479-P4 FS-1290 Fluorosilicone Grease (Dow-Corning Corp., Midland, Michigan) 1/2 oz.
39479-P5 DC-200 Silicone Fluid; 200,000 Centistroke Viscosity (Dow-Corning Corp., Midland, Michigan) 1/2 oz.
39479-P13 DC-200 Silicone Fluid; 200 Centistroke Viscosity (Dow-Corning Corp., Midland, Michigan) 1/2 oz.
39479-P7 009 Lubricant (Keystone Carbon Co., St. Mary's, Pa.) 1/2 oz.
39479-P8 Instrument Oil N-75 2 oz.
39479-P9 DC-44 Silicone Grease; Light Consistency (Dow-Corning Corp., Midland, Michigan) 2 oz.
39479-P14 G.E. Versilube (G-322L)
39479-P15 Vischem #352 (Ultra Chem Inc., Wilmington, Del) 2 oz.

MISCELLANEOUS

39490-P4 Clyptal Thinner 1511M 8 oz.
LP 8101-S Silicone Compount (General Cement, Rockford, IL)
LP Chlorothene (Dow Chemical Co., Midland, Michigan) 1+1+1
LP Methyl Alcohol

TEST FILMS

*40478-P3 TV16AS 16mm Television Test Film(Alignment & Resolution) 40" Loop
*45191-G2 P16-SF-A 7000 Hz Film (PH 22.42-7) 12'
*45191-G3 P16-B.T. Buzz Track Film (PH22.57) 12'
*45191-G8 16-RT 16mm Registration Test Film 12'
*45191-G7 P16-SL, Signal Level Test Film, Optical 400 Hz. 12'
** P16-PP SMPTE Jiffy Test Film

*Available in 100' Roll from: Test Film Dept.
Society of Motion Picture & Television Engineers
862 Scarsdale Avenue, Scarsdale, NY 10583

**Also available through above source.


D. TOOLS

G10-38000 CLAW ARM PROTRUSION GAUGE
ST-5880 STROKE SETTING GAUGE
ST-5884 SHUTTLE CAM ADJUSTING TOOL
T-38000-N ROLL PIN - INSERTING AND EXTRACTING TOOL
T-38000-N1 REPLACEMENT PIN
T-38000-S FILM TENSION GAUGE
T-38000-U WALDES TRU-ARC NO. 52 APPLICATOR
T-38000-V WALDES TRU-ARC NO. 54 APPLICATOR
T-38000-X WALDES TRU-ARC NO. CR-31 APPLICATOR
T-38001-G SOUND DRUM LOCATING PLUG

INSTA LOAD/XL
2200 SERIES

DRIVE UNIT ASSEMBLY TV


TRIM MOTOR SHAFT 5/16"
AFTER LOCATING .06" HOLE



PART No.	DESCRIPTION	PART No.	DESCRIPTION
1	39099 COLLAR	10	GROUND STRAP
2	38206-3 BEARING	11	35473-46X WASHER
3	40465-G2 PULLEY ASSEMBLY	12	39081 SPACER, Rubber
4	39098-P1 SPRING	13	30473-P73H WASHER
5	42872-G1 HUB ASSEMBLY	14	32090-P48 SPACER
6	192-4-8 PIN	15	265-5 GROMMET
7	39128-P1 FAN	16	47239-G1 MOTOR PLATE
8	257-2 RETAINER, Modified	17	116-10R-8H SCREW, Mounting
9	203-8 NUT, Stop	18	40459-G3 MOTOR ASSEMBLY
			40460-P2 MOTOR
			44360-P1 TERMINAL (Not Shown)
			44505-P9 HOUSING (Not Shown)

INSTA LOAD/XL
2200 SERIES



2230 T.V. Projector
Drive Motor Plate
Modification



Holes:

- A- 7/16" end mill
- B- (with end mill).

2230 T.V. Projector
Lampholder Modification
to hold Opal Glass




This assembly in "A" hole only.
Other two holes - delete item 3.
Install Opal glass coated side to lamp.



1. 38473-P7X Washer
2. 41086-P8 Spacer
3. AV16-41-8 Retainer
4. 1/8" x 1/4" Pop Rivet

NSTA LOAD/XL
2200 SERIES

LOW VOLTAGE REMOTE



INSTA LOAD/XL
2200 SERIES




INSTA LOAD/XL
2200 SERIES

0 dbm
List of Materials


1	43176-P2	Jack
1	Triad T32X	Transformer
1	42267-P1	Capacitor, 10 mfd., 25 volt
1	45147-P6	Capacitor, .0015 mfd., 100 volt
1	415B-P472K-C	Capacitor, .0047 mfd., 12 volt
1	402-18-0-3	Resistor, 18 ohm, 1/2 watt
1	406-392-3	Resistor, 3.9K, 1/4 watt
1	406-822-3	Resistor, 8.2K, 1/4 watt
1	406-103-3	Resistor, 10K, 1/4 watt
1	406-333-3	Resistor, 33K, 1/4 watt
1	406-154-3	Resistor, 150K, 1/4 watt
1	40761-P12	Potentiometer, 100K
1	42727-P1	Transistor, 2N2923
1	AV16-12-11	Circuit Board
AR	43618-G2	Cable
1	39472-P1	Butt Connector
1		0 dbm Label
3	43485-P1	Standoff
2	200-4	Nut, 4-40
2	116-4R-4H	Screw, 4-40 X 1/4

INSTA LOAD/XL
2200 SERIES



PROJECTOR SCHEMATIC DIAGRAM MODEL 2210
WITH SYNCHRONOUS MOTOR


NSTA LOAD/XL
2200 SERIES



PROJECTOR SCHEMATIC DIAGRAM MODEL 2230

○ = 11 PIN SOCKET

INSTA LOAD/XL
2200 SERIES



PROJECTOR SCHEMATIC DIAGRAM - MODEL 2230N


INSTA LOAD/XL
2200 SERIES

SECTION II PREVENTIVE MAINTENANCE

PARA.	TITLE	PAGE
A.	CLEANING and LUBRICATION	2-2
B.	SPRING LINK ADJUSTMENT	2-5
C.	COUNTER ADJUSTMENT	2-5
D.	LOOP SETTING CABLE REQUIREMENT & ADJUSTMENT	2-7
E.	LOOP SETTING GEAR AND ARBOR INSTALLATION	2-7
F.	REEL ARM PULLEY SERVICING	2-8
G.	SOUND DRUM AREA SERVICING	2-9
1.	FILM DAMPENER ARM ADJUSTMENT	2-10
2.	FRONT PRESSURE ROLLER ADJUSTMENT	2-11
H.	CAM LUBRICATION PAD SERVICING	2-11
J.	INTERNAL MECHANISM SERVICING	2-12
K.	MOTOR PULLEY SERVICING	2-13
L.	SAFETY SHUTTER	2-13
M.	SHUTTER AND CAM OPERATION & ADJUSTMENT	2-14
1.	SIDE CLEARANCE	2-14
2.	CLAW PIN REQUIREMENT & ADJUSTMENT	2-15
O.	PRESSURE SHOE	2-17
P.	AUTOMATIC LOOP RESET SERVICING	2-17
Q.	DRIVE BELT	2-18
R.	REWIND BRAKE	2-19
S.	TAKE-UP ADJUSTMENT	2-19
T.	LIFT OFF	2-20
U.	FAST FORWARD	2-20
V.	BUZZ & SOUND OPTIC FOCUSING	2-21
1.	SOUND OPTIC FOCUSING ADJUSTMENT	2-23
2.	BUZZ ADJUSTMENT	2-23
W.	FINAL PERFORMANCE TEST	2-23
X.	PREVENTIVE MAINTENANCE LUBRICATION CHART	2-24
Y.	OVERHAUL MAINTENANCE LUBRICATION CHART	2-25
Z.	OPERATION CHECK	2-16

SECTION II PREVENTIVE MAINTENANCE

To insure proper operation of Telex Model 2200 Projectors, preventive maintenance should be performed every 500 hours or once a year, whichever occurs first. The Projector should be thoroughly cleaned and then checked for proper operation before any parts replacement or adjustments are attempted.



1. Reel Spindle Lock Lever
2. Take-up Sprocket
3. Lamphouse Cover
4. Framing Knob
5. Feed Sprocket
6. Reel Arm Lock
7. Manual Advance Knob
8. Elevation Knob
9. Auto Loop Restorer
10. Hi-Lo Lamp Switch
11. Speaker Jack
12. Film Control Buttons
13. Film Pressure Shoe
14. Volume/Tone Control
15. Main Power Switch (2270 & 2280)
16. Microphone Jack (2270 & 2280)
17. Microphone Control (2270 & 2280)
18. Master Control Lever
19. Film Counter

**START WITH A CLEAN BENCH-
FINISH WITH A CLEAN BENCH.**

Left over parts?

Check your reassembly.

INSTA LOAD/XL
2200 SERIES

Cleaning Suggestions

1. All dust and grime should be removed from external surfaces of covers, main casting, etc. Any good household detergent should be sufficient.
2. Projection lens - Remove lens. Remove dust from front and rear exposed lens surfaces by brushing gently with a soft brush. Then wipe lens gently with a clean lens tissue (slightly moistened with lens cleaner if necessary).

CAUTION: Never pour lens cleaner or other solvents on the lens elements. DO NOT use silicone impregnated lens tissue.
3. Projection Lamp and Exciter Lamp. Remove dust by brushing gently with a soft brush. Then wipe gently with a clean lens tissue (slightly moistened with lens cleaner if necessary).
4. Aperture Plate and Film Pressure Shoe

Open the film channel by moving the Master Control Lever to PROJECT. Turn the lens forward. Insert the Aperture Brush (Cat. 3694) into the top of the channel and move it vigorously up and down. Use care to keep the shaft of the brush away from the pressure shoe or the film track. If necessary, dampen the brush with solvent to loosen and remove any hardened substance.
5. Claw Arm - Remove all lint and dirt from pins on Claw Arm with a soft bristled brush. Examine pins for looseness or grooves cut in them by film. (Solvents may be used for this cleaning).
6. Film Rollers For proper cleaning, Rollers should be removed and wiped thoroughly with clean, dry rag. Remove stubborn dirt from plastic Rollers with detergent and warm water. Dry thoroughly. Shaft holes may be cleaned with cotton swabs or a pipe cleaner moistened with instrument oil N-75. Roller end play should be .002" to .005".
7. Sprockets - Wipe with clean, dry cloth. (Cloth may be moistened with alcohol if necessary.)
8. Reel Arm Pulleys - Clean grooves with cotton swabs moistened with alcohol or chlorothene. Wipe flat surfaces with clean rag moistened with alcohol or chlorothene.
9. Sound Drum - Clean grease and dirt from general area with alcohol. Moisten cotton swab with alcohol and clean Photo-diode and back edge of Sound Drum.
10. Sound Optic - Moisten cotton swab with lens cleaner or alcohol and clean upper and lower lenses.
11. Motor Pulley and Main Shaft Pulley - Clean drive surfaces with clean rag moistened with alcohol or chlorothene.
12. Shutter - Wipe all visible surfaces of Shutter and Cam Assembly using a cloth dampened with chlorothene or alcohol.
13. Safety Shutter - Wipe all visible surfaces of Safety Shutter using a cloth dampened with chlorothene or alcohol.
14. Lexan Gears - (Main Drive Shaft Worm Gears, Film Feed Clutch Gear and Takeup Clutch Gear) - DO NOT clean Lexan Gears with ANY solvent. Wipe clean with clean, dry cloth or remove excess, dirty grease with toothbrush.

A. CLEANING and LUBRICATION


Some Useful Cleaning tools.




Be sure to use correct lubricant as specified by the lube charts and instructions. Improper lubricant can cause damage.



Clean the front of the projector thoroughly. Stubborn dirt may be removed with Isopropyl Alcohol, Chloroethene 1+1+1 or equivalent.



Be sure to clean the claw thoroughly. Remove all accumulated dirt from the claw pins.




INSTA LOAD/XL
2200SERIES

The idlers at the take-up sprocket are secured with grip rings. The idler must turn freely with approximately 0.002" to 0.005" (0.05 to 0.13mm) end play.




Assemble grip rings with the sharp edge away from part being held in place so the ring will grip the shaft better.




B. SPRING LINK ADJUSTMENT

With the Master Control Lever in the PROJECT position, loosen the brass pivot screw and adjust the pivot Counterclockwise until the lower idler roller touches the take-up sprocket enough to cause the gap in the spring link to close 0.003" to 0.005" (0.08 to 0.13mm).




C. COUNTER ADJUSTMENT

After mounting the counter(Fast Forward Models), be sure the idler arm swings open freely when moving the control lever to the LOAD position. If the arm is sluggish, reposition the counter until the arm swings freely. Tighten the screws and check for free arm movement.



D. LOOP SETTING CABLE REQUIREMENT

Hang a claw arm (38041-G1) on the cable as shown. The top edge of the claw arm should be parallel with the bottom edge of the Master Control Lever.




E. LOOP SETTING CABLE ADJUSTMENT

Position the cable drum with the gear section located between 6 and 9 o'clock.

Align the right edge of the bottom tooth with the back edge of the bearing slot.

Hold the drum in position with a rubber band as illustrated, pull the inside cable (Short end) tight, wrap it counterclockwise, twice around the post on the Master Control Lever and secure it under the front screw and washer.




Thread the outside cable (Long end) as illustrated.

Wrap it clockwise, twice around the post on the Master Control Lever and secure it under the rear screw and washer.

Hang a claw arm (38041-G1) on the cable as shown and adjust the cable tension until the top edge of the claw arm is parallel with the bottom edge of the Master Control Lever.

Tighten the screws holding both ends of the cable to the Master Control Lever to 5.5 to 6.5 inch/pounds of torque and recheck the position of the claw arm.


Remove the rubber band from the cable drum and operate the Master Control Lever between the LOAD and PROJECT positions several times. In the LOAD position, the left edge of the bottom tooth of the cable drum gear should align with the front edge of the bearing slot. In the PROJECT position, the right edge of the bottom tooth should align with the back edge of the bearing slot. If not, readjust the cables.



LOOP SETTING GEAR AND ARBOR INSTALLATION

Lubricate the loop setting gear with a film of DC 44 grease (39470-P9).


Lubricate the clutch spring arbor with a drop of Teresso Instrument oil (39479-P8) and assemble as shown.



The loop setting gear should turn smoothly in both directions.


Move the master control lever up and down several times after assembling each part. If binding occurs, the last part assembled is probably the cause.

Continue assembling the sprocket and film stripper and check for smooth operation of the Master Control Lever.




F. REEL ARM PULLEY SERVICING

OILITE bearings in the Reel Arms require cleaning and lubricating each time preventive maintenance or overhaul is performed.




Remove and discard the reel belts.




INSTA LOAD/XL
2200 SERIES

Mark one of the flat sides of the reel arm lock with a felt marker and mark the face of the pulley to correspond with this mark so proper orientation of the roll pin hole can be maintained during reassembly.


Use the roll pin inserting and extracting tool (T-38000-N) to remove and insert the roll pin (shown being inserted).



The roll pin may be removed by using a pin punch. Support the spindle on a block of wood when knocking out the pin.



Clean the oilite bearing with a cotton swab saturated with Teresso Instrument Oil (39479-P8). DO NOT USE SOLVENTS ON OILITE BEARINGS.



Clean the pulley and shaft with crocus cloth. DO NOT USE SANDPAPER OR EMERY PAPER. If the shaft is scored, the pulley assembly must be replaced.



Insert the new spring belts from the top side of the pulley. In the case of the take-up belt, the control lever should be in the LOAD position.



G. SOUND DRUM AREA SERVICING

LOCK


→ ALL SINGER INSTA-LOAD PROJECTORS use a BSW, 7 volt exciter lamp. 200 MA 50 HRS

Lamps having a darkened envelope around the filament cause reduced sound output.


Try a new exciter lamp first if the projector has poor or low sound. (Driver Trainer Projectors are seriously affected by exciter lamps with low light output).



Thoroughly clean the sound drum area.




Remove the flywheel and the sound drum. Thoroughly clean the sound drum shaft, the inside of the sound drum, and the back edge of the sound drum.



Soak a cotton swab with Teresso Instrument Oil (39479-P8) and clean the oilite bearing in the sound drum support.

Moisten a cotton swab with Alcohol and clean the photo diode in the sound support.



Reassemble the Sound Drum and Flywheel.

With the Master Control Lever in the PROJECT position, raise the film dampener arm (Behind the sound drum) to its uppermost position. When released it should take 3 to 5 seconds to drop to its rest position.



G.1. FILM DAMPENER ARM ADJUSTMENTS

If the dampener arm doesn't drop in 3 to 5 seconds, DO NOT BEND THE DAMPENER ARM SPRING.

Remove the dampener arm roller and spring (note orientation of spring).

Remove the dampener arm.




Disassemble the Dampener Arm and wipe the dampening fluid off the arm hub and aluminum cup.

Apply 2 or 3 drops of very heavy DC 200 (200,000 Centistoke) dampening fluid (39479-P5) in an even coat on the hub and reassemble the aluminum cup to the arm.

Wipe a thin coat of dampening fluid on the post on which the arm mounts and reassemble the arm and spring to the projector.


Add more dampening fluid if the arm drops in less than 3 to 5 seconds. Remove fluid if the arm drops too slowly.



G.2. FRONT PRESSURE ROLLER ADJUSTMENTS

Connect the take-up tension gage (T-38000-S) to the sound drum front pressure roller with a small loop of film as shown.

When the gage measures 3 to 5 ounces, the roller should just start to move away from the sound drum.




Form Front Pressure Roller Spring along its entire length to increase or decrease pressure. DO NOT BEND THIS SPRING - FORM IT.



The front pressure roller must be square and parallel with the sound drum.


Make sure pressure roller rivets or pressure roller spring rivets are not loose. Tighten by squeezing with vise grips.

Twist the pressure roller spring if necessary to obtain parallelism. Recheck pressure roller lift-off tension.



H. CAM LUBRICATING PAD SERVICING

The Cam Lubricating Pad must be changed each time preventive maintenance or overhaul is performed on a projector.




Loosen the two lube pad spring retaining screws and replace pad.

New Pads are supplied with the correct amount of lubricant already on them. (16 drops of Teresso Instrument Oil #39479-P8).




J. INTERNAL MECHANISM SERVICING

The internal mechanism must be thoroughly cleaned and relubricated.



Clean Worm Gears with a clean dry cloth or a clean, dry toothbrush. DO NOT USE SOLVENTS.


Relubricate by brushing DC44 Grease (39479P9) into the teeth.



K. MOTOR PULLEY SERVICING

If the motor pulley wobbles on the shaft, replace the nylon pulley bearing.

Carefully tap out the 1/16" roll pin which secures the fan hub to the motor shaft.




Slide the fan hub, motor pulley and bearing from the motor shaft carefully noting the positioning of the fiber washer and nylon bearing. Wash all parts in alcohol or chlorothene 1+1.

Lubricate the inside and outside of the nylon bearing with FS 1290 grease (39479P4).


Lubricate the fan hub kick spring by applying Vischem 352 grease (39479P15) between the spring and the fan hub.

When reassembling, make sure that the pin on the motor pulley and the pin on the fan hub do not trap one of the tails of the spring between them. There should always be spring action between these two pins, otherwise damage may result to the projector.




L. SAFETY SHUTTER THEORY

The safety shutter is operated by a Viscous Fluid which sets up a drag between the steel hub, which is secured to and turns with the main shaft and the brass cylinder of the safety shutter.




SAFETY SHUTTER SERVICING

Replenish the DC 200 Viscous fluid (200 Centistoke, #39479-P17) each time preventive maintenance or overhaul is performed by standing the projector on its nose and applying two or three drops in the small crack between the steel hub and the sealing washer. Turn the main shaft while rocking the safety shutter back and forth to "WICK" the fluid down into the shutter.



Run the projector for several seconds to distribute the fluid inside the brass cylinder.

Repeat the procedure two or three times to completely fill the reservoir.



M. SHUTTER AND CAM OPERATION

The shutter and cam are locked together and require no timing.

The cam moves the claw arm up and down (stroke) and in and out of the film sprocket holes (protrusion).



Up-and-down movement occurs as the cam follower on the front of the claw arm follows the radial (round) surface of the cam.

In-and-out movement occurs as the cam follower Button (see arrow) on the back of the claw arm follows the axial surface (wobble plate) of the cam.

The pivot (lower right) is used to adjust stroke, and repositioning of the shutter and cam assembly on the main shaft is what determines protrusion.

Tools required for adjusting stroke and protrusion are:

- a. Protrusion Gage G10-38000 (Left)
- b. Pivot Adjusting Tool ST-5884 (Upper Left)
- c. Stroke Gage ST-5880 (second from left)
- d. .050" Allen wrench
- e. 1/16" Allen wrench
- f. 1/4" - 3/16" open-end wrench
- g. Continuity Tester






M.I. SIDE CLEARANCE ADJUSTMENT

Before attempting any adjustments, manually rotate the inching knob to make sure the Claw Arm Pins do not strike the sides of the Aperture Plate Claw Slot.

At the bottom of its travel, this Pin will be nearer to the outside edge of the Aperture Plate Slot.

To observe this condition, watch the back of the aperture plate as the Claw Arm is cycled slowly through its stroke by turning the main shaft.




To adjust, loosen the setscrew in the Claw Arm with the .050" Allen wrench and move the oilite bushing so the two distances are equal.

M.2. CLAW PIN PROTRUSION REQUIREMENT

Pin protrusion is the distance which the Claw Pins extend through the aperture plate and is one of the most critical adjustments on all Singer 16mm Projectors. If protrusion is not correct, the operation of the machine may be erratic even though all other adjustments are correct.


The end of the Claw Pin must extend .035" to .040" beyond the film rail of the aperture plate.



CLAW PIN PROTRUSION MEASUREMENT

- a Raise the Master Control Lever to PROJECT position.
- b Move the Master Control Lever down and open the lensmount just enough to insert the gate. Then raise the control lever just enough to hold the gage snugly in place.

NOTE: Do not insert the gage and then close the lensmount. The lensmount may pop open and not hold the gage properly.



- c Connect the screw on the Protrusion Gage to one side of the continuity meter. Connect the other side of the continuity meter to the chassis of the projector (connecting point must be free from paint, dirt or grease).


- d Rotate the Inching Knob clockwise and observe the Claw Arm. Stop rotating the Inching Knob when the Claw Arm Pins enter the slot in the Aperture Plate and start down. (The edge of the Shutter blade will be just below the Aperture).

NOTE: The protrusion on NEW projectors is set at .040" to .045" to allow for run in. This measurement is acceptable for NEW projectors. However, when replacing the claw arm, adjust to the .035" to .040" requirement.

- e Push the Claw Arm toward the Aperture Plate and gently push the Gage down until the bottom of the gage touches the top pin of the Claw Arm. (The ohm meter or continuity tester will show continuity).



- f Release the Claw Arm and reference the position of the red and yellow reference tapes to a point on the projector. Slide Gage down 1/2 width (1/4 width with new style gage) of either tape. The Bottom step of the gage should be opposite the top pin of the Claw Arm. (Figure A)

- g If the meter or tester shows continuity, protrusion is more than .040" and should be adjusted. If no continuity is shown, gently push gage down one width of tape. The top step of the gage should be opposite the top pin of the Claw Arm. Continuity indicates correct protrusion between .035" and .040". No continuity indicates protrusion is less than .035" and should be adjusted. (Figure B)



CLAW PIN PROTRUSION ADJUSTMENT

- a To adjust, loosen the "W" point screw and remove the outer oval point screw.
- b Position the gage with the bottom step aligned with the top pin of the Claw (Claw must be positioned as in step (d) above). Grasp the Shutter and loosen the inner oval point screw.
- c Move the shutter on the Main Drive Shaft while observing the meter or tester. When continuity is established, allow the shutter to move back to the point of just breaking continuity and tighten the inner oval point screw on the flat of the shaft. Rocking the shutter slightly while tightening this screw will insure proper alignment on the flat of the shaft.
- d Push the gage down as in step (g) above and check for continuity. If no continuity exists, repeat this entire process until no continuity exists on the lower step of the gage but continuity does exist on the upper step.
- e Tighten the "W" point screw and recheck the requirements of step (d) above. If tightening the "W" point screw results in failure to meet these requirements, repeat steps (c) and (d) until tightening of the "W" point screw no longer causes failure.
- f Tighten the "W" point screw and the inner oval point screw to 140 inch ounces of torque. Replace the outer oval point screw to 140 inch/ounces of torque. (If a torque wrench is not available, tighten the screws until the allen wrench shaft starts to twist.




N. LENSHOLDER STOP PIN THEORY

The Lensholder Stop Pin limits the distance that the bottom of the pressure shoe moves away from the Aperture Plate when the Loop Restorer resets the lower loop. This should be checked and reset if necessary each time preventive maintenance or overhaul is performed on the projector.

LENSHOLDER STOP PIN GAGE

Lay the Protrusion Gage (G10-38000) on a flat surface with the protrusion measuring steps facing up.

With a set of calipers or a depth gage, measure from both steps to the flat surface. Select the step which measures $.138 \pm .003$ " for the lensholder stop pin adjustment.



If neither step measures $.138 \pm .003$ ", build up the back side of the gage with tape until the correct thickness is obtained.

LENSHOLDER STOP PIN ADJUSTMENT


Move the Master Control Lever to LOAD and remove the lensholder cover.

Rotate the inching knob until the Claw Arm pins have been completely retracted from the Aperture Plate.

Insert the Protrusion Gage in the Aperture Plate with the measuring steps facing the lensholder stop pin and the $.138'' \pm .003''$ step directly in line with the pin.

Move the master control lever to PROJECT.

Loosen the Stop Pin Setscrew and adjust the Pin until it just touches the $.138'' \pm .003''$ step. Tighten the screw.




O. PRESSURE SHOE REQUIREMENT

Move the Master Control Lever to LOAD AND assemble the Lensholder Cover with the Pressure Shoe.

Place an Index Card below the Pressure Shoe and sight down the edge of the Pressure Shoe as the Master Control Lever is moved toward PROJECT.

The Pressure Shoe should enter the aperture plate channel without striking either side. The outside edge clearance should be $.005''$ to $.010''$.



PRESSURE SHOE ADJUSTMENT



Adjust by loosening the two socket head screws which hold the "C" carrier to the lensholder and moving the carrier to obtain the $.005''$ to $.010''$ dimension. (Loosen the screws just enough to permit carrier movement with considerable resistance. The carrier should not be too loose.)

Run the projector forward with film. Move the carrier to obtain quietest operation and steadiest picture. These two requirements will generally occur simultaneously.

Reverse project. Readjust, if necessary, for quiet, steady operation. Recheck (b) above.

Tighten the carrier.

Move the control lever up and down several times to be sure that the pressure shoe seats properly and recheck with film.



P. AUTOMATIC LOOP RESET SERVICING

Move the Master Control Lever to LOAD.

By hand, rotate loop reset gear clockwise about 90° and hold.

Push the lower spring loaded arm down and examine the raised lip on the eccentric stud.

Replace the gear if this lip is worn.

While the loop reset arm is disassembled, check the gear latch tab for burrs. If a burr is found, replace the arm.



AUTOMATIC LOOP RESET ECCENTRIC ADJUSTMENT

When the Master Control Lever is in the LOAD position, the cradle in the end of the arm link should trap the loop reset arm eccentric so the arm is neither forced up by the cradle nor able to be pushed up with the cradle in place. This would result in the release of the engagement of the gear latch tab with the raised lip on the loop reset gear eccentric, causing continuous recycling of the loop reset mechanism in the fast modes of operation.

Loosen the setscrew in the eccentric and rotate it to fit into the cradle of the master control lever without releasing the loop reset gear when the projector is in the LOAD position.




Q. DRIVE MOTOR BELT REQUIREMENT

Reinstall the motor to the projector.

Hook the take-up tension gage to the motor drive belt as shown in the illustration and pull down on the gage.

Sight along an imaginary line which touches the bottom of the motor pulley and main shaft pulley while pulling down on the tension gage.


When the top of the gage wire touches this line, the gage should read 7 to 10 ounces.



DRIVE MOTOR BELT ADJUSTMENT

Back the lock nut away from the motor plate and adjust the belt tension nut for correct tension. Turn it counterclockwise to increase belt tension and clockwise to decrease tension.

Tighten the lock nut securely against the motor plate when adjustment is completed.




R. REWIND BRAKE REQUIREMENTS

Before attempting any take-up or lift-off adjustments, check the operation of the rewind brake (on models without Fast Forward).

Move the Master Control Lever to LOAD.


Viewed from the motor side of the projector, the take-up reel arm belt should move freely in a counterclockwise direction but bind or grip in a clockwise direction. The feed and rewind arm belt should move freely in both directions.



Manually operate the rewind solenoid.

The take-up reel arm belt should move freely in both directions and the feed and rewind arm belt should bind in the counterclockwise direction but move freely in the clockwise direction.

If the above requirements are not met, make sure the brake cable is on the pulleys. If so, adjust the brake cable by loosening the clamp screw on the solenoid paddle and lengthen or shorten the cable as required.




S. TAKE-UP ADJUSTMENT


Take-up tension is adjusted with the nut directly under the bias spring.

Place an empty 400-foot reel on the take-up arm.

Thread the projector. (Film may be pulled from the front reel directly to the rear sprocket, bypassing the normal film path if desired.)



Insert the film tension gage (T-38000-S) as illustrated with the idler directly above the last roller of the film path. Hold the gage at about a 30° angle, operate the projector in FORWARD PROJECT. The gage should read 4 to 6 ounces with 25 to 40 feet of film on the take-up reel. Favor the low side of this requirement with the blue or green clutch liner.




Adjust the take-up tension adjusting nut up to increase tension and down to decrease it.

If difficulty is experienced meeting the take-up adjustment requirement, perform the lift-off adjustment and try the take-up adjustment again. If the take-up requirement is met, it is not necessary to do the lift-off adjustment.

T. LIFT-OFF THEORY AND ADJUSTMENT


The lift-off adjustment establishes the proper point of contact of the take-up clutch pulley with the take-up clutch liner. It is accomplished by adjusting the bottom two nuts on the threaded rod so the pulley exerts just the right amount of pressure on the liner. Too little pressure will result in erratic take-up, and too much pressure may break the take-up gear.



Mount an empty 400-foot reel on the take-up arm, move the master control lever to PROJECT and run the projector in FORWARD.

Turn both bottom nuts up until the 400-foot reel just stops turning. Make sure the flat plate always remains firmly trapped between these two nuts.


Mark one face of the bottom nut for reference and turn the bottom nut down three turns. Turn the top nut down until it snugs tightly against the flat plate. This establishes correct lift-off.



U. FAST FORWARD DRIVE REQUIREMENT

Place an empty 400-foot reel on the take-up arm. Connect the Take-up Film Tension Gage (T-38000-S) to this reel about 3" out from the center by means of a paper clip or other wire suitable for this purpose.

Run projector in "FAST FORWARD" mode. The gage should read 13 to 18 ounces.



FAST FORWARD DRIVE BELT ADJUSTMENT

Loosen the screw holding the Adjusting Plate and move the plate either up to decrease torque or down to increase torque. Tighten the screw.


Note: If this fails to change the torque, make sure the FAST FORWARD Solenoid is causing the FAST FORWARD clutch to engage. As a last resort, it is permissible to adjust the lift-off setting (the double nuts on the bottom of the take-up clutch threaded rod). Turn these nuts up 1/2 turn.



PROJECTION LENS

Clean and replace the projection lens.

Make sure the lens is positioned so the antitheft screw is flush with the lensholder casting. If this screw is not seated properly, the lensholder cover cannot be assembled properly and the projector will not handle film.




V. BUZZ AND SOUND OPTIC FOCUSING

a SMPTE P16-BT Buzz Track film (45191-G3) is used to adjust the lateral position of the front pressure roller with respect to the sound drum.

b SMPTE P16-SF-A 7000 Hz sound focusing film (Telex 45191-G2) or SMPTE P16-SF-B 5000 Hz sound focusing film (Telex 45191-G1) is used to adjust the focusing of the sound optic and the azimuth of the sound optic.

c These two adjustments are interdependent. If difficulty is experienced in making either of these adjustments, check the other one and adjust it as necessary.



V.1. SOUND OPTIC FOCUSING ADJUSTMENT


a Cut two strips of 7000 Hz sound focusing film about 40" long. SMPTE P16-SF-A, P/N 45191-G2).

b Splice them together to form a closed loop with the emulsion side of one strip on the outside circumference of the loop and the emulsion side of the other strip on the inside circumference of the closed loop.

c Thread this loop in the projector and adjust the Tone Control to its maximum right-hand position.

d Connect an AC Voltmeter across the speaker terminals and set the meter range switch to read 50 volts full scale minimum.


e Run the projector Forward and adjust the Volume Control for comfortable listening level. Adjust the voltmeter range scale for a reading between 1/2 scale and full scale.



INSTA LOAD/XL
2200 SERIES

Requirement : Meter readings from both sections of the loop must be within 3 db of each other.

If the meter used does not have db scales, set the Volume Control so one section of the loop produces one of the Set Value voltage readings shown in the Chart and check that the other section of the loop meets the Allowable Deviation Requirements.



If this requirement cannot be met, proceed to Step f. Otherwise, disconnect the meter and proceed with the "Buzz" adjustment.

Loop Section I Set Value	Loop Section II Allowable Deviation	
	Maximum Reading	Minimum Reading
.775 VAC	1.10 VAC	.54 VAC
2.450 VAC	3.45 VAC	1.73 VAC
7.750 VAC	10.95 VAC	5.40 VAC

Loosen the Sound Optics Setscrew and remove the Sound Optics. It may be difficult to remove due to the wedging action of the nylon plug used to lock it in place. Rotating it back and forth while pushing up on it will aid in its removal. DO NOT pry up on the bottom of the cartridge as this may damage the bottom lens. Inspect bottom element for damage.



Turn the setscrew as though tightening. This will force the nylon plug out of the hole. Be careful to prevent the plug from falling into the projector.

Remove the setscrew. Insert a NEW NYLON PLUG (38162-P1) and start the setscrew into the threads. After cleaning the top and bottom lenses of the optic, insert it in the projector and tighten the setscrew until it is held in place but can be turned and moved up and down easily. Be careful to prevent the optic from dropping onto the sound drum as this may damage the bottom lens.




Note: You may find it more convenient to replace the nylon plug and setscrew with a new NYLON Tip Setscrew (45209-P1).

Run the projector in Forward and focus the Sound Optics Cartridge by moving it up or down while rotating it back and forth until both requirements of Step (e) above are met. Tighten setscrew VERY tight when adjustments are complete.

Note 1: Use of Tool T-43680-G1 might make focusing of the Sound Optic more convenient. To use the tool, attach the ring portion to the optic and clamp the adjusting rod portion to the lamp-house platform of the main casting.


Note 2: No attempt should be made to remove the lens elements. If difficulty is encountered meeting the above requirements and the Sound Optic is suspected, replace the entire cartridge.



V.2. BUZZ ADJUSTMENT

Thread a continuous loop of "BUZZ" track film (SMPTE-P16-BT) (45191-G3) in projector and set the Tone Control to its maximum right-hand position. Set the Volume Control for comfortable listening.

Run the projector Forward and adjust the BUZZ adjusting nut until no sound is heard or until the high and low frequencies are heard with equal volume. (There is a Buzz Track included as part of the Jiffy Test Film SMPTE-P16-PP).



W. FINAL PERFORMANCE TEST

Place a Jiffy Test Film in the projector and check for proper operation.

Replace the covers and clean.

INSTA LOAD/XL
2200 SERIES




Figure 3-46. PREVENTIVE MAINTENANCE LUBRICATION POINT DIAGRAM

INSTA LOAD/XL
2200 SERIES




Figure 3-47. OVERHAUL MAINTENANCE LUBRICATION POINT DIAGRAM

INSTA LOAD/XL
2200 SERIES

2. OPERATION CHECK

It is recommended an old film be used for the initial part of this check. This will prevent damage to a valuable test film in case the projector is malfunctioning to the extent that it damages film. An SMPTE jiffy test film Mo. P16-PP should be used for the latter portion of this check.

1. Connect power cord to AC receptacle supplying correct line voltage and frequency. Swing reel arms up until they lock.
2. Set Master Control Lever to PROJECT position.
3. Press FORWARD button. Check that sprockets and reels turn properly, that screen is illuminated evenly and blower is operating. Listen for unusual noises.
4. Press Still button (if projector has this feature). Illumination should decrease and motion of sprockets and reel pulleys should stop. (Screen may be partially or totally dark. If so, rotate manual advance knob slightly to move shutter blade away from aperture.)
5. Press REVERSE button. Check that sprockets and reels turn properly.
6. Press STOP button. Projector should stop.
7. Move Master Control Lever to LOAD/FAST MODE.
8. Press FAST FORWARD button (on projectors with this option). Check that sprockets and take-up reel operate and the fast mode interlock light comes on after a slight delay.
9. Press STOP button. Projector should stop and fast mode interlock light (on FAST FORWARD models) should remain on for three to five seconds.
10. Press REVERSE button. Check that sprockets and supply reel operate in the fast reverse mode. On fast forward models, interlock light will light.
11. Press STOP button. Projector should stop. On Fast Forward models, the interlock light should remain on for three to five seconds.
12. Thread an old film into the projector and move the Master Control Lever to the PROJECT position.
13. Check for proper threading by manually rotating the manual advance knob and checking the film movement through the projector.
14. Press the FORWARD button and observe that film moves smoothly through the projector and is gathered on the take-up reel. Set volume and tone controls for comfortable listening.
15. Check for proper film handling in the film gate by observing smooth quiet operation in this area.
16. Check picture for focus, double image or ghosting.
17. Adjust framing knob maximum clockwise and then maximum counterclockwise. Observe that the frame line moves an equal distance into the top and bottom of the projected image. Check for picture jump, side shake or weave, and mechanical noise at both extremities of framing.
18. Readjust framing knob to eliminate frame line from projected image.
19. Press REVERSE button and observe that the film moves smoothly and quietly through the projector and is gathered on the supply reel.

Note: At this point, the balance of the old film may be run through the projector and rewound or rewound immediately at the operator's discretion.
20. Press the STOP button. Move the Master Control Lever to the LOAD position and thread a jiffy test film (SMPTE P16-PP) onto the projector.
21. Move the Master Control Lever to the PROJECT position.
22. Check for proper threading by manually rotating the manual advance knob and checking the film movement through the projector.
23. Press the FORWARD button and observe that film moves smoothly through the projector and is gathered on the take-up reel.
24. Move the tone control and listen for a change in pitch.
25. Advance the volume control momentarily to a loud listening level. Check for case rattle or buzz.
26. Follow directions on jiffy test film.
27. Rewind jiffy test film when test is complete.
28. Check Elevation.
29. Check Loop Restorer.

INSTA LOAD/XL
2200 SERIES

SECTION III DISASSEMBLY and REASSEMBLY ADJUSTMENTS

PARA.	TITLE	PAGE
	SECTION III SERVICE PROCEDURES	3-ii
A.	REMOVAL OF LENSHOLDER	3-1
B.	REASSEMBLY OF LENS HOLDER	3-1
C.	REMOVAL OF FRONT CLUTCHES	3-2
D.	REASSEMBLY OF FRONT CLUTCHES	3-2
E.	REMOVAL OF TAKE-UP CLUTCH	3-4
	Installation of Blue or Green Take-Up Clutch Liner	3-5
	Take-Up Clutch Arm Servicing	3-5
F.	TAKE-UP CLUTCH REASSEMBLY	3-6
G.	REMOVAL OF TAKE-UP SPROCKET and GEAR	3-6
H.	REASSEMBLY OF TAKE-UP GEAR and SPROCKET	3-7
J.	SPRING LOADING TIP	3-8
K.	REMOVAL OF AUTOMATIC LOOP RESET ASSEMBLY	3-8
L.	REASSEMBLY OF AUTOMATIC LOOP RESET ASSEMBLY	3-9
M.	REMOVAL OF MAIN SHAFT	3-9
N.	REASSEMBLY OF MAIN SHAFT	3-10
P.	REMOVAL OF CLAW ARM	3-11
Q.	REASSEMBLY OF CLAW ARM	3-12
	Claw Arm Adjustment	3-12
	Claw Arm Adjustment (Model 2280)	3-15
R.	FRAMING ADJUSTMENT	3-18
S.	REPLACING PHOTO DIODE CHIP IN SOUND DRUM	3-18
T.	SOUND DRUM ADJUSTMENTS	3-19
U.	FEED SPROCKET CLUTCH	3-20
V.	FAST FORWARD and REWIND CLUTCHES	3-21
W.	SWITCH ADJUSTMENTS	3-22
X.	FILM COUNTER	3-23

SECTION III

SERVICE PROCEDURES

A. GENERAL

This section provides repair, reassembly, adjustments, and preventive maintenance instructions.


B. TOOLS AND EQUIPMENT

Servicing Telex INSTA-LOAD 2200 SERIES Projectors will be facilitated by tools and equipment described in this section. Some tools are standard tools. Special tools have been assigned tool numbers and are available from Telex Communications, Inc.


1. Special Tools

Special tools required in the repair of the projector are listed below. For a description of these tools, refer to the applicable illustration.

ST-5884	Claw Arm Adjusting Tool (Pg. 3-ii)
G10-38000	Claw Arm Protrusion Gage (Pg. 3-iii)
T-38000-N	Rollpin - Insert and Extracting Tool (Pg. 3-iii)
T-38000-S	Take-up Film Tension Gage (Pg. 3-iii)
ST-5880	Stroke Setting Gage (Pg. 3-iii)
T-38001-G	Sound Drum Locating Plug (Pg. 3-iv)
SS-305	Retainer Feeler Gage (Pg. 3-iv)
T-43411-G1A	Solenoid Holding Clamp (Pg. 3-iv)
SS-327	Solenoid Stroke Gage (Pg. 3-iv)
T-43680-G1G	Sound Optics Adjusting Tool (Pg. 3-iv)



FRONT VIEW



REAR VIEW

Used to adjust claw arm side clearance and pull-down stroke.


**CLAW ARM ADJUSTING TOOL
No. ST 5884**

2. Commercial Tools

The commercial tools used in the repair of the projector are listed in the table below. These tools are available from Telex Communications, Inc.



EDUCATION SYSTEMS NO.	DESCRIPTION	USE
SS-307	Waldes Retaining Ring Applicator M-C 012	To install retaining rings.
T-38000-U	Waldes Tru-Arc No. 1520 Applicator	To remove and install small retaining rings.
T-38000-V	Waldes Tru-Arc No. 1540 Applicator	To remove and install large retaining rings.
T-38000-W	Claw Cam Wrench (Pair)	Claw arm eccentric pivot nuts.
T-38000-X	Waldes Tru-Arc No. CR-0310	To remove and install "C" rings.

INSTA LOAD/XL
2200 SERIES



Used to set claw pin protrusion electrically.


CLAW ARM PROTRUSION GAGE,
No. G10-38000



Used to measure forward take-up tension, belt tension and fast forward take-up tension. The scale reading is twice the actual film tension.


TAKE-UP FILM TENSION GAGE
No. T-38000-S

DETAIL I




(REPLACEMENT PIN # T-38000-NI)

MAT'L: 5/32 DRILL ROD
BREAK ALL EDGES 0.005"




ROLLPIN-INSERT AND EXTRACTING
TOOL, No. T-38000-N




This gage is a piece of stainless steel with perforations simulating double-perforated 16mm motion picture film. This gage is used to adjust the stroke of the projector. The projector functions as an optical comparator when this tool is used.

STROKE SETTING GAGE,
No. ST-5880




Used to locate the lateral and rotational position of the sound drum.

SOUND DRUM LOCATING PLUG,
No. T-38001-G




MATERIAL: .025 PHOS. BRONZE
OR SPE. BR.

RETAINER FEELER GAGE,
No. SS-305




Used to hold solenoid while setting stroke.

SOLENOID HOLDING CLAMP
No. T-43411-G1-A



Used to set solenoid stroke.

SOLENOID STROKE GAGE
No. SS-327



Used to set Sound Optics.

SOUND OPTICS ADJUSTING TOOL
No. T-43680-G1-G

C. MATERIALS

Materials required are listed in the following table. The stock numbers of materials available from Telex Communications are given. If there is no number, the product will not be supplied by Telex Communications. Only those test films showing our stock numbers can be procured, others must be ordered by PH number from SMPTE.

LUBRICANTS AND CEMENTS

STOCK NO.	STOCK PACKAGE	DESCRIPTION
39479P5	1/2 oz.	DC-200 Silicone Fluid; 200,000 centistroke viscosity (Dow-Corning Corp., Midland, Mich.)
39479P13	1/2 oz.	D200 Silicone Damping Fluid, 200 centistroke viscosity (Dow-Corning Corp., Midland, Mich.)
39479P7	1/2 oz.	009 Lubricant (Keystone Carbon Co., St. Mary's, Pa.)
39479P8	2 oz.	Instrument Oil-Teresso Oil, No. N-75 (Humble Oil & Refining Co., New York, N. Y. N.)
39479P9	2 oz.	DC-44 Light Consistency Silicone Grease (Dow-Corning Corp., Midland, Mich.)
39479P15	2 oz.	Vischem No. 352 (Ultra Chem Inc., Wilmington, Del.)
39479P4	1/2 oz.	FS-1290 Fluorosilicone Grease (Dow-Corning Corp., Midland, Mich.)
39479P14	2 oz.	Versalube - G-322L (General Electric)
39490P1	3 oz.	7526 Blue Glyptal (General Electric Co., Schenectady, N. Y.) N-75
39479P16	4 oz.	Extreme Pressure Lube No. 3
39490P2	3 oz.	1276 Clear Glyptal (General Electric Co., Schenectady, N. Y.)
39479-P17	1/2 oz.	DC 350 Dampening Fluid (Used on Insta Load safety shutter P/N 42994-G2 (Replaces 39479-P13, DC 200-200CS)
- - - - -	- - - - -	8101-S Silicone Compound (General Cement Electronic Co., Rockford, Ill.)
- - - - -	- - - - -	No. 59 Loctite, Screw Lock (Loctite Corp., Newington, Conn.)
- - - - -	3 oz.	EC-880 (Minnesota Mining & Manufacturing Co., St. Paul, Minn.)
45191-G3	12 ft.	PH22. 57 Buzz Track Film (P16BT)
- - - - -	- - - - -	PH22. 43 3000 cps Film
45191-G7	- - - - -	PH22. 45 400 Cycle Test Film
45191-G2	12 ft.	PH22. 42 7000 cps Film (P16SFA)
45191-G6	12 ft.	16. 3 mm Registration Test Film (Reg. 16)
39490P4	8 oz.	Glyptal Thinner 1511M
- - - - -	- - - - -	Chlorothene (Dow Chemical Co., Midland, Mich.)
39490P12	4 oz.	Tan Paint
39490P13	4 oz.	Brown Paint

SECTION III DISASSEMBLY AND REASSEMBLY PROCEDURES

Where disassembly and reassembly seems straightforward and self explanatory, no procedures are given in this service manual. However, where certain steps may not be obvious or where a definite order of steps should be followed, we would like to pass on a few tips or tricks we've learned to make your job a little easier and cut repair time.

Disassembly of the projector and subassemblies thereof should only be performed to the extent necessary to accomplish repair.

Note: Internal electrical connections may be "LIVE" when covers are removed. USE CAUTION.

Always clean parts thoroughly before any lubrication or reassembly is attempted. See cleaning suggestions under Preventive Maintenance, Section II.

A. Removal of Lensholder

1. Remove the Film Stripper (8), the "C" Ring (11) and the Front Sprocket (10). (Figure 3-1).
2. Loosen Screw (63) enough to allow the Lobster Claw (62) to slip off the Guide Arm Roller (47).

3. Move the Master Control Lever to the LOAD position and remove Screw (44). (This Screw is accessible from the back of the projector below the front Worm Gear and to the right of the motor start capacitor.)
4. Slide the Lensholder (43) off its mounting rod taking care not to lose the Spring (45) and the Guide Arm Roller (47).

B. Reassembly of Lensholder to Projector

1. Raise the Master Control Lever to the PROJECT position and make sure the Lensholder Link is straight and resting on top of the Lensholder Rod Boss of the main casting.
2. Slide the Spring (45) and the Lensholder onto the Lensholder Rod and push the Lensholder in until the screw hole is visible toward the back edge of the access slot for Screw (44).
3. Slowly move the Master Control Lever toward LOAD while observing the Lensholder Link.
4. When the hole in the Link just starts to become visible, insert the end of Screw (44) into the hole. (It will be very helpful to hold the screw with a Holding type screwdriver).




Figure 3-1. REMOVAL AND REASSEMBLY OF LENSHOLDER

INSTA LOAD/XL
2200 SERIES

5. Continue to move the Master Control Lever slowly toward LOAD until the hole in the Link lines up with the hole in the Lensholder and start the Screw (44) into the hole in the Lensholder.
6. While tightening the Screw (44) make sure the over-size hole in the link slips over the shoulder on the Screw (44) so the Lensholder does not bind during operation. Tighten the Screw (44) securely.
7. Replace the Front Sprocket (10) and the Film Stripper (8).
8. Adjust Setscrew (46) to provide .002" to .010" clearance between the Setscrew and the main housing throughout the total Lensholder travel.

C. Removal of Front Clutches

1. Remove the Film Stripper (8), the "C" Ring (11) and the Front Sprocket (10).
2. Remove the Spring (14) being very careful not to allow the Pin (16) to slip out of the Arbor (15) and drop into the base of the projector.
3. Remove the Pin (16), Arbor (15) and Gear (17).
4. Remove the "C" Ring (20), Screws (25) and (26) and the reel arm Belt Guide (24).
5. Remove the three Screws (4) which hold the Solenoid Package in place and lay the Solenoid Package (3) to one side out of the way. (Be careful not to allow the Rewind and Fast Forward Clutch Actuator Caps (6) and (7) to drop off their shafts until you have noted which one goes where - THEY ARE DIFFERENT.)
6. Remove the Front Reel Arm Belt.
7. Move the Master Control Lever to the PROJECT position.
8. Remove "E" Rings (28) and (33) and start sliding the Rewind Clutch (27) and the Fast Forward Clutch (32) off their shafts.
9. While sliding the Rewind and Fast Forward Clutches off their shafts, push in on the shaft of the Front Sprocket Clutch (37). The Washers (21) may lodge in the "C" Ring slot of the shaft making it difficult to push the shaft out of the bearing. Move the Washers (21) around while pushing in on the shaft until the shaft pushes in easily.
10. While pushing in on the shaft of the Front Sprocket Clutch and pulling out on the Rewind and Fast Forward Clutches, a point will be reached where the Fast Forward Drive Belt will prevent further movement of these clutches. Reach in and push the drive belt over the flange of the Fast Forward Clutch Pulley and draw the Rewind and Fast Forward Clutches and the Front Sprocket Clutch out of the projector.
11. Be careful not to lose Washers (31), (36), (38) and (39).
12. Be careful not to allow the Fast Forward Drive Belt to touch the Fast Forward Clutch Shaft and pick up lubricant on its driving surface.

D. Reassembly of Front Clutches to Projector

1. Clean the front sprocket clutch Main Casting Oilite Bearing with a cotton swab moistened with Teresso Instrument Oil (39479-P8).
2. Lubricate the gear teeth of the Front Sprocket Clutch and the Rewind and Fast Forward Clutches with a light coat of DC 44 grease (39479-P9).
3. Lubricate the rewind and fast forward clutch Shafts with a thin film of Extreme Pressure Lube #3 (39479-P16) and assemble Washers (31) and (36).
4. Assemble Washers (38) and (39) to the shaft of the Front Sprocket Clutch (37) and start the shaft into the Main Casting Bearing.
5. Inspect the needle bearings in the pulleys of the Rewind and Fast Forward Clutches to make sure all are in place and none are missing.
6. Engage the gear teeth of the Rewind and Fast Forward Clutches with the gear teeth of the clutched gear on the Front Sprocket Clutch and align the Rewind and Fast Forward Clutches with their shafts.
7. Push all three clutches toward the main casting simultaneously until the Rewind and Fast Forward Clutches have started onto their shafts.
8. Continue pushing the clutches toward the main casting until the fast forward Drive Belt can be seated on the Fast Forward Clutch Pulley. Seat the belt and push the three clutches all the way to the main casting.
9. Use the correct number of Washers (30) and (35) to obtain an end play of .001" to .005" on clutches (27) and (32) when Washers (29) and (34) and "E" Rings (28) and (33) are assembled.
10. Assemble the correct number of Washers (21) to obtain an end play of .001" to .005" on clutch (37) when "C" Ring (20) is assembled.
11. Apply a light coat of DC 44 grease (39479-P9) to gear (17) and assemble the gear to the shaft of the Front Sprocket Clutch (37).
12. Assemble Arbor (15) to the shaft and pin it in place with Pin (16).

INSTA LOAD/XL
2200 SERIES




Figure 3-2. REMOVAL AND REASSEMBLY OF FRONT CLUTCHES

13. Apply a light film of Teresso Instrument Oil (39479-P8) to the surface of Arbor (15) and assemble the Clutch Spring (14) on the Arbor. Make sure the tails of the Spring turn away from the raised sector of Gear (17). The Master Control Lever should move up and down easily with no binding after the Spring (14) is installed.
14. Assemble the Front Sprocket (10) using the correct number of Washer (13) to obtain an end play of .003" to .007" for the Sprocket. (In order to correctly check the end play of the Sprocket, the front sprocket clutch Shaft must be prevented from moving since it has its own end play of .001" to .005".)
15. Assemble the Film Stripper (8).
16. Apply a thin film of Extreme Pressure Lube #3 (39479-P16) to the tail of the clutch Springs in the Rewind and Fast Forward Clutches.
17. Assemble the rewind and fast forward clutch Actuator Caps (6) and (7) such that the ramps on the Caps engage the tails on the clutch Springs to make the springs wrap tighter around their arbors when the Actuator Caps are pushed in.
18. Hold the Actuator Caps (6) and (7) in place and assemble the Solenoid Package (3) with three Screws (4) making sure to insert the interlock link wire into the slot in the bottom of the Interlock Solenoid Paddle.

E. Removal of Take-Up Clutch

1. Remove the motor and motor mounting plate to expose the take-up clutch for servicing.
2. In its normal position, the roll pin which holds the upper end of the clutch arm to the reel arm shaft is difficult to remove.



Figure 3-3. TAKE-UP CLUTCH

3. Remove the reel arm belt and place a block of wood under the arm as shown to hold it in a vertical position.




Figure 3-4. REEL ARM BLOCKED

4. Drive the roll pin out with a $3/32$ " (2.5mm) pin punch.
5. Remove the upper end of the clutch arm from the reel shaft. Remove the reel arm. Clean the shaft and casting hole and relubricate with G. E. Versilube G-322L. (39479-P14)




Figure 3-5. ROLL PIN IN POSITION

6. Pull the clutch hub (pulley) out of the take-up gear and push down on it to compress the bias spring and allow the hook of the rod to rise up in the slot.




Figure 3-6. PUSH DOWN ON BIAS SPRING

7. As soon as the hook clears the slot, the clutch arm can be swung out and lifted up off the rod.




Figure 3-7. SWING CLUTCH ARM OUT

8. Clean the main shaft worm gear and the take-up gear with a clean, dry cloth or toothbrush. (DO NOT USE SOLVENTS ON THESE GEARS AS THEY WILL CRAZE OR CRACK).

9. Grasp the take-up gear and attempt to move it up and down. If noticeable movement is detected, the rear main casting bearing is worn and must be replaced. Remove the rear sprocket and take-up gear, press the old bearing out and a new bearing in and reassemble the sprocket and take-up gear.




Figure 3-8. CHECK and CLEAN GEARS and BEARING

10. Lubricate the worm gear and take-up gear with DC 44 grease (39479-P9) applied with a brush onto the teeth.

Installation of Blue or GREEN

Take-Up Clutch Liner

1. Butt the two ends of the liner against the key inside the take-up gear.

2. Form a slight belly in the liner opposite the key and push the liner into the take-up gear.

3. Push out on the belly formed in step 2 and the liner will snap into correct position inside the gear.

Note: The liner may appear to be too long. However, it is not. DO NOT CUT THE LINER TO MAKE IT SHORTER.




Figure 3-9. INSTALLATION OF CLUTCH LINER

Take-Up Clutch Arm Servicing

1. On projectors without the FAST FORWARD option, it is necessary to disassemble and thoroughly clean the take-up pulley and brake spring.

2. Use a cotton swab saturated with Teresso Instrument Oil (39479-P8) to clean the pulley oilite bearing. DO NOT IMMERSE THE BEARING IN SOLVENT.

3. Replace the brake spring and brake spring hub if deformed or scored.

4. Lubricate the brake spring hub with four small drops of Teresso Instrument Oil.




Figure 3-10. CLEAN and SERVICE CLUTCH ARM

F. Take- Up Clutch Reassembly

1. Reassemble the take-up clutch and assemble it to the projector.
2. Press a new roll pin in place making sure that it extends far enough to contact the roll pin on the take-up arm.




Figure 3-11. INSTALL ROLL PIN




Figure 3-12 REMOVAL AND REASSEMBLY OF TAKE-UP SPROCKET

G. Removal of Take-Up Sprocket and Gear

1. Remove the Take-Up Clutch.
2. Remove the Grip Ring (6) and manually rotate the take-up Sprocket (10) clockwise slightly to move the sprocket Pin away from the stop (7). (Figure 3-12)
3. Grasp the Stop (7) with a pair of pliers and pull it straight out.
4. Slowly release your grip on the Sprocket (10) and allow the Spring (9) to unwind.
5. Remove the Spacer (5), Outside Washer (8), Spring (9) and Inside Washer (8). (The two washers (8) are usually removed easily with a magnet.)
6. Remove Grip Ring (11), Washer (12) and Sprocket (10).
7. Slide the Take-Up Gear out of the main casting bearing (Figure 3-13).

H. Reassembly of Take-Up Gear and Sprocket

1. Clean the main casting Oilite Bearing with a cotton swab moistened with Terreso Instrument Oil (39479-P8).
2. Lubricate the teeth of the Take-Up Gear with a light coat of DC-44 grease and push the shaft of the gear through the main casting Oilite Bearing.
3. Assemble the sprocket (10) and the correct number of Washers (12) to allow for .003 to .007" end play
4. Install Inside Washer (8) and Spring (9). (The Spring (9) should be installed so turning the Sprocket (10) clockwise will tighten the Spring.)
5. Install Outside Washer (8) after lubricating the surface of the Spring (9) with Terreso Instrument Oil (39479-P8).




Figure 3-13. REMOVAL AND REASSEMBLY OF TAKE-UP GEAR

6. Wind the Sprocket (10) clockwise until the Spring (9) is fully wound. Then allow the Sprocket to unwind one full turn. (Use the pin in the Sprocket as your point of reference.)
7. Note the position of the slot in the end of the shaft with relation to the pin in the Sprocket. This determines which way the Stop (7) will be installed to stop the sprocket rotation as soon as possible during its next rotation.
8. Release the sprocket and allow the spring to unwind completely.
9. Install the Stop (7) in the position determined in Step 7 above but allow the end of the Stop (7) to be lifted up enough to allow the Sprocket Pin to rotate under it when the Spring (9) is wound.
10. Wind the Sprocket (10) until the Spring (9) is completely wound and then allow the Sprocket to unwind just enough that the Sprocket Pin passes under the Stop (7) once. Push the Stop down all the way and allow the Sprocket to unwind until the Pin comes to rest against the Stop.




Figure 3-14. TAKE-UP SPROCKET LOADING

J. Spring Loading Tip

1. An easy way to load the Spring is to use the projector drive motor, running in REVERSE.
2. Assemble the spring to the projector as described above.
3. While holding both the Spring (9) and the Sprocket (10), push the REVERSE button and allow the turning of the shaft to wind the Spring.
4. When the Spring is small enough, it can be pushed into the Sprocket. The same method may be used to load the Spring after the Stop (7) has been installed.




Figure 3-15. WINDING TAKE-UP SPROCKET SPRING




Figure 3-16. AUTOMATIC LOOP RESET REMOVAL AND REASSEMBLY

K. Removal of Automatic Loop Reset Assembly

1. Remove the venturi plate (1).
2. Remove the sound drum Flywheel (2).
3. With a long, flat-blade screwdriver, reach in behind the blower venturi plate and remove the "E" Ring (3).
4. Slide the Arm Complete (4) out of its mounting hole in the main casting.
5. Loosen the Set Screws (5), remove Belt loop setter (6), the Pulley (7) and slide the Pinion (8) out of the bearing of the Pivot (9).
6. Remove the "E" Ring (10), the Gear (11) and the Kick Spring (12).

L. Reassembly of Automatic Loop Reset Assembly Ref. Figure 3-16

1. Clean the Oilite Bearing in the Pivot (9) with a cotton swab moistened with Teresso Instrument Oil (39479-P8).
2. Assemble the Kick Spring (12) immediately next to the loop reset gear mounting shaft as shown.
3. Insert a dental pick through the small hole next to the hub of the Loop Reset Gear (11) and push the Kick Spring (12) out of the way so the gear can be pushed onto its shaft. Secure the gear with the "E" Ring (10) (251-7-1).
4. Slide the Pinion (8) into the oilite bearing of the Pivot (9) and assemble the Pulley (7) allowing for .001" to .007" end play. Tighten Set Screws (5).
5. Slide the Arm Complete (4) into its mounting hole in the main casting and secure it in place with the "E" Ring (3). (A set of surgical hemostats are very helpful for holding this "E" Ring during installation.)
6. Replace the sound drum Flywheel (2).
7. Move the Master Control Lever to the LOAD position and observe that the cradle in the end of the arm link traps the Loop Reset Arm Eccentric so the Reset Arm is neither forced up by the cradle nor able to be pushed up with the cradle in place (Figure 3-18).
8. Loosen the Set Screw in the Eccentric and rotate it to fit into the cradle of the Master Control Lever without releasing the Loop Reset Gear with the Master Control Lever in the LOAD position.




Figure 3-17. KICK SPRING ORIENTATION



Figure 3-18. LOOP RESET ARM ECCENTRIC ORIENTATION

M. Removal of Main Shaft Ref. Figure 3-19

1. Unhook the top of the Claw Arm Spring from the Framing Arm and make sure all tension is off the Claw Arm before proceeding with these instructions. Throughout this procedure, be extremely careful of the Claw Arm Pins (Figure 3-20).
2. Loosen both Set Screws (14) in the Pulley (13) so the Pulley will rotate freely on the Main Shaft. (Figure 3-19)
3. Loosen both Set Screws (19) in the Collar (18) so the Collar will rotate freely on the Main Shaft (34).
4. Loosen Set Screw (23) in the pinion (22) so the Pinion will rotate freely on the main shaft.
5. Remove the oval point Jam Screw (27) and loosen the remaining two Set Screws in the Shutter and Cam Assembly (26) so the Cam Assembly will rotate freely on the Main Shaft.
6. Loosen both Set Screws (31) in the Collar (30) so the Collar will rotate freely on the Main Shaft.
7. Loosen Set Screw (25) in the Safety Shutter (24) so the collar of the Safety Shutter rotates freely on the Main Shaft. Unhook the Link (2) from the Safety Shutter and allow the Spring (1) to pull the Link against the Pin on the Bracket Assembly (3). (Disregard for projectors having no Safety Shutter.)

INSTA LOAD/XL
2200 SERIES

NOTE: Items 9 & 10 reversed
on all projectors except
2120L & 2151




Figure 3-19. REMOVAL AND REASSEMBLY OF MAIN SHAFT

8. Slide the Shutter and Cam Assembly (26) along the main shaft toward the rear of the projector as far as it will go.
 9. Pull the Inching Knob (9) off the front of the main shaft and push the main shaft toward the rear of the projector as far as it will go.
 10. Tuck a cleaning cloth under the main shaft bearings. Remove "C" Ring (29) located between the Shutter and Cam Assembly (26) and the Front Bearing (28).
 11. Remove "C" Ring (16).
 12. Drive Pin (21) completely out of Gear (20).
 13. Remove the cam Lubricating Pad.
 14. Put the Inching Knob (9) back on the front of the main shaft and pull the main shaft toward the front of the projector, removing the Pulley (13) and other parts in order until the Shutter and Cam Assembly (26) can be removed.
- N. Reassembly of Main Shaft**
1. Assemble the parts to the main shaft in reverse order from which they were removed.
 2. Apply a thin coat of DC 44 grease (39479-P9) to the outside circumference of main shaft Bearings (15) and (28).
 3. Install "C" Rings (16) and (29) with Waldes retaining ring applicator CR-0310.
 4. Align the Set Screws (31) in Collar (30) with their corresponding recesses in the main shaft and start tightening them. Be sure the points of the screws seat properly in the recesses. Otherwise, the main shaft will be burred and will not be positioned properly in the projector. It is best to tighten each one a little bit at a time and alternately with the other one until they cannot be tightened further. The main shaft should visibly move forward during the tightening process. Manually pushing the main shaft forward while starting to tighten these screws will help insure they are seated properly.
 5. Tighten Set Screws (19) in Collar (18) observing the proper alignment and seating of the Set Screw points as noted in Step 4. The main shaft will not move forward when these screws are tightened.
 6. Use a new Roll Pin (21) (P/N 191-N6-9) when re-assembling Gear (20) to the main shaft.
 7. Position the Pinion (22) .146" to .156" (diameter of a 5/32" drill bit) from the Drive Gear (20) and tighten Screw (23) on the flat of the main shaft.

INSTA LOAD/XL
2200 SERIES

8. Install a new Cam Lubricating Pad (P/N 39002 G3).
9. Rotate the Main Shaft (34) until the flat on the shaft just behind the Front Bearing (28) is at about 2 o'clock (See Shutter and Shaft Alignment insert on Figure 3-19). Rotate the Shutter and Cam Assembly (26) until the Setscrew (#1 in insert) lines up with the flat on the Shaft (34). Gently push the Shutter and Cam Assembly forward while pushing down on the Claw Arm until the cam follower on the Claw Arm slips under the the Cam. Tighten the Setscrew (#1 in insert) on the flat of the Shaft (34). Make sure the Claw Arm is not hitting the Aperture Plate.

Note: Be very careful not to damage the Claw Arm pins.

10. Hook the Claw Arm Spring on the Framing Arm, being very careful that the Cam Follower on the Claw Arm contacts the radial surface of the Cam.

Note: Be very careful not to damage the Claw Arm pins.

11. Perform all Claw Arm adjustments - Pin protrusion, Side clearance, Pull-down stroke and Framing.
12. Align the main shaft Pulley (13) with the motor pulley for proper drive belt tracking.
13. Lubricate the Drive Gears (20) and (32) with a thin coat of DC 44 grease (39479-P9).
14. Lubricate the Safety Shutter (24) with DC 200 Dampening Fluid (39479-P13).
15. Lubricate the Pinion (22) with a light coat of DC 44 (39479-P9).




Figure 3-20. REMOVAL AND REASSEMBLY OF CLAW ARM

P. Removal of Claw Arm

Note: Extreme care should be exercised during this procedure to insure that the pins on the Claw Arm are not allowed to hit the aperture plate or any other part of the projector, causing damage to them.

1. Unhook the top of the Claw Arm Spring (15) from the Framing Arm (20) and make sure all tension is off the Claw Arm (13) before proceeding with these instructions.
2. Remove the oval point Jam Screw (#3 in the Shutter and Shaft Alignment insert on Figure 3-20) and loosen the remaining two Setscrews (#1 and #2 in the insert) and move the Shutter and Cam

Assembly back on the main shaft to make clearance for removal of the Claw Arm (13).

3. Remove two Nuts (9) and Washers (10) and (11).
4. Loosen the two Setscrews (14) and (19) and remove the Bushing (8), the Washer (17) and the Pivot (18).

Note: Wipe the Pivot (17) and the Bushing (18) with a Clean, dry rag. DO NOT clean these two parts with solvent.

5. Grasp the Claw Arm (13) and pull toward you being careful not to lose the Spring (15) or Pin (12) or damage the Claw Arm Pins.
6. Unhook the Spring (15) and remove the Pin (12).

Q. Reassembly of Claw Arm to Projector

Note: Extreme care should be exercised during this procedure to insure that the pins on the Claw Arm are not allowed to hit the aperture plate or any other part of the projector, causing damage to them.

1. Apply DC 44 grease (39479-P9) to the Pin (12) and stick the Pin in place on the Claw Arm (13) making sure the notch lines up with the hole in the Claw Arm (13).
2. Apply DC 44 grease to Rod (1) threads.
3. Hook Spring (15) onto the Claw Arm (13) and insert the Claw Arm (13) into the projector between the Framing Arm (20) and the Shutter and Cam Assembly.
4. Lubricate both sides of Washer (17) with FS-1290 lubricant (39479-P4).
5. Assemble Pivot (18), Washer (17), Claw Arm (13), Bushing (8), Washers (11) and (10) and Nuts (9).
6. Tighten Nuts (9) for .001" end play and coat Nuts with Blue Glyptal (39490-P1). The outside Nut is a jam nut to prevent the inside nut from turning off the Pivot shaft.
7. Rotate the Pivot (18) so the Eccentric Pin is between 6 and 7 o'clock when viewed from the front of the projector. Tighten the Pivot Setscrew (19).
8. Rotate the Bushing (8) so its circumference lines up with the circumference of the Pivot (18) and the groove in its side is slightly below the groove in the side of the Pivot (18). Tighten the Claw Arm Setscrew (14).
9. Gently push the Shutter and Cam Assembly forward while pushing down on the Claw Arm (13) making sure the cam follower on the Claw Arm slides under the Cam. Tighten the Setscrew (#1 in the Shutter and Shaft Alignment insert of Figure 3-20) on the flat of the main drive shaft. (See Step 9 under Reassembly of Main Shaft.) Make sure the Claw Arm (13) is not hitting the aperture plate.
10. Hook the top of the Claw Arm Spring (15) on the Framing Arm (20) being very careful that the cam follower on the Claw Arm contacts the radial surface of the Cam.

Note: Be very careful not to damage the Claw Arm pins.

11. Make sure Pin (12) is trapped in place by Spring (15).
12. Perform all Claw Arm Adjustments - Side Clearance, Pull-down Stroke, Framing and Pin Protrusion.

Claw Arm Adjustments Side Clearance Pull-down Stroke

Note: These two adjustments are interdependent and must be adjusted at the same time. If either one is adjusted, the other must be checked and adjusted as necessary until requirements for both can be met.

A good starting position for the Pivot (18) (Figure 3-21) places its eccentric pin at about 7 o'clock when viewed from the front of the projector. (See Figure 3-25) The notch in Bushing (8) should be slightly below the notch in Pivot (18) so an imaginary line drawn across the top of the Bushing notch aligns with the bottom of the Pivot notch.




Figure 3-21. CLAW ARM ADJUSTMENTS

Before attempting any adjustments, manually rotate the inching knob to make sure the Claw Arm pins do not strike the sides of the Aperture Plate Claw Slot. At the top of the Claw Arm Stroke, the Top Claw Arm Pin will be nearer the inside edge of the Aperture Plate Slot (Figure 3-22). At the bottom of its travel, this Pin will be nearer the outside edge of the Aperture Plate Slot. Loosen Screw (14) and adjust Bushing (8) (Figure 3-21) so these two distances are equal. (Removing the Lamphouse Cover and viewing the Pins from behind the Aperture Plate aids in this adjustment.)

INSTA LOAD/XL
2200 SERIES

1. Thread an old film in the projector (do not use a good film for this adjustment) and adjust the Framing Knob to eliminate any frame lines at the top or bottom of the projected image with the projector running in FORWARD. If excessive noise results when the Framing Knob is moved, stop the projector and check the location of the Claw Arm Pins in the sprocket holes of the film. When Framing is correct, the Top Claw Arm Pin should be the same distance from the inside edge of the sprocket hole at the top of its stroke as it is from the outside edge of the sprocket hole at the bottom of its stroke. (Figure 3-22). Loosen Screw (14) and adjust the Bushing (8) (Figure 3-21) so these two distances are equal. Remove the film from the projector after proper Framing and Side Clearance are established.




Figure 3-22. SIDE CLEARANCE

2. Remove the Motor Drive Belt or disconnect the Motor wires so the Main Drive Shaft will not turn during the next adjustments. Be careful not to disconnect the Blower wires.
(As an alternative, the STILL button may be depressed on models having that feature.)
3. Rotate the Inching Knob clockwise until the Claw Arm Pins are in the Aperture Plate Slot at the bottom of their travel. Insert the Stroke Setting Gauge (ST-5880) into the Aperture Plate Film Channel. Close the Film Gate. Make sure the Pressure Shoe seats properly. Push the Gauge down until it hits the Claw Arm Pins.
4. Rotate the Inching Knob clockwise through enough cycles of the Claw Arm to draw the target in the Gauge into the Aperture. Be careful not to allow the Claw Arm to move up at any time when the Pins are engaged in the sprocket holes. The Pins must pull the Gauge down smoothly for the measurement to be valid.

5. After the Gauge Target has been moved into the Aperture, continue turning the Inching Knob clockwise so the Claw Arm Pins withdraw from the bottom of the stroke and raise to the top of the stroke. STOP turning the Inching Knob when the Pins reenter the sprocket holes BEFORE they start moving down. (The Shutter Blade will be even with the bottom edge of the Aperture.)

Note: If you go too far, go back to Step (3) and repeat.

6. Turn the Lamp on and project an image at least 8" wide (a wide angle lens will help achieve this width at a shorter projection distance), raise the elevation approximately 1" (this will get you set up in case the Stroke is in need of adjustment), and draw a reference line the full width of the Target on the bottom step (Figure 3-23).




Figure 3-23. CLAW PULL DOWN STROKE SET-UP

7. Pull up on the Gauge. The projected Target will move down. The upper Target step must touch the reference line drawn in Step 6 for correct stroke (Figure 3-24).




Figure 3-24. CLAW PULL DOWN STROKE

INSTA LOAD/XL
2200 SERIES

8. Adjust stroke by placing the Shuttle Cam Adjusting Tool (ST- 5884) on the Claw Arm Pivot (18) (Figure 3-21), loosening Screws (14) and (19) and rotating the Pivot (18) and Bushing (8) the same amount in the same direction simultaneously. Turn counterclockwise (as viewed from the front of the projector) to shorten the stroke, and clockwise to lengthen the stroke (Figure 3-25).

Note: Theoretically, turning the Pivot (18) and the Bushing (8) equally will change Pull-Down Stroke but not Side Clearance. However, Side Clearance should be checked.


REQUIREMENT:

The Top Claw Arm Pin should be the same distance from the inside edge of the Gauge

sprocket hole at the top of its stroke as it is from the outside edge of the gauge sprocket hole at the bottom of its stroke. (Figure 3-22)

Loosen Screw (14) and adjust the Bushing (8) (Figure 3-21) so these two distances are equal.

WHEN ADJUSTMENTS ARE COMPLETE, THE ECCENTRIC PIN IN THE FRONT PIVOT (18) MUST ALWAYS BE BETWEEN 6 AND 9 O'CLOCK AS VIEWED FROM THE FRONT OF THE PROJECTOR. IF NOT, the cam follower on the Claw Arm may be severely worn requiring replacement of the Claw Arm.



9. If the stroke was adjusted, repeat Steps 3 through 8. When performing Step 6, it is quite probable that the bottom step of the projected Target no longer rests on the reference line. ADJUST THE ELEVATION to line up the bottom step of the projected Target with the reference line and then proceed with Steps 7 and 8. It may be necessary to repeat this sequence of steps several times until correct stroke and side clearance are obtained.
10. A final, dynamic check for proper Side Clearance is made during the Framing Adjustment which follows.

Claw Arm Adjustments-Model 2280

Side Clearance Pull-down Stroke

CAUTION: When working on Model 2280 Projectors, NEVER LOOK AT THE LAMP! It is advisable to wear dark or tinted glasses (preferably safety glasses) when working on these projectors.

Note: These two adjustments are interdependent and must be adjusted at the same time. If either one is adjusted, the other must be checked and adjusted as necessary until requirements for both can be met.

A good starting position for the Pivot (18) (Figure 3-26) places its eccentric pin at about 7 o'clock when viewed from the front of the projector. (See Figure 3-25) The notch in Bushing (8) should be slightly below the notch in Pivot (18) so an imaginary line drawn across the top of the Bushing notch aligns with the bottom of the Pivot notch.

Before attempting any adjustments, manually rotate the Inching Knob to make sure the Claw Arm pins do not strike the sides of the Aperture Plate Claw Slot. At the top of the Claw Arm Stroke, the Top Claw Arm Pin will be nearer the inside edge of the Aperture Plate Slot (Figure 3-27). At the bottom of its travel, this Pin will be nearer the outside edge of the Aperture Plate Slot. Loosen Screw (14) and adjust Bushing (8) (Figure 3-26) so these two distances are equal. (Removing the Lamphouse Cover and viewing the Pins from behind the Aperture Plate aids in this adjustment.)

1. Thread an old film in the projector (do not use a good film for this adjustment) and adjust the Framing Knob to eliminate any frame lines at the top or bottom of the projected image with the projector running in FORWARD. If excessive noise results when the Framing Knob is moved, stop the projector and check the location of the Claw




Figure 3-26. CLAW ARM ADJUSTMENTS

Arm Pins in the sprocket holes of the film. When Framing is correct, the Top Claw Arm Pin should be the same distance from the inside edge of the sprocket hole at the top of its stroke as it is from the outside edge of the sprocket hole at the bottom of its stroke. (Figure 3-27) Loosen Screw (14) and adjust the Bushing (8) (Figure 3-26) so these two distances are equal. Remove the film from the projector after proper Framing and Side Clearance are established.




Figure 3-27. SIDE CLEARANCE

2. Rotate the Inching Knob clockwise until the Claw Arm Pins are in the Aperture Plate Slot at the bottom of their travel. Insert the Stroke Setting Gauge (ST-5880) into the Aperture Plate Film Channel. Close the Film Gate. Make sure the Pressure Shoe seats properly. Push the Gauge down until it hits the Claw Arm Pins.

3. Rotate the Inching Knob clockwise through enough cycles of the Claw Arm to draw the Target in the Gauge into the Aperture. Be careful not to allow the Claw Arm to move up at any time when the Pins are engaged in the sprocket holes. The Pins must pull the Gauge down smoothly for the measurement to be valid.
4. After the Gauge Target has been moved into the Aperture, continue turning the Inching Knob clockwise so the Claw Arm Pins withdraw at the bottom of the stroke and raise to the top of the stroke. STOP turning the Inching Knob when the Pins re-enter the sprocket holes BEFORE they start moving down. (The Shutter Blade will be even with the bottom edge of the Aperture.)

Note: If you go too far, go back to Step (2) and repeat.

5. Modify a discarded 42994-G1 Safety Shutter as shown in (Figure 3-28). (A similar heat filter may be used)




Figure 3-28. MODIFIED SAFETY SHUTTER (42994-G1)

6. Hang this Heat Filter on the front of the Arc Lamp Mounting Bracket so it is between the Lamp and the Aperture. Make sure there is enough clearance so the Douser does not hit the Filter when the Douser is raised.
7. Operate the LAMP switch to "ON". Leave the main pushbutton switch on "STOP". It is suggested that the Lamp be left "ON" during the remaining tests. If the Lamp is turned "OFF", it must be allowed to cool before it will strike again.
8. Manually raise the Douser and project an image at least 8" wide (a wide angle lens will help achieve this width at a shorter projection distance), raise the elevation approximately 1" (this will get you set up in case stroke is in need of adjustment), and draw a reference line the full width of the Target on the bottom step. (Figure 3-29)




Figure 3-29. CLAW PULL DOWN STROKE SET-UP

9. Pull up on the Gauge. The projected Target will move down. The upper Target step must touch the reference line drawn in Step 8 for correct stroke (Figure 3-30).

3) PULL GAUGE UP




Figure 3-30. CLAW PULL DOWN STROKE

10. Adjust stroke by placing the Shuttle Cam Adjusting Tool (ST-5884) on the Claw Arm Pivot (18) (Figure 3-26), loosening Screws (14) and (19) and rotating the Pivot (18) and the Bushing (8) the same amount in the same direction simultaneously. Turn counterclockwise (as viewed from the front of the projector) to shorten the stroke, and clockwise to lengthen the stroke. (Figure 3-31)

Note: Theoretically, turning the Pivot (18) and the Bushing (8) equally will change Pull-Down Stroke but not Side Clearance. However, Side Clearance should be checked.

REQUIREMENT:

The Top Claw Arm Pin should be the same distance from the inside edge of the Gauge sprocket hole at the top of its stroke as it is from the outside edge of the Gauge sprocket hole at the bottom of its stroke. (Figure 3-27)

INSTA LOAD/XL
2200 SERIES

Loosen Screw (14) and adjust the Bushing (8) (Figure 3-26) so these two distances are equal.

WHEN ADJUSTMENTS ARE COMPLETE, THE ECCENTRIC PIN IN THE FRONT

PIVOT (18) MUST ALWAYS BE BETWEEN 6 AND 9 O'CLOCK AS VIEWED FROM THE FRONT OF THE PROJECTOR. IF NOT, the cam follower on the Claw Arm may be severely worn requiring replacement of the Claw Arm.




Figure 3-31. CLAW PULL DOWN STROKE ADJUSTMENTS

- If the stroke was adjusted, repeat Steps 2 through 10. When performing Step 8, it is quite probable that the bottom step of the projected Target no longer rests on the reference line. ADJUST THE ELEVATION to line up the bottom step of the

projected Target with the reference line and then proceed with Steps 9 and 10. It may be necessary to repeat this sequence of steps several times until correct stroke and side clearance are obtained.

R. Framing Adjustment

1. After the Claw Arm Adjustments have been checked and/or made, the Framing Limit Plate can be adjusted. (Figure 3-32)
2. Thread film in the Projector and run it in FORWARD. Adjust the Framing Knob to eliminate any frame lines at the top or bottom of the projected image.
3. Loosen two Screws (41) and slide the Framing Limit Plate (40) so the top of the Framing Arm (43) is centered in the notch of the Framing Limit Plate (40). Tighten the two Screws (41).
4. Run the projector in FORWARD and adjust the Framing Knob maximum in both directions. A frame line should move into the projected picture an equal amount on both top and bottom. Readjust the Framing Limit Plate (40) until this requirement is met.

Note: If the projector becomes noisy when the Framing Knob is rotated maximum in either direction, the Side Clearance is not correct and must be adjusted. (See Claw Arm Adjustments.)




Figure 3-32. FRAMING ADJUSTMENT

S. Replacing Photo Diode Chip in Sound Drum

1. Mark the body of the Sound Drum Support at the outer end of the Photo Diode (this establishes proper orientation for installation of a new Diode).
2. Remove the Retainer (1) and the Photo Diode (2) out of the slot. Clip the leads and discard the Diode. (Figure 3-33)
3. Remove the Insulating Tubing (3) and unsolder the remaining portion of the Diode leads.
4. Clean the residual epoxy cement from the Photo Diode Slot.
5. Position a new Photo Diode into the slot with the shiny, black surface up (red wire) and the end aligned with the mark made in Step 1. Assemble the Retainer (1) to hold the Photo Diode in place, orienting the Retainer as shown in Figure 3-33. Make sure the Photo Diode is perfectly flat in the slot. (The end of the Photo Diode should be .293" --about 9/32"-- from the end of the Sound Drum Support.) **THE PHOTO DIODE IS VERY FRAGILE. BE VERY CAREFUL NOT TO BREAK IT!**

INSTA LOAD/XL
2200 SERIES




Figure 3-33. REPLACING PHOTO DIODE CHIP IN SOUND DRUM SUPPORT

6. Mix 100 parts of Hysol R9-2039 Resin to 11 parts of Hysol H2-3404 Hardener (by weight). Dip a toothpick or paperclip in the cement mixture and apply cement to the slot, contacting the front edge of the Photo Diode so the cement will run under the Diode. DO NOT allow the cement to get on the top surface of the Diode. Allow the cement to dry thoroughly (overnight) before proceeding.
7. Slide the insulating tubing on the leads of the Photo Diode and make sure that the third piece of tubing is on the shield of the Cable (4). Solder the Black lead of the Photo Diode to the Shield of the Cable and the Red lead to the Center Conductor. Slide the tubing over the solder connections (It may be helpful to cut the Cable Tie (5) so the Cable can be lifted out of the slot for soldering). Dress the wires into the slot and replace the Cable Tie, if cut.
8. Measure the resistance between the Shield of the Cable and the Sound Drum Support with an Ohmmeter. The resistance must be 5 Megohms MINIMUM.

T. Sound Drum Adjustments

1. Loosen the Sound Optic Setscrew and remove the Sound Optic Cartridge. (This Cartridge may be very difficult to remove due to the wedging action of the nylon plug used to lock it in place. Rotating it back and forth while pushing up on it will aid in its removal. DO NOT pry up on the bottom of the Cartridge as this will damage the bottom lens.) Inspect the bottom lens element for damage.
2. Insert the Sound Drum Locating Plug (T-38001-G) in place of the Sound Optic Cartridge. Push the Plug down until the small pin in its end is just above the Photo Diode in the Sound Drum Support (the pin should not touch the Diode).
3. Loosen the Sound Drum Support Retaining Screw and rotate the Support until the Photo Diode notch of the Support is centered on the pin in the end of the locating Plug. (The sound drum support Setscrew is accessible through a small hole in the bottom of the projector base. Use a long-bladed 1/16" Allen Wrench.)

INSTA LOAD/XL
2200 SERIES

4. Insert the Sound Drum in the Sound Drum Support and push this entire assembly toward the main casting until the back edge of the Sound Drum just touches the Pin on the Locating Plug. (Figure 3-34) Be sure to maintain the centering accomplished in Step 3 while making this adjustment.

Note: Be sure the Sound Drum is butted against the end of the Sound Drum Support during this adjustment. Having the Flywheel attached during this adjustment will help in holding these parts together in proper orientation.




Figure 3-34. SOUND DRUM ALIGNMENT




Figure 3-35. FEED SPROCKET CLUTCH

U. Feed Sprocket Clutch

1. Lubricate the Spring (6) with 009 Lubricant (39479-P7) (Figure 3-35).
2. Assemble the Lubricating Pad (7) and the Clutch Spring (6) making sure the tail of the Spring (6) is trapped in the Notch (N) of Gear (14).
3. Assemble Pin (11) to the Gear and Hub Assembly (3) and assemble the remaining parts on the shaft of Gear (14) in the order shown.
4. Adjust the Nut (8) to obtain .002" to .010" end play on the Gear and Hub Assembly (3).
5. Assemble the clutch to the projector (see Reassembly of Front Clutches to Projector).
6. Assemble Stop (9) and Nut (15) and tighten the Nut (15) just enough to hold the Stop in place.
7. Depress Pin (A) and turn Clutch Gear (B) clockwise until Pin (A) touches Pin (C). HOLD GEAR (B) — DO NOT ALLOW IT TO SPRING BACK. (Figure 3-36)
8. Position the Stop (D) so that the corner or edge is just over the small cross pin of Pin (A) as shown.
9. Hold Nut (F) to prevent it from turning and tighten Nut (E) being careful not to allow Stop (D) to turn during this tightening process.
10. Recheck the end play of the Gear and Hub Assembly (B) for .002" to .010". Repeat Steps 6 through 9 until the Stop (D) is positioned properly and the end play is correct.

STEPS 6 THROUGH 10 PERTAIN TO FAST FORWARD PROJECTORS ONLY. PROCEED TO STEP 11 IF YOUR PROJECTOR IS NOT A FAST FORWARD MODEL.

INSTA LOAD/XL
2200 SERIES

11. Lubricate the outside diameter of Pin (2) with Teresso Instrument Oil (39479-P8) and insert the pin in the hole in the end of the shaft of Gear (14). (Figure 3-35)
12. Insert the Spring (1) through the hole in the end of Pin (2) and then into the hole in the end of Pin (11).
13. Push the Spring (1) onto the Roll Pin protruding from the Gear and Hub Assembly (3). (On Fast Forward models, be sure the cross pin in Pin (11) is pointing toward the shaft of Gear (14).




Figure 3-36. FEED SPROCKET CLUTCH ADJUSTMENT

V. Fast Forward and Rewind Clutches




Figure 3-37. REWIND and FAST FORWARD CLUTCH REASSEMBLY

1. Lubricate the outside diameter of the shaft of the Pulley Assembly (8) and assemble the Gear (7) and the Drum (6) to the shaft as shown (Figure 3-37)
2. Seat the notches of the Drum (6) over the raised lugs inside the Cup Gear (7).
3. Assemble the Arbor (4) on the shaft of the Pulley (8) and tighten the Setscrew (5) in the notch in the end of the shaft allowing for end play of .005" to .010".
4. Apply three or four small drops of Teresso Instrument Oil (39479-P8) on the Arbor (4) and push the Spring (1) over the Arbor until it is seated on the Drum (6) with its tail trapped in the slot in the Drum.
5. Assemble Screw (2) and Washer (3) to the Drum (6) trapping the tail of the Spring (1) permanently in the slot of the Drum (6).
6. Assemble the Clutch to the projector (see Reassembly of Front Clutches to Projector).

W. Switch Adjustments

1. Switches (S-3), (S-5), (S-6), and (S-7) should be adjusted to actuate in the LOAD position and relax in the PROJECT position. (Figure 3-38)
2. Switch (S-4) should be adjusted to relax in the LOAD and PROJECT positions and actuate between these two positions.




Figure 3-38. OPERATING LOGIC SWITCH CLUSTER

X. Film Counter

1. Lubricate the interfaces of the Idler Gear Assembly Shaft (8) and the Bearing (10) with Teresso Instrument Oil (39479-P8). (Figure 3-39)
2. When the Gear (6) is rotated, the entire gear train and counter must operate freely and smoothly.




Figure 3-39. FILM COUNTER

INSTA LOAD/XL
2200 SERIES

SECTION IV ELECTRICAL SYSTEM

PARA.	TITLE	PAGE
A.	FORWARD PROJECT	4-1
B.	REVERSE PROJECT	4-2
C.	FAST FORWARD	4-3
D.	FAST REWIND	4-5
E.	AUDIO AMPLIFIER	4-8
F.	MARC 300 POWER SUPPLY	4-11

Switches (S2D) and (S7) are closed applying either 22 or 24 volts AC from the "Hi-Lo" Lamp Switch (S9) to the Blower Motor Relay (K7) and Projection Lamp (L1). The Relay operates since the other side of its coil is connected directly to the "NEUTRAL" side of the primary of the Transformer (T1). The Projection Lamp lights having its circuit completed through the (C) and (NC) contacts of switch (S3), and the blower Motor operates with "LIVE" power connected to one side of it through the closed contacts of Relay (K7) and "NEUTRAL" power connected to its other side through the (C) and (N.C.) contacts of Switch (S3).

NOTE: The Projection Lamp and Blower Motor operate only when the Master Control Lever is in the PROJECT position. Switches (S3) and (S7) move to their (N. O.) contacts when the Master Control Lever is in the LOAD position, removing power from the Lamp and Blower Motor Relay circuits.

Switch (S2A) closes only when the Forward button on the Main Control Switch is depressed. It completes the exciter lamp circuit through the normally closed contacts of Relay (K1), allowing the exciter lamp to light and produce sound from the film.




Figure 16. Reverse Project

B. REVERSE PROJECT - 2270 MODELS

With the Reverse button depressed, the Main Control Lever in the Project mode and the Main Power Switch "ON", switches (S2B), (S2C), (S2D), and (S14) are closed. The movable contacts are connected to the normally closed contacts on switches (S3) and (S5) and Relay (K-1). Relay (K-3) is operated closing its normally open contacts. Switch (S-6) is open. Switch (S-9) may be in the "Hi" or "Lo" position. Switch (S2FJ) is connected to terminal (6) and (S2GH) is connected to terminal (8).

The "LIVE" side of the line is connected to the black wire of the start winding and the yellow wire of the run winding of the Main Drive Motor. The "NEUTRAL" side of the line is connected to the white wire of the start winding and the brown wire of the run winding of this motor. Thus, the phase relationship is established between the two windings which causes the motor to run in reverse.

The Rewind Solenoid (SO1) operates since the "LIVE" side of the line is connected to its terminal (2) from (S2FJ) and the "NEUTRAL" side of the line is connected to its terminal (1) through (S5) and (S3).

INSTA LOAD/XL
2200 SERIES

The operated Rewind Solenoid locks the Rewind Clutch in direct drive so it can drive the supply reel to take up film in reverse. The Rewind Clutch is driven by the Feed Sprocket Clutch which is not locked into direct drive because solenoid (S02)

is not operated. The Feed Sprocket Clutch slips to provide the proper Reverse take-up tension and prevent film damage in the front sprocket.

Switch (S2A) mutes the sound by opening the exciter lamp circuit so the exciter lamp goes out.

C. FAST FORWARD - 2270 MODELS

Power is supplied to all the projector circuits by operating the Main Power Switch (S14) to "ON". With the Forward button depressed, the Master Control Lever in the Fast mode and the Main Power Switch "ON", switches (S2A), (S2B), (S2C), (S2D) and (S14) are closed. The movable contacts (C) are connected to the normally open (N. O.) contacts on switches (S3), (S5) and (S6). Switch (S9) may be in the "Hi" or "Lo" position. Switch (S2FJ) is connected to terminal (9) and (S2GH) is connected to terminal (7). Relay (K3) is operated closing its normally open contacts.

The "LIVE" side of the line is connected to the black wire of the start winding and the brown wire of the run winding of the Main Drive Motor. The "NEUTRAL" side of the line is connected to the white wire of the start winding and the yellow wire of the run winding of this motor. Thus the phase relationship is established between the windings which causes the motor to run in forward.

Relay (K1) is operated because one side of its winding (terminal 9) is connected to the line "NEUTRAL" through switches (S3) and (S4), and the other side of its winding (terminal 11) is connected to the line "LIVE" through switch (S6). Relay contacts (K3) and switches (S2C) and (S14). The normally closed contacts (K1A) open, breaking the exciter lamp circuit to mute the sound in the fast mode. Contact (K1B) connects the line or mains "NEUTRAL" to the Fast Forward Solenoid (S03) terminal (5). The solenoid operates because its other end (terminal 6) is connected to line "LIVE" through switch (S2GH), Relay (K3), and switches (S2C) and (S14). With the Fast Forward solenoid operated, the Fast Forward Clutch is locked into direct drive to transport film rapidly through the projector in the forward direction.

When film is transported rapidly "IN-PATH" through the projector, it must not be possible to raise the Master Control Lever to the Project Mode and close the mechanism tightly on the film or else the film would be damaged. A Fast mode interlock system is used to prevent this from happening.




Figure 17. Fast Forward Initially On

INSTA LOAD/XL
2200 SERIES




Figure 20. Rewind 2270 Initially On

When film is transported rapidly "In-Path" through the projector, it must not be possible to raise the Master Control Lever to the Project mode and close the mechanism tightly on the film or else the film would be damaged. A Fast mode interlock system is used to prevent this from happening. This interlock system is activated and held by Relay (K2) and Interlock Solenoid (SO2).

When the projector is initially turned on in the Rewind mode, Relay (K2) does not operate because capacitor (C18) acts as a momentary short across it while it is charging. After 3 to 5 seconds, (C18) is charged and (K2) operates to connect the "LIVE" side of the line to Interlock Solenoid (SO2) and Interlock Indicator Lamp (L3). These operate because their other side is connected to the line "NEUTRAL" through the N. O. contacts of Switch (S3) and Switch (S4).

INSTA LOAD/XL
2200 SERIES




Figure 21. Rewind 2270 C-18 Charged

Interlock Solenoid (S02) performs two distinct functions in Rewind. First, it operates the mechanism which locks the Master Control Lever in the Fast Mode position. Second, it causes the Feed Sprocket Clutch to go into direct drive so it will not slip when driving the Rewind Clutch in Rewind. (See REWIND under FEED AND REWIND SYSTEM)

Interlock Indicator Lamp (L3) lights to show that the mechanism is in a Fast Mode function.

When the projector is turned off, "LIVE" AC power is removed from the Main Drive Motor (M1), Relays (K1), (K2), and (K3) and Rewind Solenoid (S01). Relays (K1) and (K3) and Rewind Solenoid (S01) release. Relay (K2) remains operated for 3 to 5 seconds while (C18) discharges through it.

The contacts of Relay (K2) continue to apply "LIVE" AC power to the interlock circuit and now also to the Fast Forward Solenoid (S03) through the N.C. contacts of Relay (K1B).

The Interlock Solenoid (S02) remains operated for 3 to 5 seconds preventing the Master Control Lever from being raised before the film comes to a complete stop.

The Fast Forward Solenoid (S03) operates to lock the Fast Forward Clutch in direct drive braking the rear reel and stopping fast film movement through the projector.

After 3 to 5 seconds, Capacitor (C18) discharges sufficiently so Relay (K2) releases and removes power from this entire circuit causing the Fast Forward Solenoid (S03) and Interlock Solenoid (S02) to release, thus restoring the circuit to its rest condition.

INSTA LOAD/XL
2200 SERIES

THE MAIN AMPLIFIER

The Main Amplifier consists of Preamplifier (Z1A) and (Z1B), Tone Control (VR-2), Volume Control (VR-3), Mixer Amplifier (Z4D), and Driver and Power Amplifier (Z2), (Q1) and (Q2).

The variations of light intensity produced by the exciter lamp shining through the sound track on the film are picked up by a photo-sensitive diode (PD-1) and converted to electrical variations. These electrical variations are fed into the Preamplifier (Z1A) and (Z1B) where they are amplified and fed to the Tone/Volume Control (VR-2) and (VR-3). From there they pass into the Mixer Amplifier (Z4D) and then into the Driver and Power Amplifier (Z2), (Q1) and (Q2). The Power Amplifier then drives the Speakers (LS1) and (LS2) mounted in the projector. A standard $\frac{1}{4}$ " audio jack (JS1) is provided for connecting an external speaker. The external speaker plug opens the normally closed contacts of this jack and removes the internal speakers from the circuit.

THE MICROPHONE PREAMPLIFIER

With the Microphone plugged into the Mic Jack (JM-1) and the Microphone Level Control (VR4) adjusted to the desired level, the signals introduced by the microphone are amplified by the Preamplifier (Z4A) and (Z4B) and fed from the Level Control (VR4) to the Mixer Amplifier (Z4C). From there they are fed to the Drive and Power Amplifier (Z2), (Q1) and (Q2) and then to the Speakers (LS1) and (LS2).

Since the Microphone signal is fed through Mixer Amplifier (Z4C) at the same time that the Main Amplifier signal is fed through Mixer Amplifier (Z4D), it is possible to talk over the sound on the film with the microphone. It is also possible to use the projector as a P. A. amplifier by using just the microphone feature with no film running in the projector.

THE MUTING CIRCUIT

The purpose of the Muting Circuit is to open the circuit between the Main Amplifier output and the speakers each time a button on the Main Control Switch is depressed, thereby eliminating "switch clicks" or "popping" in the speakers caused by transients produced from opening and closing switch contacts.

Half Wave Rectifier (D2) and Filter Capacitor (C40) produce the positive voltage required to operate Transistors (Q4), (Q5), and (Q6). A small portion of this positive voltage is impressed on the base of (Q5) through Resistors (R62), (R63), and (R65), forward biasing the transistor and allowing it to conduct. In turn, (Q5) forward biases (Q6) and it conducts through Relay (K4). The Relay operates and its contacts close completing the speaker

circuit. Transistor (Q4) is cut off at this time by the ground connected to its base through the switches (S11) and (S2E).

When any button is depressed on the Main Control Switch (S2), contact (S2E) opens as the button starts down and closes when the button reaches the bottom of its travel. This lifts the ground from the base of (Q4) allowing (Q4) to conduct while the button is being pressed. The resulting drop in voltage at the collector of (Q4) is coupled to the base of (Q5) cutting (Q5) and (Q6) off and releasing the Relay (K4). The contacts of (Q4) open to disconnect the speakers from the output amplifier and mute switch clicks.

THE POWER SUPPLY

The 40 volts AC from the secondary of the Lamp-Amplifier Transformer (T1) is rectified by Full Wave Bridge Rectifier (D1) to produce 54 volts DC which is centertapped to produce a positive and negative 27 volts DC.

The positive 27 volts feeds the current regulator circuit (Q3) and (Z3) and the relay portion of the muting circuit (K4) as well as the main amplifier and microphone preamplifier. The negative 27 volts is used for the driver and power amplifier stages of the main amplifier (Z2) and (Q2).


Current regulation is accomplished by transistor (Q3) and regulator chip (Z3). This regulated current is required to keep the exciter lamp brilliance constant and prevent any variations in sound which would occur if the brightness of the exciter lamp were to vary.

When the DC voltage to the circuit increases because of the line voltage increase, the DC output current from the emitter of the transistor tries to increase. However, since the base is held at a constant voltage by the regulator chip (Z3), any attempted increase in emitter voltage is recognized as an increase in reverse bias causing the transistor to conduct less and maintain a constant current at its emitter.

When the input DC voltage drops due to a drop in line voltage, the voltage at the emitter of (Q3) tries to drop. With the base still held at a constant voltage by the regulator chip (Z3), this attempted drop in voltage at the emitter causes greater forward bias, the transistor conducts more, and the output at its emitter remains the same.

Resistor (R38) is in a series with the exciter lamp (L2) to reduce the 18 volt regulated supply to approximately 5.6 volts for the exciter lamp. When the exciter lamp is removed from the circuit, the voltage measured between P1-8 and P1-9 will be 18 volts. This is an open circuit voltage since no circuit is flowing in the circuit with the exciter lamp removed.


INSTA LOAD/XL
2200 SERIES



F. MARC 300 POWER SUPPLY

The key to operation of the regulated Mark 300 Arc Lamp Power Supply is the voltage developed across Resistor (R22) when Arc Lamp current flows. When


the Power Pack is initially turned on, there is no voltage across (R22) and a low appears on pins 5 and 8 of (IC1).



The low output from pin 2 of (IC1) conditions the series regulating circuit to turn Transistor (Q7)


fully on allowing the boost capacitor (C18) to charge.

INSTA LOAD/XL
2200 SERIES



The high output from pin 14 of (IC1) turns transistor (Q2) fully on so the high voltage winding (F-D) of auxiliary transformer (T1) can charge the strike


capacitor (C8) to the 375 volt breakdown voltage of the spark gap.



When the spark gap arcs, (C8) discharges through the primary winding of pulse Transformer (T2), which


applies a 15,000 volt pulse on the anode of the Gemini 300 Lamp.

INSTA LOAD/XL
2200 SERIES



The Arc Lamp ignites and the boost Capacitor (C18) discharges through it to sustain conduction long

enough for the series regulated circuit to take over.



A voltage appears across Resistor (R22) which causes a high to appear at pins 5 and 8 of (IC1). The high output from pin 2 of (IC1) conditions the series regulating circuit to drop the voltage on the base of (Q7) so it will regulate current in the series regulated circuit to 7.7 amps as preset by resistor (R7). The low output from pin 14 of (IC1) turns transistor (Q2) off and disables the strike circuit.

A reduction in lamp current reduces the voltage across (R22), reducing the high applied to pin 5 of (IC1). The output high from pin 2 of (IC1) is reduced, conditioning the series regulating circuit to allow (Q7) to conduct more to compensate for the reduction in lamp current. The converse is true if lamp current increases.

SECTION V ELECTRONIC CIRCUIT ADJUSTMENTS




Figure 5-1. 16mm AUDIO AMPLIFIER-BLOCK DIAGRAM

A. ADJUSTMENT OF VR-1

Before attempting to adjust VR-1, perform the Buzz track adjustment and the Sound Optic Focusing adjustment.

1. Thread a continuous loop of 400 Hz Signal Level Test Film (SMPTE P16-SL) in projector.
2. Connect an Oscilloscope and/or an AC VTVM between pin 1 of Z1 (Test Point 6) and ground (Test Point 9).
3. Run the projector in Forward and observe the signal on the oscilloscope.
4. The Signal should be an undistorted sine wave with an amplitude of 1.5 volts RMS(4.4 volts P-P)
5. Adjust VR-1 to obtain the above reading.
6. Stop the projector.
7. Plug an 8 ohm, 25 watt dummy load into the speaker jack (JS1)
8. Set the volume control to its extreme Left position and the Tone Control to its extreme Right position.
9. Disconnect the Oscilloscope and/or VTVM from pin 1 of Z1 and connect them across the 8 ohm resistor.
10. Run the projector in Forward and gradually move the Volume Control to the Right(increasing volume) until the signal on the oscilloscope just starts to show clipping of the peaks.
11. The voltage across the 8 ohm resistor should be 14 volts RMS minimum(39.5 volts P-P(+25db)
12. Remove the 400 Hz loop from the projector and run the projector in Forward without film in it. DO NOT MOVE THE TONE OR VOLUME CONTROL.




Figure 5-2. CIRCUIT BOARD TEST POINTS

13. The reading on the Oscilloscope and/or VTVM should be .14 volts RMS maximum (.395 volts P-P) (-15 db)

This is equivalent to a signal-to-noise ratio of -40db.




Figure 5-3. 0dbm CIRCUIT

B. 0dbm ADJUSTMENT

1. Adjust (VR-1) on the main amplifier board per procedure.
2. With the 400 Hz. Signal Level Test Film (SMPTE P16-SL, Singer P/N 45191-G7) running in Forward through the projector, plug a 600 ohm, 1 Watt resistor into the 0 dbm jack (J-7) and connect an AC VTVM across the resistor. Adjust VR-6 on the 0dbm Circuit Board for 0dbm reading on the AC VTVM (.775 volt).




Figure 5-4. 0 dbm CIRCUIT BOARD

C. 5KHz FILTER / AMPLIFIER ADJUSTMENT

1. Connect a jumper wire between Test Point 15 and Test Point 19 on the 5K Hz. Filter Board.
2. Perform the Buzz Track Adjustment and the Sound Optic Focusing Adjustment per the procedures for those adjustments.
3. Remove the jumper connected in Step 1 above.
4. Thread a continuous loop of 400 Hz. Signal Level Test Film (SMPTE P16-SL) in the projector.
5. Connect an Oscilloscope and/or an AC VTVM between pin 1 of Z1 (Test Point 6) and ground (Test Point 9) on the main amplifier board.
6. Run the projector in Forward and adjust the Reserve Gain Potentiometer (VR-1) on the main amplifier board for a reading of 3.0 volts RMS (8.5 volts P-P).
7. Plug an 8 ohm, 25 watt dummy load into the ext. speaker jack (JS-1) and connect the Oscilloscope/VTVM combination across this load.
8. Set the Tone Control to its mid position and adjust the Volume Control for a reading of 11 volts RMS (31 volts P-P).
9. Remove the 400 Hz. loop from the projector and run the projector in Forward without film in it. DO NOT MOVE THE TONE OR VOLUME CONTROL. The VTVM reading should be .11 volts RMS or less (.31 volts P-P). This represents a Signal to Noise Ratio of 40db.
10. Thread a continuous loop of 5K Hz. Test Film (SMPTE P16-SFB) in the projector and run it in Forward.
11. Adjust the 5K Hz. Null Potentiometer (VR-5) on the 5K Hz. Filter Board for a minimum reading on the VTVM or Oscilloscope. This reading should be .348 volts RMS or less (.984 P-P). (This represents a 30db rejection of the 5K Hz. signal from the audio output.)

INSTA LOAD/XL
2200 SERIES




Figure 5-5. 2220L 5K Hz. (Driver Training) Filter Circuit

12. Connect the Oscilloscope and/or VTVM across the 5K Hz. Jack (JS-1B) and terminate the jack with a 1000 ohm, 1 watt resistor.
13. Adjust the 5K Hz. Output Level Potentiometer (VR-4) on the 5K Hz. Filter Board for .505 volt RMS (1.43 volts P-P). If .505 volt cannot be obtained by adjusting (VR-4), leave it at maximum and adjust (VR-1) on the main amplifier board for .550 volt RMS (1.55 volts P-P) at (JS-1B).
14. Remove the 1000 ohm resistor from the 5K Hz. Jack (JS-1B).
15. Adjust (VR-4) on the 5K Hz. Filter Board to reduce the 5K Hz. output at (JS-1B) to .180 volt. (This is a requirement for all driver trainer projectors. Failure to meet this requirement indicates a problem in the 5K Hz. circuit.)
16. Readjust (VR-4) on the 5K Hz. Filter Board for .505 volt at the 5K Hz. Jack (JS-1B) with the 1000 ohm, 1 watt resistor terminating the jack.




Figure 5-6. 2220L 5K Hz. (Driver Training) Filter Board




Figure 5-7. DC Power Supply

Exciter Lamp voltage on all 2200 Series Projectors should be approximately 5.6 volts DC WITH THE EXCITER LAMP IN THE CIRCUIT. With the Exciter


Lamp removed from the circuit, the open circuit voltage is +18 volts, DC.

SECTION VI TROUBLE SHOOTING


TROUBLESHOOTING AID CHARTS

The Troubleshooting Aid Charts are included as a logical approach to a troubleshooting procedure. They are by no means the final word on how troubles should be traced, but they are designed to eliminate as much duplication of effort as possible. Simply follow the direction of the arrow describing the condition existing during any given test. If following arrows results in a closed loop, then a trouble most likely exists in that area and further testing in that area is recommended.


Loses Upper Loop



Auto Loop Restorer Cycles Continuously




Auto Loop Restorer Recycles Continuously In Fast Forward



* If the gear eccentric is worn, carefully examine the latch tab on the Loop Resetting Arm for rough edges or burrs.


Auto Loop Restorer Doesn't Cycle



SEMICONDUCTOR TESTING

1. Transistors

An effective but simple transistor test for leakage, amplification and short circuit conditions may be performed using any standard 20,000 ohm/volt multimeter. Connect the transistor under test in the circuit shown, observing polarity.



Use the X100 scale for regular small-signal devices and X10 scale for power types. All readings are referred to the X1 scale.

With the base switch open, the reading should be above 200 ohms. A lower reading indicates excessive leakage or a shorted transistor.

With the base switch closed, the reading should be less than 500 ohms. A higher reading indicates low gain, and a very high reading indicates an open transistor.

Polarity is shown for NPN transistors using a Simpson 260/270 Multimeter with the ohmmeter voltage selector switch set on positive DC. PNP transistors may be checked by reversing the VOM polarity. Observe opposite polarity of terminal voltage when using Weston or Triplett instruments.

2. Diodes


Front-to-back resistance ratio will indicate silicon and germanium diode defects. Using the RX100 multimeter scale, a diode should measure a very low resistance with one lead (test probe) polarity and very high resistance with leads reversed.

3. Zener Diodes


Depending on voltage rating, Zener diodes will exhibit lower reverse resistance than regular diodes but a marked front-to-back ratio should be evident.

INSTA LOAD/XL
2200 SERIES

Take-up Sluggish, Erratic or Fails




Projector Exhibits "WOW" In Sound



INSTA LOAD/XL
2200 SERIES


Rewind Sluggish or Fails



* Omit this step if the projector has no fast forward function.

** This step applies to Simplified Control models only.

Fast Forward Sluggish or Fails



INSTA LOAD/XL
2200 SERIES

TROUBLE	CAUSE	REMEDY
1. Control System Troubles		
a. Blower Motor does not operate in any mode.	Blower Motor defective Blower Motor Relay defective (Models 2270 and 2280) Switch S2 defective Switch S7 defective (Model 2270)	Replace Blower Motor Replace Blower Motor Relay (K7 on 2270 and K6 on 2280) Replace Switch S2 Replace Switch S7 (Model 2270)
b. Projector does not operate when FORWARD button is depressed	Switch S2 defective Relay K3 defective (Models 2270 and 2280)	Replace Switch S2 Replace Relay K3
c. Projector operates but projection lamp does not illuminate when the FORWARD button is pressed	Projection lamp defective Transformer T1 defective Switch S2 defective Switch S9 defective Switch S7 defective (Models 2270 and 2280) Lamphouse cover not in place properly (Model 2280) Switch S8 defective (Model 2280)	Replace lamp Replace transformer Replace Switch S2 Replace Switch S9 Replace Switch S7 Assemble lamphouse cover to projector properly Replace Switch S8
d. Low light level on screen during projection	Safety shutter not lifting Safety shutter sticking Safety shutter defective	Redampen with DC200 (39479-P13) Visually align the safety shutter midway between the shutter and cam assembly. Safety shutter spring and link must clear the shutter cam by 1/8" Replace safety shutter
e. Film burns in still mode	Safety shutter sticking on bumper pad Safety shutter return spring unhooked or missing Safety shutter defective	Replace bumper pad Reassemble or replace spring Replace safety shutter
f. Projector does not operate when REVERSE button is depressed	Switch S2 defective (terminals H-8 or J-6)	Replace Switch S2
g. Fast mode interlock light does not come on with Master Control Lever in LOAD/FAST and FORWARD or REVERSE button pressed	Interlock lamp L3 defective Capacitor C18 shorted Relay K2 defective Diode D3 open Resistor R27 open	Replace Lamp L3 Replace Capacitor C18 Replace Relay K2 Replace Diode D3 Replace Resistor R27

INSTA LOAD/XL
2200 SERIES

TROUBLE	CAUSE	REMEDY
h. Fast mode interlock light does not remain on for five seconds after STOP button is pressed (Models 2270 and 2280)	Capacitor C18 open Relay K5 defective (Model 2280) Relay K6 defective (Model 2270)	Replace Capacitor C18 Replace Relay K5 Replace Relay K6
i. Failure to drive in Fast FORWARD or brake in REWIND (Models 2270 and 2280)	Solenoid SO3 defective Relay K1 defective Switch S3 defective Switch S6 defective Fast Forward clutch actuator cap not engaging clutch spring properly Fast Forward drive belt tension incorrect	Replace Solenoid SO3 Replace Relay K1 Replace Switch S3 Replace Switch S6 Check cap/spring engagement. Replace actuator cap or spring as necessary Adjust drive belt tension
j. Failure to REWIND, or brake in FAST FORWARD	Solenoid SO1 defective Solenoid SO2 defective Relay K1 defective Switch S3 defective Switch S5 defective Rewind clutch actuator cap not engaging clutch spring properly Feed sprocket clutch positive drive roll pin missing	Replace Solenoid SO1 Replace Solenoid SO2 Replace Relay K1 Replace Switch S3 Replace Switch S5 Check cap/spring engagement. Replace actuator cap or spring as necessary Replace feed sprocket clutch gear
k. Failure to brake in REWIND (Models 2210, 2220 and 2220L)	Rewind brake cable off pulleys Wrong rewind brake cable length Take-up clutch pulley worn Take-up clutch brake spring worn or dirty	Reassemble brake cable Adjust brake cable Replace take-up clutch pulley Clean or replace brake spring
m. No interlock on main lever in FAST modes	Solenoid SO2 defective Interlock link uncoupled or deformed	Replace Solenoid SO2 Reassemble or reform
2. Film Handling and Picture Troubles (NOTE: Test Film must be in good condition)		
a. Noisy film handling in film gate	Claw protrusion or stroke out of adjustment Pressure shoe out of adjustment Emulsion buildup on pressure shoe and aperture plate	Adjust protrusion and/or stroke Adjust pressure shoe Clean pressure shoe and aperture plate

INSTA LOAD/XL
2200 SERIES

TROUBLE	CAUSE	REMEDY
2. Film Handling and Picture Troubles (Continued)		
a. Noisy film handling in film gate (Continued)	Claw arm pins worn or damaged	Replace claw arm
b. Film scratch	Dirty film Aperture plate or pressure shoe dirty Film path rollers stuck	Clean the film Clean with Isopropyl Alcohol or Chlorothene 1 + 1 + 1 Clean and lubricate film path rollers
c. Film damage at feed sprocket	Supply reel arm pulley binding No end play in feed sprocket Sprocket defective	Clean or replace reel arm pulley and bearing Adjust end play by reducing number of washers (35473-P48) Replace feed sprocket
d. Film spills at supply reel (Reverse operation)	Solenoid SO1 defective Rewind clutch actuator cap not engaging clutch spring properly Feed sprocket clutch not driving	Replace Solenoid SO1 Check cap/spring engagement. Replace actuator cap or spring as necessary Check feed sprocket clutch spring and arbor. Replace as necessary
e. Clicking noise (film picking)	Teeth of feed or take-up sprocket damaged or out of alignment Claw arm teeth worn, damaged or missing Pressure shoe not seated properly Claw arm out of adjustment	Replace feed or take-up sprocket Replace claw arm Adjust pressure shoe Adjust stroke and/or protrusion
f. Damaged film at take-up	Film take-up tension too high Bottom idler roller pressure too high or too low Take-up sprocket defective	Adjust take-up tension Adjust pressure roller eccentric Replace take-up sprocket
g. Film spills in FORWARD at supply reel	Rewind clutch driving	Clean and adjust rewind clutch. Check rewind clutch for proper end play. Replace actuator cap, spring or arbor as necessary.
h. Loose film on reel after rewind	Supply or take-up reel bent	Replace bent reel
i. Picture jumps (possible loss of loop)	Claw protrusion, stroke or side clearance out of adjustment Aperture plate or pressure shoe dirty	Adjust protrusion, stroke and side clearance Clean aperture plate and pressure shoe with isopropyl alcohol or chlorothene 1 + 1 + 1


INSTA LOAD/XL
2200 SERIES

TROUBLE	CAUSE	REMEDY
i. Picture jumps (possible loss of loop) (Continued)	Pressure shoe not aligned properly Claw arm damaged	Align pressure shoe Replace claw arm
j. Picture motion - side-to-side	Film edge guide spring weak or assembled improperly	Replace spring or assemble properly
k. Picture goes in and out of focus at random	Bad film Pressure shoe damaged or out of adjustment	Check projector with known good film Replace or adjust pressure shoe
m. Picture "streams" vertically	Pressure shoe not aligned Claw arm protrusion too short Film edge guide spring not assembled properly	Align pressure shoe Adjust protrusion Reassemble properly
3. Sound System Troubles		
a. Exciter lamp blows or has short life	Defective lamp, Q3, Z3, or R38	Replace lamp first then try each component
b. Exciter lamp doesn't light. Speaker hiss increases with volume control	Defective lamp, Q3, Z3, or R38 Exciter lamp socket defective or open leads to the lamp socket Switch S2A defective or Relay K1 defective (Model 2270) Switch S2A defective or Switch S9 defective (Model 2280)	Replace lamp first then try each component Replace lamp socket after checking for open leads to the socket Replace defective component Replace defective component
c. Exciter lamp doesn't light. No speaker hiss	Fuses F1 and F2 blown, Defective D1, T1, C23	Check for defective component, then replace fuses
d. Exciter lamp O.K. No sound from film. Speaker hiss increases with volume control	Defective Photo diode PD1, Z1, C1, C5, broken or shorted wire from sound drum, defective P1-15 or 16	Check for open or shorted wire from sound drum then check each component and plug P1
e. Exciter lamp O.K. No sound from film. Speaker hiss but volume control has no affect on hiss	Defective Z1, C10, P1-15 or 16, Z4 (Models 2270 and 2280)	Check P1 contacts, replace defective component
f. Exciter lamp O.K. No sound, hum or hiss	Defective Fuse F3, Switch S2A (Models 2210, 2220 and 2220L), Speaker jack JS1, C34, Q1, Q2, Z2, Bad connection to speaker In addition for models 2270 and 2280: Defective S2E, K4, S11, D2, Q4, Q5, Q6	Check for bad fuse and bad connections, then replace defective component Replace defective component
g. Exciter lamp O.K. Distorted sound	Defective Z1, Z2, Q1, Q2, C24, C1, C5, C10, C13, C34, Z4 (Models 2270 and 2280), speaker	Replace defective component
h. Excessive hum with sound	Defective C23, C24, C9	Replace defective component

INSTA LOAD/XL
2200 SERIES

TROUBLE	CAUSE	REMEDY
4. Miscellaneous Troubles		
a. Motor runs, drive shaft does not rotate	Motor belt tension low (belt slips) Main shaft pulley loose Belt and pulleys dirty Motor pulley pin broken	Adjust belt tension Tighten setscrews Clean with isopropyl alcohol or chlorothene 1 + 1 + 1 Replace pulley or pin (39092-P1)
b. Failure to start on low power	Kick spring on main drive motor hub not functioning properly	Check as follows: (1) Hold pulley without binding motor shaft. Wind spring to fully tight position by rotating fan. (2) Release fan. Spring must throw fan 180°. If less than 180°, clean and lubricate - replace spring if necessary
c. Loss of power and/or speed	Extremely low line voltage Low drive belt tension	Check line voltage - consult with power company Adjust drive belt tension
d. Failure to set upper loop	Loop set cables loose or off pulley Defective loop setting gear or drum in front sprocket assy	Reassemble, tighten and adjust Replace defective part(s)
e. Master control lever binds when moving from LOAD to PROJECT	Defective loop setting gear or drum in front sprocket assy Lensholder stop pin not set correctly Front sprocket clutch spring assembled improperly	Replace defective part(s) Adjust lensholder stop pin Reassemble properly
f. Projection lens binds	Lens locking screw binding on lens housing Rack and pinion damaged	Reassemble screw properly Replace defective part(s)
g. Projection lens loose	Pinion retainer worn or damaged	Replace defective part(s)

INSTA LOAD/XL
2200 SERIES



CIRCUIT BOARD TEST POINTS