

FILM-TECH

THE INFORMATION CONTAINED IN THIS ADOBE ACROBAT PDF FILE IS PROVIDED AT YOUR OWN RISK AND GOOD JUDGMENT.

THESE MANUALS ARE DESIGNED TO FACILITATE THE EXCHANGE OF INFORMATION RELATED TO CINEMA PROJECTION AND FILM HANDLING, WITH NO WARRANTIES NOR OBLIGATIONS FROM THE AUTHORS, FOR QUALIFIED FIELD SERVICE ENGINEERS.

IF YOU ARE NOT A QUALIFIED TECHNICIAN, PLEASE MAKE NO ADJUSTMENTS TO ANYTHING YOU MAY READ ABOUT IN THESE ADOBE MANUAL DOWNLOADS.

WWW.FILM-TECH.COM

House Light Dimmer Remote Control Instructions

KELMAR #7872 REMOTE CONTROL STATION

The #7872 Remote Control Station offers full remote control for both the Kelmar Deluxe House, House Light, and Encore Lighting Systems. It can be conveniently mounted on a standard 4" x 4" electrical box with up to eight stations wired in parallel. All the interface wiring is low voltage, and under full load draws less than .2 of an amp. The control logic is grouped as follows.

Interface Wiring Schedule

Remote Station Term. #	Function	Deluxe House Term. #	House Light Term. #	Encore Term. #
1	Up LED	1	1	1
2	Mid LED	2	2	2
3	Low LED	3	3	3
4	Down LED	4	4	4
5	Up SWITCH	5	5	5
6	Mid Switch	6	6	6
7	Low Switch	7	7	7
8	Down Switch	8	8	8
9	Control Common	9	9	9
10	By-Pass LED's	10	N/C	N/C
11	By-Pass OFF	11	N/C	11
12	By-Pass ON	12	N/C	10
13	By-Pass Common	13	N/C	N/C