

# Film-Tech

The information contained in this Adobe Acrobat pdf file is provided at your own risk and good judgment.

These manuals are designed to facilitate the exchange of information related to cinema projection and film handling, with no warranties nor obligations from the authors, for qualified field service engineers.

If you are not a qualified technician, please make no adjustments to anything you may read about in these Adobe manual downloads

[www.film-tech.com](http://www.film-tech.com)



obsolete service code			→ service code → ordering code	obsolete service code			→ service code → ordering code
c	CM 208 201J	P	4822 123 10195				
c	CN 20 EV103M	P	" 123 10196				
c	CP 56K		903/N100K + 2x B1 030 24				
c	CP 6186 EE503X	P	4822 124 70118				
	CR 110 14	P	4822 126 02099				
	CR 110 15	P	" 126 02101				
	CR 110 16	P	" 126 02096				
	CR 110 17	P	" 126 02097				
	CR 120 17		" 126 02102				
	CR 120 18		4822 126 02104				
	CR 120 29	P	" 126 02105				
	CR 120 30	P	" 126 02098				
	CR 120 63	P	" 126 02102				
	CR 120 64	P	" 126 02104				
	CR 120 79	P	4822 126 02104				
	CR 120 80	P	" 126 02102				
	CR 130 05		" 126 02095				
	CR 130 08		" 126 02094				
	CR 130 13		" 126 02103				
	CR 130 24	P	4822 126 02095				
	CR 151 34		" 126 02107				
	CR 151 53	P	" 126 02107				
	CR 161 08	P	" 126 02106				
	CR 186 25		" 276 50074				
	CR 217 72/01	P	4822 333 50085				
	CR 249 64	P	" 421 40005				
	CR 346 18	P	" 498 10014				
	CR 347 21	P	" 303 30047				
	CR 487 06	P	" 256 60053				
	CR 730 07	P	4822 125 20084				

	obsolete service code	→ service code → ordering code		obsolete service code	→ service code → ordering code
	C1 000 01	C1 419 65		C1 004 43	+ 4822 144 30005
	C1 000 02 3	+ 4822 693 50061		C1 004 61	" 144 00427
c	C1 000 17 0	+ " 502 10333	c	C1 050 01	
	C1 000 18	" 146 00365		C1 050 05	C1 708 94
	C1 000 19			C1 050 07	
	C1 000 20			C1 050 12 0	4822 144 00482 +
c	C1 000 22 0	+ 4822 693 50015		" 144 00473	
	C1 000 23	C1 000 22		C1 050 13	
o	C1 000 27 0	+ 4822 502 10334	o	C1 050 15 0	+ 4822 522 30467
	C1 000 32	" 145 00317		C1 050 21	" 144 00473 +
	C1 000 37 0	+ 4822 492 60112		" 144 00474 +	
c	C1 000 38 1	+ " 502 10297		" 144 00475	
	C1 000 41	C1 604 14		" 144 00456	
c	C1 000 43 0	+ 4822 522 30401	o	C1 050 24	P
o	C1 000 47 0	+ " 535 70017		C1 050 25 0	+ 4822 492 50064
	C1 000 50 0	+ 4822 535 80015		C1 050 27	C1 708 87
c	C1 000 52 0	+ " 522 30058		C1 050 35	
c	C1 000 53 0	+ " 522 30059	o	C1 050 37	+ 4822 530 20045
	C1 000 54 1	+ " 522 30061	c	C1 050 43 0	+ 4822 522 30402
c	C1 000 56 0	+ " 522 30062		C1 050 53 0	89 047 02
	C1 000 57 0	+ 4822 693 50031		C1 050 56	C1 708 87
c	C1 000 60 0	+ " 520 10132	o	C1 050 59	
	C1 000 64 5	" 145 00318		C1 050 66	+ 4822 466 60087
	C1 000 67			C1 050 71	
	C1 000 68			C1 050 74 0	+ 4822 271 30008
	C1 000 73		c	C1 050 88	+ " 528 20055
c	C1 000 78 0	+ 4822 535 40003		C1 051 04	
	C1 000 82 1	+ " 525 60001	c	C1 051 05	
c	C1 000 85 0	+ " 492 40026		C1 051 18 0	+ 4822 502 10188
	C1 000 86			C1 103 31	4822 144 00478
c	C1 000 88 0	+ 4822 532 10004		C1 103 62	
	C1 000 90	C1 000 78		C1 103 63	
	C1 000 91			C1 103 64	
	C1 000 95	C1 608 72		C1 103 65	
c	C1 000 96 0	+ 4822 380 20012		C1 103 66	
	C1 001 12 1	+ " 522 30063		C1 103 67	
	C1 001 18		c	C1 104 89	
c	C1 002 15 0	+ 4822 522 30064		C1 105 02 0	+ 4822 535 70003
c	C1 002 91 0	+ " 361 40004		" 144 00477	
c	C1 003 14 0	+ " 463 10011	o	C1 105 06	P
c	C1 003 29 0	+ " 525 60002		C1 105 07 0	+ 4822 532 50027
	C1 003 32	C1 004 02		C1 105 08	C1 105 07
c	C1 004 20	+ 4822 276 20021		C1 105 12	4822 144 00476
o	C1 004 21	+ " 276 20022		" 522 30065	
c	C1 004 42	+ " 146 40006	c	C1 105 15 0	+ C1 105 02
				C1 105 17	+ 4822 535 90007
				C1 105 24	

obsolete service code		→ service code → ordering code	obsolete service code		→ service code → ordering code
C1 105 25			C1 202 64	-	4822 492 50345
C1 106 77			C1 202 69	-	89 181 03/20
C1 106 79			C1 202 70	-	WT 475 95/01
C1 106 80		C1 050 74	C1 202 79	-	970/2x350
C1 106 86			C1 202 83 0	-	4822 140 50011
C1 108 06			C1 202 85 0	-	4822 152 20021
C1 108 20 0	-	4822 358 50004	C1 202 86 0	-	" 146 20038
C1 109 25	-	" 380 10002	C1 202 87 0	-	" 130 50008
C1 109 26	-	" 381 40008	C1 202 94	-	NK 164 62
C1 110 94	-	" 256 90009	C1 202 95 0	-	4822 156 20093
C1 110 98	P	4822 144 00424	C1 202 97 0	-	4822 346 10035
C1 111 09	P	" 144 00425	C1 202 99 0	-	" 156 10082
C1 112 59	-	" 321 30037	C1 203 01 0	-	" 157 30052
C1 112 68	-	" 492 50065	C1 203 02 0	-	" 146 30015
C1 113 22	-	" 358 50005	C1 203 03 0	-	" 140 30001
C1 113 24	-	4822 358 50006	C1 203 10	-	4822 157 30053
C1 200 00 0	-	" 256 30036	C1 203 12	-	
C1 200 11		996/4x10	C1 203 20	-	4822 276 10003
C1 200 20			C1 203 21	-	" 276 10004
C1 200 30 2			C1 203 39		
C1 200 31 2			C1 203 40		
C1 200 41			C1 203 52 0	-	4822 525 60059
C1 200 67 0	-	4822 532 50331	C1 203 68 0	-	" 466 40045
C1 200 75			C1 203 72 0	-	" 532 40021
C1 200 76			C1 203 84		
C1 200 77			C1 203 85 0	-	4822 265 40002
C1 201 40 0	-	4822 158 30005	C1 203 86 0	-	" 267 50002
C1 201 41		NK 164 96	C1 203 99		C1 210 92
C1 201 62			C1 204 34 0	-	4822 450 30003
C1 202 11 0	-	4822 281 30017	C1 204 35		C1 204 34
C1 202 19		R6 000 04 + 4822 136 00046 for EL 3500 R6 000 04 + 4822 136 00046 for EL 3590	C1 204 48 0	-	4822 520 30124
C1 202 21		R6 000 04 + 4822 136 00046	C1 204 55 0	-	" 492 30084
C1 202 36		C1 210 61	C1 204 67		
C1 202 37		C1 212 17	C1 205 09 0	-	4822 249 40001
C1 202 41 0	-	4822 281 30018	C1 205 18		SZS 1127/300A
C1 202 42 0	-	4822 535 90180	C1 205 20		SZS 1700/001/CYC/A
C1 202 45 0	-	" 525 60037	C1 205 48		
C1 202 53 0	-	" 535 50002	C1 205 77		SZB 1700/001/MMM/A
C1 202 56 0	-	" 535 50003	C1 205 94		4822 168 00612
C1 202 61 0	-	" 535 70102	C1 206 32		937/B1x5,8
			C1 206 33		836/B1x5,8
			C1 206 34		C1 205 09
			C1 206 44	-	4822 413 30166
			C1 206 71	-	" 535 50004
			C1 207 60		

obsolete service code	→ service code → ordering code	obsolete service code	→ service code → ordering code
C1 207 62		C1 310 84	
C1 207 67	WT 861 65	C1 310 94	+ 4822 522 30066
C1 208 00	- 4822 249 30012	C1 311 29	C1 904 03
C1 208 02	- " 249 20012	C1 311 32	C1 904 28
C1 208 05	C1 210 06	C1 311 33	- 4822 451 10004
C1 208 06	C1 210 06	C1 311 49	- 4822 404 50011
C1 209 46	- 4822 277 10095	C1 311 51	" 214 00968
C1 210 06	- " 249 40028	C1 311 52	- " 492 30085
C1 210 44	- " 502 10335	C1 311 55-1	
C1 210 61	- " 466 80145	C1 311 69	C1 313 38 +
C1 210 62	C1 212 17		2x C1 313 39
C1 210 92	- 4822 532 40064	C1 312 10	
C1 211 60	C1 210 61	C1 313 30	
C1 211 71	- 4822 530 20087	C1 313 31	
C1 211 84	- " 466 40003	C1 313 38	- 4822 249 30016
c C1 211 85	R6 000 04-S	C1 313 39	- " 249 10004
	4822 136 00046-S	C1 313 50	C1 313 77
C1 211 98	C1 211 99	C1 313 76	P 4822 144 00455
c C1 211 99	4822 164 00701	C1 313 77	+ " 249 10022
C1 212 12	- " 466 80058	C1 313 80	C1 313 77
C1 212 17	- " 463 10018	C1 314 40	- 4822 249 10005
C1 212 20	- 4822 529 10072	C1 314 69	22 416 20
C1 212 26	+ " 532 60214	C1 315 57	- 4822 492 60113
C1 212 40	- " 413 30167	C1 315 58	- " 535 80081
C1 212 43		C1 315 83	- " 404 50001
C1 212 47	- 4822 525 60093	C1 315 87	- " 360 40001
C1 212 53	- 4822 404 50009	C1 315 89	C1 316 63
C1 212 57	- " 535 80079	C1 316 57	
C1 212 60	R6 041 74	C1 316 63	- 4822 310 30057
C1 212 61	4822 164 00806	C1 317 30	- " 535 50033
C1 212 62	R6 041 74	C1 317 37	
C1 212 69	- 4822 520 10021	C1 317 46	- 4822 525 60039
C1 213 00	NK 174 50	C1 317 56	- " 462 70373
C1 213 06	NK 164 92	C1 317 57	- " 310 20019
C1 213 07	NK 164 90	C1 317 92	- " 404 50001
C1 303 27 2	22 515 14	C1 317 93	- " 525 60082
C1 303 29 3	- 4822 278 90077	C1 318 05	- 4822 492 60114
C1 303 40 1	- " 278 90076	C1 318 34	- " 144 00459
C1 304 08		C1 318 38	- " 525 20001
C1 304 12		C1 318 39	P " 122 00001
C1 304 13		C1 318 40	- " 535 30001
C1 304 14	- 4822 278 90075	C1 319 01	- 4822 532 60001
C1 310 46	- " 290 40015	C1 319 58	- " 144 00001
C1 310 76	- " 525 60038	C1 319 70	- " 525 20001
C1 310 83		C1 319 71	P " 144 00457

	obsolete service code	→ service code → ordering code		obsolete service code	→ service code → ordering code
C	C1 400 11 1	+ 4822 522 30067		C1 403 44	
	C1 400 64	992/M5		C1 403 46	
	C1 400 74	C1 408 60		C1 403 48 0	+ 4822 380 30012
C	C1 400 94 0	+ 4822 535 70174		C1 403 57	
	C1 400 97			C1 403 59 0	+ 4822 522 30068
	C1 400 98			C1 403 61 0	+ 4822 522 30069
	C1 400 99			C1 403 62	C1 406 90
	C1 401 34			C1 403 66 0	+ 4822 361 50002
	C1 401 40			C1 403 67	C1 751 56
	C1 401 52			C1 403 91	R 302 KA/235
	C1 401 63			C1 404 22 0	+ 4822 535 70021
	C1 401 65			C1 404 23 0	+ " 505 10048
	C1 401 66			C1 404 25 0	+ " 535 90121
	C1 401 67			C1 404 34 0	+ " 535 70022
	C1 401 68			C1 404 54	
	C1 402 38	C1 408 57		C1 404 64 0	+ 4822 463 50023
	C1 402 41	C1 408 57		C1 404 74	C1 404 75
	C1 402 61	P5 635 74/977		C1 404 75 0	+ 4822 693 50018
	C1 402 62 1	+ 4822 463 50002		C1 404 80	22 437 99 1
C	C1 402 64 1	+ " 502 10189		C1 404 90	C1 612 65
	C1 402 66	P 4822 144 00471		C1 404 91 0	+ 4822 358 10004
C	C1 402 71	+ " 535 90183		C1 404 92	
	C1 402 72			C1 404 93	
C	C1 402 79 0	+ 4822 466 60056		C1 405 07 0	+ 4822 522 30446
	C1 402 90 0	+ " 463 10013		C1 405 19	C1 405 07
	C1 402 94	C1 402 62 +		C1 405 22	C1 405 07
		C1 402 71 +		C1 405 46 0	+ 4822 466 90078
		A9 866 73		C1 405 48 0	+ " 325 30003
	C1 402 98			C1 405 64	C1 660 58
	C1 403 00			C1 405 69	
	C1 403 01	C1 403 61 +		C1 405 80	C1 405 48
		22 417 03		C1 405 97	C1 402 90
		22 414 34 +		C1 406 09	
		22 444 30 +		C1 406 27	+ 4822 404 50086
		22 444 40 +		C1 406 65 0	+ " 525 30004
		22 414 02 +		C1 406 69 0	+ 4822 492 60442
		C1 400 11		C1 406 90 0	+ " 404 50012
	C1 403 29			C1 406 97 0	+ " 535 80082
	C1 403 31			C1 407 01 0	+ " 535 80083
	C1 403 32			C1 407 04 0	+ " 404 50071
	C1 403 33			C1 407 05 0	
	C1 403 34			C1 407 06 0	
	C1 403 35			C1 407 09	
	C1 403 36			C1 407 11 0	+ 4822 535 50005
	C1 403 40			C1 407 13 0	+ " 535 50006
	C1 403 41				
	C1 403 42				

x TO ORDER FROM C.D. E.L.A.

obsolete service code		→ service code → ordering code	obsolete service code		→ service code → ordering code
c	C1 407 39	C1 408 37	c	C1 409 97 0	† 4822 463 50006
c	C1 407 43	† 4822 380 30013	c	C1 409 98	† " 522 30434
	C1 407 48			C1 410 25 0	† " 463 10005
c	C1 407 49 0	† 4822 535 80084	c	C1 410 28 0	† " 323 20065
	C1 407 63	C1 407 04	c	C1 410 29 0	† " 256 20021
c	C1 407 65 0	† 4822 278 90084	c	C1 410 30	† 4822 463 50024
c	C1 407 66 0	† " 362 40012	c	C1 410 31 0	† " 404 50091
c	C1 407 67 0	† " 256 20012	c	C1 410 32	† " 522 30071
	C1 407 68	C1 668 27	c	C1 410 33 0	† " 522 30072
c	C1 407 75 0	† 4822 255 20006	c	C1 410 34 0	† " 522 30073
	C1 407 76		c	C1 410 35 0	† 4822 522 30074
c	C1 407 79 0	† 4822 503 40013	c	C1 410 36 0	† " 522 30075
c	C1 407 82 0	† " 503 40006	c	C1 410 37 0	† " 522 30076
c	C1 407 84 0	† " 503 40007	c	C1 410 38 0	† " 522 30077
c	C1 407 85 0	† " 520 20003	c	C1 410 39 0	† " 522 30078
	C1 407 89		c	C1 410 40 0	† 4822 522 30616
	C1 407 92	C1 407 75		C1 410 41	C1 412 30
c	C1 407 94 0	† 4822 381 20012		C1 410 77	
	C1 408 02 0	x 6844	c	C1 410 90	† 4822 345 20001
c	C1 408 09 0	† 4822 522 30403		C1 410 91	C1 904 81
c	C1 408 10 0	† 4822 522 30404		C1 410 92	22 542 92
	C1 408 15	C1 755 19	c	C1 411 07	† 4822 492 50067
c	C1 408 37	† 4822 380 30011	c	C1 411 09	† " 480 50033
	C1 408 51	C1 904 28	c	C1 411 10	† " 455 50001
c	C1 408 54 0	† 4822 310 20022	c	C1 411 80	† " 526 40026
	C1 408 55	C1 904 03	c	C1 411 87	† 4622 492 60576
	C1 408 56 0	C1 408 56 1		C1 411 90	† " 693 50026
c	C1 408 56 1	† 4822 395 80003	c	C1 411 95	† " 450 60014
c	C1 408 57 0	† " 451 10021	c	C1 411 97	† " 466 60015
	C1 408 58	C1 660 71	c	C1 411 99	† " 450 60015
	C1 408 59	C1 660 71	c	C1 412 00	4822 492 30473
c	C1 408 60 0	† 4822 310 20023		C1 412 01	† " 268 20024
c	C1 408 61 0	† " 535 70023		C1 412 04	† " 532 50059
	C1 408 67	C1 408 56 1		C1 412 05	† " 532 50061
	C1 408 92 0	† 4822 463 10004	c	C1 412 06	C1 412 25
c	C1 408 99 0	† 4822 463 50004		C1 412 30	
c	C1 409 63 0	† " 463 50005		C1 412 25	† 4822 381 40007
c	C1 409 67 0	† " 256 20025	c	C1 412 30	† " 522 30081
c	C1 409 68 0	† " 256 20017	c	C1 412 38	† " 404 50072
c	C1 409 69 0	† " 381 80014		C1 412 41	C1 412 38
c	C1 409 70 0	† 4822 381 40014	c	C1 412 47	† 4822 404 50071
c	C1 409 71 0	† " 256 20002		C1 412 50	† " 381 10001
	C1 409 72		c	C1 412 63	† " 459 20069
c	C1 409 73	† 4822 361 30062	c	C1 412 64	† " 459 20032
c	C1 409 74 0	† " 253 40022		C1 412 67	† " 268 10002

x TO ORDER FROM C.D.LIGHT



obsolete service code		→ service code → ordering code	obsolete service code		→ service code → ordering code
c	C1 412 73 3	+ 4822 532 30108	c	C1 419 49	C1 420 00
	C1 412 74	+ " 480 50038	c	C1 419 50	+ 4822 532 50065
c	C1 412 75	+ " 532 50062	c	C1 419 53	+ " 492 50068
	C1 412 76	C1 417 70 +	c	C1 419 55	+ " 381 10109
		C1 417 71		C1 419 64	C1 421 25
	C1 413 12	C1 425 30			
c	C1 413 35	+ 4822 532 50063	c	C1 419 65	+ 4822 381 80006
				C1 419 78	
	C1 413 54	NF 162 38	c	C1 420 00	+ 4822 530 30015
	C1 413 56	+ 4822 381 80009	c	C1 420 21	+ " 525 60041
	C1 413 65	+ " 532 50064		C1 420 56	
c	C1 413 73	+ " 492 30086			
	C1 413 82	C1 426 33		C1 420 66	
				C1 420 67	
	C1 414 01	C1 425 30		C1 420 68	
c	C1 414 36	+ 4822 395 50031		C1 420 98	P 4822 144 00463
c	C1 414 73	+ " 381 80011		C1 421 19	F " 144 00422
	C1 414 98	+ " 492 60577			
	C1 415 07	C1 426 04 +	c	C1 421 25	+ 4822 532 50066
		C1 425 29	c	C1 422 00	+ " 522 30083
				C1 422 90	F " 144 00407
	C1 415 13	C1 417 60		C1 423 32	
c	C1 415 26	+ 4822 256 80006	c	C1 423 33	" 522 30747
	C1 415 33	+ " 277 10014			
	C1 415 42	+ " 395 50051		C1 423 34	" 522 30746
c	C1 415 61	+ " 380 30008	c	C1 423 50	P 4822 144 00423
				C1 423 63	P " 144 00449
	C1 415 77 1	+ 4822 463 50021	c	C1 423 64	+ " 381 80007
c	C1 415 78	+ " 281 30028		C1 423 86	
c	C1 415 79	+ " 362 10067			
	C1 415 80	C1 412 67 +		C1 423 90	P 4822 144 00452
		P4 635 55/343		C1 424 05	F " 144 00448
	C1 415 81	C1 425 29		C1 424 17	P " 144 00479
				C1 424 29	P " 144 00454
c	C1 416 11	+ 4822 401 10129		C1 424 55	P " 144 00451
c	C1 416 44	+ " 492 60115			
	C1 416 58	+ " 146 00396		C1 425 05	F 4822 144 00409
	C1 416 73	+ " 360 60027		C1 425 29	+ " 256 90034
c	C1 417 11	+ " 219 80029	c	C1 425 30	+ " 271 10005
				C1 425 34	F " 144 00458
	C1 417 23	+ 4822 381 80004		C1 425 80	F " 144 00464
c	C1 417 44	+ " 381 80005			
c	C1 417 60	+ " 693 50046		C1 426 01	P 4822 145 00316
c	C1 417 63	+ " 528 20011		C1 426 04	+ " 256 90026
c	C1 417 64	+ " 535 70024		C1 426 20	P " 144 00453
			c	C1 426 33	+ " 219 80001
	C1 417 70	+ 4822 535 90122		C1 426 61	F " 144 00473
c	C1 417 71	+ " 532 20084			
	C1 418 45	49 870 30		C1 426 63	P 4822 144 00481
c	C1 418 62	+ 4822 535 70025		C1 426 66	P " 144 00474
c	C1 418 64	+ " 522 30082		C1 426 67	P " 144 00482
				C1 427 00	P " 144 00465
c	C1 419 39	+ 4822 492 30087		C1 427 59	F " 144 00466

obsolete service code		→ service code → ordering code	obsolete service code		→ service code → ordering code
C1 427 92	P	4822 144 00411	c C1 504 54 0	+	4822 535 80085
C1 428 56	P	" 144 00472	c C1 504 57	+	" 265 40003
C1 428 60	P	" 144 00467	C1 504 61		
C1 428 69	P	" 144 00468	C1 504 62		
C1 431 06	P	" 144 00475	C1 504 63		
C1 431 66	P	4822 144 00483	C1 504 64		
C1 500 16		C1 668 27	c C1 504 68 0	+	4822 525 60003
C1 500 17		C1 668 27	C1 505 08		
C1 500 19		C1 500 25	c C1 505 09 0	+	4822 520 10017
C1 500 23			c C1 505 85 0	+	" 361 50089
c C1 500 25 0	+	4822 500 10019	c C1 505 88 0	+	4822 525 60064
C1 500 33		970/3x250	C1 506 68		C1 515 55
C1 500 38		R 302 KA/235	c C1 507 00 0	+	4822 157 30054
c C1 500 39 0	+	4822 256 20013	c C1 507 01 0	+	" 145 10002
C1 500 46			C1 507 02		C1 510 14
C C1 500 53 0	+	4822 532 50067	c C1 507 03 0	+	4822 130 50146
C1 500 61			c C1 507 06 0	+	" 152 20022
C1 500 63			c C1 507 07 0	+	" 146 20039
C1 500 64			c C1 507 08 0	+	" 146 40007
C1 500 65			c C1 507 09 0	+	" 152 20023
C1 500 70			C1 507 19		
C1 500 73		ND 964 31	c C1 507 20 0	+	4822 140 50012
C1 500 76		4822 220 00364	C1 507 21		NK 174 02
		" 144 00472	C1 507 24		NK 173 98
c C1 500 83	+	4822 277 10015	C1 507 26		NK 174 06
C1 501 04		C1 608 78			
c C1 501 05 1	+	4822 528 80137	c C1 507 27 0	+	4822 142 50006
C1 501 15			c C1 507 28 0	+	" 140 40037
C1 501 33		C1 604 13	C1 508 00		NK 164 82
C1 501 39			c C1 508 01 0	+	4822 130 50145
c C1 501 41	+	4822 381 20016	C1 508 02 0	+	" 146 40008
c C1 501 44 1	+	4822 693 50024	c C1 508 03 0	+	4822 152 20024
c C1 501 47 0	+	" 532 30154	c C1 508 05	+	" 105 30001
c C1 501 49 0	+	" 492 40027	c C1 509 24 0	+	" 395 50029
C1 502 34			c C1 509 33	+	" 271 30066
C1 502 60			C1 509 41		
c C1 503 11 0	+	4822 528 70117	C1 509 42		
C1 503 41			C1 509 43		
C1 503 71			C1 509 44		
c C1 503 78 0	+	4822 281 30001	C1 509 45		C1 509 33
C1 503 93			c C1 509 47 0	+	4822 281 30043
					89 18/03/20
C1 504 10			c C1 509 58	+	" 358 30041
c C1 504 15	+	4822 267 50003	c C1 509 59 0	+	NK 173 96
c C1 504 17 0	+	" 468 80153	C1 510 00		NK 173 90
C1 504 37		NK 164 94	C1 510 01		NK 173 90
			C1 510 02		NK 173 90

obsolete service code		→ service code → ordering code	obsolete service code		→ service code → ordering code
	C1 510 03	NK 174 00		C1 602 30	C1 406 90
	C1 510 04	NK 173 94	c	C1 602 35 0	+ 4822 525 60009
c	C1 510 07 0	+ 4822 140 50013		C1 602 41	
c	C1 510 09 0	+ " 152 20025		C1 602 86	
	C1 510 10	NK 174 04	c	C1 602 96 0	+ 4822 381 10098
c	C1 510 13 0	+ 4822 156 200 94	c	C1 602 97 0	+ 4822 381 10099
c	C1 510 14 0	+ " 145 50002	c	C1 602 98 0	+ " 381 10101
c	C1 511 07 0	+ " 281 30002		C1 603 35	
c	C1 511 08 0	+ " 281 30003		C1 603 37	NA 908 58
	C1 511 10	C1 512 76		C1 603 47	C1 604 15
	C1 511 16	T9 046 17	c	C1 603 55 0	+ 4822 255 20007
c	C1 511 50 0	+ 4822 404 50014	c	C1 603 64 0	+ " 395 80008
c	C1 511 53 0	+ " 479 30017	c	C1 603 77 0	+ " 528 20012
	C1 511 77 0	- " 525 60004		C1 603 92	
c	C1 511 81 0	+ " 535 50007		C1 604 03 0	+ 4822 358 20007
	C1 511 92	C1 512 14		C1 604 13 0	+ 4822 525 60011
c	C1 512 09 0	+ 4822 525 60005		C1 604 14	+ " 525 60012
c	C1 512 14 0	+ " 528 90021		C1 604 15 0	+ " 525 60013
c	C1 512 71 0	+ " 152 20026		C1 604 24	C1 612 65
	C1 512 72	NK 164 42		C1 604 30	A9 866 95
c	C1 512 76 0	+ 4822 535 90149		C1 604 31	C1 608 11
	C1 513 73	NK 173 76		C1 604 34	C1 612 65
c	C1 513 92 0	+ 4822 525 60006		C1 604 40	
c	C1 513 95	+ " 525 60007	c	C1 604 54 0	+ 4822 381 40003
	C1 514 05		c	C1 604 60 0	+ " 381 10089
c	C1 514 10 0	+ 4822 525 60008	c	C1 605 03 0	+ 4822 358 10037
	C1 514 11	WT 496 11		C1 605 04	22 542 92
	C1 514 14		c	C1 605 32 0	+ 4822 358 10005
	C1 514 15		c	C1 605 46 0	+ " 525 60042
	C1 514 16		c	C1 605 48 0	+ " 492 60116
	C1 514 17		c	C1 605 52 0	+ 4822 503 40008
c	C1 514 54 0	+ 4822 144 40004	c	C1 605 57 0	+ " 520 10024
	C1 514 80	R6 000 04 +		C1 605 58	
		4822 136 00046	c	C1 605 66 0	+ 4822 492 50069
c	C1 515 54 0	+ " 273 40000	c	C1 605 72 0	+ " 535 80086
	C1 601 32			C1 605 74 0	+ 4822 492 40029
	C1 601 33		c	C1 605 75 0	+ " 503 40012
c	C1 601 56 0	+ 4822 264 40033	c	C1 605 89 0	+ " 492 40031
	C1 601 67	977/M05	c	C1 605 98 0	+ " 535 80298
	C1 601 71		c	C1 605 99 0	+ " 506 40002
	C1 602 00 0	+ 4822 356 20001		C1 606 10 0	+ 4822 535 80087
c	C1 602 10 0	+ " 492 40028	c	C1 606 13	+ " 525 30001
	C1 602 17	" 077 00104		C1 606 14	C1 704 72
	C1 602 21			C1 606 15	
	C1 602 26		c	C1 606 16 0	+ 4822 492 40032

obsolete service code		→ service code → ordering code	obsolete service code		→ service code → ordering code
c	C1 606 17	+ 4822 463 50013	c	C1 609 03	
	C1 606 18	C1 607 29		C1 609 04	
	C1 606 19	C1 607 29		C1 609 05	
c	C1 606 28 0	+ 4822 503 40014	c	C1 609 07	+ 4822 525 60074
c	C1 606 29	+ " 525 30002		C1 609 11	
	C1 606 34		c	C1 609 23	+ 4822 515 20015
	C1 606 45	C1 607 30	c	C1 609 24	+ " 522 30088
	C1 606 46	C1 607 30	c	C1 609 28	+ " 522 30089
	C1 606 61	C1 313 38 +	c	C1 609 30	+ " 535 50009
		2x C1 313 39	c	C1 609 42	+ " 492 60117
c	C1 606 79	+ 4822 219 80004	c	C1 609 66	4822 463 30021
c	C1 606 88 0	+ 4822 256 80005		C1 609 70	C1 610 55
c	C1 606 89 0	+ " 310 20024		C1 609 79	C1 610 55
c	C1 606 93 0	+ " 463 30002	c	C1 610 04 2	+ 4822 532 50001
			c	C1 610 13	+ " 466 40006
c	C1 606 95 0	+ 4822 463 30003	c	C1 610 15	+ 4822 528 80093
	C1 607 15 0	+ " 522 30084		C1 610 21	+ " 273 20007
c	C1 607 17 0	+ " 404 50015		C1 610 27	+ " 525 60083
c	C1 607 18 0	+ " 404 50016		C1 610 36	+ " 380 20011
	C1 607 20	+ " 145 00317	c	C1 610 40 B	+ " 532 80103
	C1 607 29 0	+ 4822 463 10006		C1 610 53	+ 4822 281 30004
	C1 607 30 0	+ " 463 10007		C1 610 55	+ " 249 30001
	C1 607 31	89 181 03/20	c	C1 610 57	+ " 463 30004
c	C1 607 41	+ 4822 522 30085		C1 610 75	+ " 146 00365
	C1 607 44	P " 145 00351		C1 610 87	
	C1 607 45		c	C1 610 89 B	+ 4822 249 30002
	C1 607 69	P 4822 145 00307		C1 610 93	+ " 145 00355
c	C1 607 73 0	+ " 528 20013	c	C1 610 95	+ " 310 20025
	C1 607 74 0	+ " 522 30086		C1 611 29	P " 145 00319
	C1 607 75	C1 607 74		C1 611 43	P " 145 00321
c	C1 607 76 0	+ 4822 522 20085		C1 611 44	4822 145 00348 +
	C1 607 77	P 4822 522 30565			145 00349
	C1 607 80	C1 610 15	c	C1 611 50	+ " 693 50036
	C1 607 85	C1 610 89		C1 611 51	P " 145 00323
	C1 607 93			C1 611 85	
	C1 608 10			C1 612 19	P 4822 145 00325
c	C1 608 11	+ 4822 693 50048		C1 612 24	P 4822 145 00326
	C1 608 59			C1 612 25	P " 145 00327
c	C1 608 72 0	+ 4822 535 50008		C1 612 28	P " 145 00315
c	C1 608 78	+ " 515 20006		C1 612 43	P " 145 00328
	C1 608 87	+ 4822 358 20011	c	C1 612 65	+ " 361 60068
	C1 608 97	+ " 451 10005		C1 612 73	P 4822 145 00329
c	C1 608 94	+ " 451 10006		C1 612 99	P " 145 00331
	C1 608 96	+ " 451 10007		C1 613 51	P " 145 00305
c	C1 609 01			C1 613 55	P " 145 00332

obsolete service code		→	service code		→	ordering code		obsolete service code		→	service code		→	ordering code	
C1 613 65	P	4822	145	00333	c	C1 661 40	+	4822	526	20002					
C1 613 88	P	"	145	00314	c	C1 661 41	+	"	463	50018					
C1 614 13	P	"	145	00334	c	C1 661 42	+	"	463	50019					
C1 614 15	P	"	145	00335	c	C1 661 43	+	"	361	20021					
C1 614 19	P	"	145	00336	c	C1 661 44	+	"	362	40015					
C1 614 25	P	4822	145	00337		C1 661 45		C1 666 39							
C1 614 41	P	"	145	00338	c	C1 661 46	+	4822	463	50001					
C1 614 52	P	"	145	00339	c	C1 661 47	+	"	310	30002					
C1 614 85						C1 661 48		C1 666 31 +							
C1 614 88		4822	145	00341				A9 031 83							
C1 614 89	P	4822	145	00342	c	C1 661 49	+	4822	404	50101					
C1 615 03	P	"	145	00343	c	C1 661 50	+	4822	253	40021					
C1 615 04	P	"	145	00344		C1 661 51		C1 661 46							
C1 615 06	P	"	145	00345	c	C1 661 52	+	4822	693	50021					
C1 615 10	P	"	145	00346	c	C1 661 53	+	"	693	50045					
C1 615 20		4822	146	00395	e	C1 661 54	+	"	256	20037					
C1 615 21	P	"	145	00318	c	C1 661 55	+	4822	256	20036					
C1 615 22	P	"	145	00317		C1 661 56		C1 666 38							
C1 615 41		"	145	00341	c	C1 661 57	+	4822	693	50041					
C1 615 53	P	"	144	00469	c	C1 661 58	+	"	693	50044					
C1 615 62	P	4822	145	00349	c	C1 661 59	+	"	693	50043					
C1 615 63	F	"	145	00348	c	C1 661 60	+	4822	401	10359					
C1 660 28	+	"	404	50013	e	C1 661 66	+	"	404	50083					
C1 660 43		C1 667 07			e	C1 662 28	+	"	492	50071					
C1 660 44 0	+	4822	532	50347	e	C1 662 40	+	"	520	40007					
C1 660 58 0	+	4822	256	20003	c	C1 662 53	+	"	404	50099					
C1 660 59						C1 662 65									
C1 660 66 0	+	4822	532	20249	c	C1 662 66	+	4822	459	20033					
C1 660 71 0	+	"	522	30459	c	C1 662 77	+	"	463	50008					
C1 660 77	+	"	361	20003	c	C1 662 86	+	"	380	30014					
C1 660 78		T9 048 71			c	C1 663 08	+	"	256	20001					
C1 660 93	+	4822	401	10037	c	C1 663 10	+	4822	256	20004					
C1 661 00	+	"	522	30091	c	C1 663 12	+	"	535	80088					
C1 661 07 0	+	"	361	30057	c	C1 663 13	+	"	492	50072					
C1 661 25	+	"	256	20014	e	C1 663 17	+	"	466	60067					
C1 661 26	+	4822	256	20015	c	C1 663 20	+	"	256	20011					
C1 661 31 0	+	"	362	40013	c	C1 663 27	+	4822	463	50009					
C1 661 32	+	"	361	10047	c	C1 663 45	+	"	492	60118					
C1 661 33	+	"	362	40014	c	C1 663 91	+	"	381	10004					
C1 661 34	+	"	492	30327	c	C1 663 92									
C1 661 35	+	4822	522	30092	c	C1 663 98	+	4822	466	60109					
C1 661 36	+	"	256	20022		C1 664 12		C1 666 96							
C1 661 37	+	"	256	20023		C1 664 87									
C1 661 38	+	"	526	40007		C1 666 03		AD 5050/22							
C1 661 39	+	"	530	20107	c	C1 666 29	+	4822	256	20038					

obsolete service code		→	service code ordering code		obsolete service code		→	service code ordering code	
c	C1 666 30	+	4822	256 20009	C1	701 38		C1	612 65
c	C1 666 31	+	"	480 30038	C1	701 49			
	C1 666 32	P	"	145 00308	C1	701 53			
c	C1 666 34	+	"	466 80131	C1	701 55			
c	C1 666 35	+	"	253 40013	C1	701 57			
	C1 666 37		C1	661 33	C1	701 58		C1	610 40
c	C1 666 38	+	4822	530 20003	C1	701 61			
c	C1 666 39	+	"	450 60052	C1	701 71			
c	C1 666 40	+	"	463 50003	c	C1 701 75 0	+	4822	520 10103
c	C1 666 41	+	"	310 30041	C1	701 81	P	"	146 00361
c	C1 666 42	+	4822	310 30039	c	C1 701 82 1	+	4822	404 60026
c	C1 666 44	+	"	256 20024	C1	701 83			
c	C1 666 45	+	"	362 20005	C1	701 85	P	4822	146 00359
c	C1 666 46	+	"	693 50042	C1	701 86			
c	C1 666 96	+	"	280 80001	c	C1 701 88 3	+	4822	520 10086
c	C1 667 07	+	4822	463 50022	C1	701 89			
c	C1 667 47	+	"	525 60014	C1	701 92			
	C1 668 27	+	"	256 20006	C1	701 94			
c	C1 669 52	+	"	395 60002	C1	701 95			
c	C1 669 57	+	"	361 30063	C1	702 00			
	C1 670 22				C1	702 02 3	+	4822	463 40006
	C1 670 31	P	4822	145 00309	C1	702 03 2	+	"	466 80077
	C1 670 32		"	145 00313	C1	702 10			
	C1 700 00				c	C1 702 11 0	+	4822	492 40033
	C1 700 03				c	C1 702 13 0	+	"	525 60043
	C1 700 04				C1	702 26	P	4822	146 00357
c	C1 700 09 0	+	4822	358 30035	C1	702 27			
	C1 700 10 0	+	"	358 30036	c	C1 702 28			
c	C1 700 13 0	+	"	525 60015	C1	702 30			
c	C1 700 14 0	+	"	525 60016	C1	702 31			
c	C1 700 15 0	+	4822	525 60017	C1	702 38			
	C1 700 71 0	+	"	463 10014	C1	702 40			
	C1 700 74		C1	610 95	C1	702 67			
	C1 700 75				c	C1 702 74			
	C1 700 78		C1	610 95	c	C1 702 75	+	4822	520 10086
	C1 700 87		C1	408 61	C1	703 05			
	C1 701 02				c	C1 703 28 0	+	4822	528 90048
	C1 701 03				C1	703 36		C1	705 42
	C1 701 12		22	416 54	C1	703 37 0	+	4822	522 30093
	C1 701 15				C1	703 38 0	+	"	522 30094
	C1 701 28 0		4822	505 10306	C1	703 43			
	C1 701 30		"	146 00364	c	C1 703 60 0	+	4822	492 60119
	C1 701 31		C1	608 11	c	C1 703 89 0	+	"	492 50073
	C1 701 35		4822	146 00365	C1	703 97		C1	705 42
	C1 701 36		"	146 00364	C1	703 99			

obsolete service code		→ service code → ordering code	obsolete service code		→ service code → ordering code
c	C1 704 01	A3 646 09	c	C1 706 68	
c	C1 704 08	+ 4822 522 306 22	c	C1 706 71	
	C1 704 12	C1 703 37	c	C1 706 84	+ 4822 290 30048
	C1 704 13	C1 703 38	c	C1 706 85	+ " 256 20016
c	C1 704 19 0	+ 4822 492 60121	c	C1 706 86	+ " 256 20005
c	C1 704 24	+ 4822 693 50028	c	C1 706 87	+ 4822 532 20232
c	C1 704 53 0	+ " 535 50011	c	C1 706 88	+ " 532 60217
c	C1 704 56	+ " 361 40012	c	C1 706 96	+ " 321 30064
	C1 704 63		c	C1 707 07	+ " 450 30018
	C1 704 64	4822 146 00347	c	C1 707 15	
	C1 704 65	4822 146 00348	c	C1 707 16	+ 4822 256 20039
	C1 704 66	" 146 00348	c	C1 707 20	+ " 280 60107
	C1 704 67	" 146 00347	c	C1 707 25	+ " 463 50016
	C1 704 68	" 146 00347		C1 707 30	C1 707 48
	C1 704 69	" 146 00347	c	C1 707 36	+ 4822 256 10004
	C1 704 70 1	4822 146 00349	c	C1 707 37	+ 4822 492 60727
	C1 704 70 2	" 146 00349	c	C1 707 42	+ " 525 60065
c	C1 704 71 0	+ " 451 10008	c	C1 707 43	+ " 522 30096
c	C1 704 72 0	+ " 501 40002	c	C1 707 48	+ " 515 20013
	C1 704 74	K 227 LB/14x8	c	C1 708 50	+ " 463 50017
c	C1 704 76 0	+ 4822 358 20002	c	C1 708 59	+ 4822 492 50074
	C1 704 87	" 144 00456+	c	C1 708 63	+ " 525 60018
		22 415 75	c	C1 708 65	+ " 532 50068
	C1 704 88	4822 146 00363	c	C1 708 67	+ " 532 10147
c	C1 705 21 0	+ " 273 50001	c	C1 708 69	+ " 525 60019
17	C1 705 42 0	+ " 522 30095	c	C1 708 72	4822 14400402+144004
	C1 705 52	C1 750 64 +		C1 708 83	" 144 00473 +
		C1 754 65			" 144 00474
c	C1 705 53 3	+ 4822 361 40011	c	C1 708 87	+ " 535 70026
c	C1 705 54	+ " 256 20032	c	C1 708 94	+ " 525 60021
	C1 705 55	C1 750 37	c	C1 750 00 0	+ " 525 20003
	C1 705 56	C1 750 38			
	C1 705 57	C1 704 08		C1 750 03	
	C1 705 58	F 4822 693 50004	c	C1 750 04	
	C1 705 59	F " 693 50005		C1 750 09 0	+ 4822 522 30087
c	C1 705 60	+ " 693 50025		C1 750 10	
c	C1 705 62	+ " 310 20098		C1 750 11 0	+ 4822 522 30098
c	C1 705 76	+ 4822 492 40034	c	C1 750 12 0	+ 4822 522 30099
	C1 705 79		c	C1 750 17	+ " 532 10164
	C1 705 87			C1 750 21	C1 750 53
c	C1 706 08	+ 4822 535 80089		C1 750 24	4822 146 00354
c	C1 706 09	+ " 492 40036		C1 750 25	F " 146 00354
	C1 706 10		c	C1 750 31 0	+ 4822 515 20009
	C1 706 43		c	C1 750 32	+ " 535 50012
	C1 706 64				

c / 705 29

4822 256 10003

obsolete service code		→ service code → ordering code	obsolete service code		→ service code → ordering code
	C1 750 33	C1 750 37 or C1 750 38 or C1 704 08	c	C1 752 74	+ 4822 535 801 84
c	C1 750 34 0	+ 4822 522 30101	c	C1 752 85	+ " 492 60122
c	C1 750 35 0	+ " 522 30102	c	C1 752 87	+ " 358 50007
c	C1 750 37	+ " 693 50027	c	C1 752 88	+ " 358 50008
c	C1 750 38	+ " 693 50034	c	C1 752 89	+ " 358 50009
	C1 750 48	C1 754 65	c	C1 752 90	+ 4822 358 50011
	C1 750 50		c	C1 753 03	+ " 381 10097
c	C1 750 51 0	+ 4822 522 30405	c	C1 753 06	
c	C1 750 57	+ " 522 30103	c	C1 753 15	+ 4822 463 50011
	C1 750 58	C1 750 57	c	C1 753 19	+ " 525 20013
c	C1 750 61 0	+ 4822 360 10014	c	C1 753 20	+ 4822 522 30466
c	C1 750 64	+ " 522 30406	c	C1 753 26	+ " 451 10012
	C1 750 65	P7 635 50	c	C1 753 28	+ " 451 10013
	C1 750 66	C1 754 65	c	C1 753 33	+ " 463 10008
	C1 750 68			C1 753 34	+ " 463 10009
	C1 751 02			C1 753 49	
	C1 751 07		c	C1 753 50	+ 4822 395 80016
	C1 751 08			C1 753 51	P5 635 52/AA
	C1 751 11			C1 753 65	P 4822 146 00318
	C1 751 23	C1 705 62		C1 753 76	P4 635 52
c	C1 751 30 0	+ 4822 503 40009	c	C1 753 79	+ 4822 395 50032
c	C1 751 34 0	+ " 492 50075		C1 753 80	
	C1 751 36	89 180 71/20	a	C1 753 82	C1 754 65
c	C1 752 05	+ 4822 525 30003		C1 753 90	+ 4822 693 50013
c	C1 752 08	+ " 462 50027		C1 753 91	P " 146 00323
	C1 752 12	C1 753 20		C1 754 04	P 4822 146 00351
c	C1 752 13	+ 4822 522 30104	c	C1 754 05	P " 146 00352
c	C1 752 15	+ " 404 50084		C1 754 08	+ " 522 30106
c	C1 752 21	+ " 505 10049	c	C1 754 60	C1 754 65
c	C1 752 25	+ " 522 30105	c	C1 754 65	+ 4822 522 30435
c	C1 752 26	+ 4822 535 70027		C1 754 66	P 4822 146 00355
	C1 752 26	C1 904 29	c	C1 754 70	+ " 535 90008
c	C1 752 31/01	+ 4822 522 30407		C1 754 92	C1 755 26
c	C1 752 42	+ " 520 10025		C1 755 03	P 4822 146 00347
c	C1 752 46/01	+ " 360 40048		C1 755 04	P " 146 00348
c	C1 752 48	+ 4822 502 10356		C1 755 05	P " 146 00349
c	C1 752 54	+ " 451 10009	c	C1 755 06	" 146 00354
c	C1 752 55/01	+ " 451 10011		C1 755 18	+ 4822 463 30005
c	C1 752 60	+ " 492 50076	c	C1 755 19	+ " 463 30006
	C1 752 62	C1 753 33		C1 755 20	+ " 361 50078
	C1 752 64	C1 753 34		C1 755 26	+ " 525 60022
	C1 752 70	P 4822 146 00355		C1 755 61	P " 146 00343
c	C1 752 73	+ " 535 80016		C1 755 61	P 4822 146 00344
				C1 755 82	P " 146 00346



obsolete service code		→ service code → ordering code	obsolete service code		→ service code → ordering code
c1	755 90	P 4822 146 00363	c1	804 25	
c1	755 91	P " 146 00353	c1	804 32	
c1	800 27	+ " 525 60094	c1	804 34	
c1	800 31		c1	804 35	
c1	800 44		c1	804 44	
c1	800 60		c1	804 45	
c1	800 75		c1	804 47	
c1	800 76		c1	804 49	
c1	801 04		c1	804 50	
c1	801 05		c1	804 57	
c1	801 51		c1	804 70	
c1	801 59		c1	804 71	
c1	801 72		c1	804 79	
c1	801 92		c1	804 81	
c1	802 03 0	+ 4822 264 30003	c1	804 91	
c1	802 09 0	+ 4822 140 40033	c1	805 01	
c1	802 12		c1	805 74	
c1	802 25		c1	805 77	
c1	802 26		c1	805 80	
c1	802 80		c1	805 81	
c1	802 86		c1	805 83	
c1	802 93		c1	805 84	
c1	802 95		c1	806 04	
c1	803 02		c1	806 16	
c1	803 09		c1	806 17	
c1	803 11		c1	806 20	
c1	803 27		c1	806 32	
c1	803 45		c1	806 44	
c1	803 50		c1	806 80	
c1	803 61	c1 807 80	c1	806 90	
c1	803 67	- 4822 492 50077	c1	807 07	
c1	803 72		c1	807 08	
c1	803 83		c1	807 11	
c1	803 89		c1	807 24	
c1	803 94		c1	807 25	
c1	803 96		c1	807 26	
c1	803 97		c1	807 80	+ 4822 281 30005
c1	804 00	JW 415 18 Cr 4822 194 00177	c1	807 91	
c1	804 06		c1	850 13	
c1	804 07		c1	850 29	+ 4822 522 30625
c1	804 12		c1	850 30	+ 4822 522 306 44
c1	804 15		c1	850 51	+ " 535 50037
c1	804 17		c1	850 56	+ " 525 60078
c1	804 20	AE 005 53	c1	850 86	+ " 522 20076
			c1	850 88	+ " 522 30624

obsolete service code		→ service code → ordering code	obsolete service code		→ service code → ordering code
C1 851 04			C1 903 59 0	+	4822 525 60081
C1 852 10			C1 903 99 0		
C1 853 94	+	4822 404 50017	C1 904 01 0	+	4822 463 30007
C1 853 95		C1 853 94	C1 904 02	+	" 522 30115
C1 854 56	+	4822 349 50001	C1 904 03	+	" 522 30116
C1 854 79	+	4822 535 50013	C1 904 05	+	4822 361 50003
C1 854 83			C1 904 19		P5 636 72/977
C1 855 36	-		C1 904 24	+	4822 522 30117
C1 855 55			C1 904 26		
C1 855 66	+	4822 525 60086	C1 904 28	+	4822 522 30118
C1 855 68	+	4822 525 60085	C1 904 29	+	4822 522 30119
C1 855 89	+	" 525 60088	C1 904 30		
C1 855 90	+	" 525 60087	C1 904 52		
C1 855 92	+	" 525 60089	C1 904 55	+	4822 492 50078
C1 856 21			C1 904 70		C1 904 72
C1 856 36			C1 904 72	+	4822 276 10007
C1 856 46			C1 904 75	+	" 535 50014
C1 856 47			C1 904 76	+	" 525 60025
C1 856 55	+	4822 358 20003	C1 904 78		C1 755 26
C1 856 56	+	" 281 30006	C1 904 81	+	4822 277 10017
C1 856 57		C1 856 56	C1 904 83	+	4822 404 50018
C1 856 83			C1 905 05	+	" 412 30004
C1 856 87	+	4822 142 70045	C1 905 09	+	" 280 60056
C1 900 19	+	" 522 301 07	C1 905 51	+	" 522 10056
C1 900 25	+	" 522 30108	C1 905 60 2	P	" 146 00319
C1 900 42	+	4822 522 30109	C1 905 74	+	4822 273 20008
C1 900 47	+	" 522 30111	C1 905 80	+	" 145 40002
C1 900 48	+	" 522 30112	C1 905 90	+	" 404 50098
C1 900 57	+	" 522 30113	C1 906 03		
C1 901 17	+	" 522 30114	C1 907 68	P	4822 146 00358
C1 901 73 0	+	4822 535 90009	C1 908 00	P	4822 146 00338
C1 902 00			C1 908 01	P	" 146 00339
C1 902 09		C1 610 53	C1 908 02	P	" 146 00341
C1 902 11	+	4822 463 50007	C1 908 08	P	" 145 00342
C1 902 13		C1 902 11	C1 909 30	P	" 146 00362
C1 902 35 0	+	4822 525 60023	C3 820 063/5	P	4822 126 00365
C1 902 36 0	+	" 525 60024	C3 820 063/6	P	" 126 00366
C1 902 61 0	+	" 693 50012	C3 820 063/7	P	" 126 00367
C1 902 62 0	+	" 693 50003	C3 820 063/8	P	" 126 00368
C1 902 91		C1 904 81	C5 820 356	P	" 126 00395
C1 902 92 0	+	4822 277 10016	C5 820 399	P	4822 126 00391
C1 903 06 0		T9 048 71	C5 820 400	P	" 126 00393
C1 903 07		OP 903 53	C5 820 468		" 126 00364
C1 903 15 0	+	4822 395 80004	C5 820 483	P	" 126 00389
C1 903 36	+	" 290 40033	C5 820 569		" 126 00355

obsolete service code	→ service code → ordering code	obsolete service code	→ service code → ordering code
20 010 05		20 361 19	LP 995 07
20 013 65		20 361 29	LP 995 07
20 016 55		20 361 39	LP 995 07
20 060 59		20 370 09	
20 061 05	LP 560 02	20 370 39	LP 147 17
20 071 10		20 370 59	LP 147 17
20 071 55		20 370 69	LP 147 17
20 071 65		20 402 27	
20 073 18		20 402 59	LP 990 08
20 073 35	LP 995 45	20 402 69	LP 995 08
20 100 29	LP 550 02	20 403 09	
20 133 09		20 403 29	
20 210 89	LP 995 00	20 404 09	LP 995 03
20 210 99	LP 995 01	20 900 19	LP 995 11
20 211 19	LP 995 01	20 900 39	LP 995 12
20 301 69		20 900 69	LP 453 53
20 301 89		20 950 19	LP 995 11
20 301 99		20 950 29	
20 302 09		20 950 39	LP 995 12
20 320 09	89 181 02	20 960 19	LP 995 11
20 320 19	89 181 04	20 970 39	LP 995 13
20 320 89		20 970 49	LP 995 13
20 330 29	LP 400 04	22 030 42	
20 332 79	LP 400 02	22 040 22	
20 333 09	LP 400 18	22 050 02.3	
20 345 08	LP 145 03	22 050 02.4	
20 350 59		22 070 14	
20 350 69		22 090 08	
20 350 99	LP 995 03	22 100 00	
20 351 29	LP 995 03	22 100 21	22 455 80
20 351 69	LP 575 02	22 100 22	22 455 80 +
20 351 79	LP 995 04		22 456 24
20 351 89	LP 995 04	22 100 60	22 455 80
20 360 29		22 100 61	22 455 80 +
20 360 39			22 456 24
20 360 49		22 120 43.1	R 287 KA/01
20 360 59		22 120 50	R 287 KA/01
20 360 79		22 130 57	4822 404 50067
20 360 89		22 130 98	" 404 50068
20 361 09	LP 995 07	22 130 99	" 404 50069

	obsolete service code	→ service code → ordering code		obsolete service code	→ service code → ordering code
a	22 265 88	P5 635 14/722NB		22 414 62	23 705 50
	22 265 95	* 4822 525 60052		22 414 68	- 4822 532 10184
	22 295 00	C1 904 24		22 414 69	+ 49 867 64
	22 295 09	C1 904 24			49 867 65
	22 295 20	C1 904 28		22 414 70	- 4822 492 60001
	22 295 31	C1 904 02		22 414 73	- 4822 503 90001
	22 295 44	C1 904 24		22 414 79	22 469 59
	22 295 63	C1 904 02		22 414 82	- 4822 522 30277
	22 406 23	916/GL50K		22 414 87	C1 660 71
	22 412 15	- 4822 273 40131		22 414 92	- 4822 381 10085
	22 413 24	- 4822 492 40001		22 414 93	22 414 92
	22 413 25	- " 492 40002		22 415 12	C1 755 19 +
	22 413 27	22 414 22			22 446 44
	22 413 32	2x 89 312 30 +		22 415 19	49 867 65
		2x 89 312 01		22 415 23	C1 317 57
	22 413 52	- 4822 522 30416		22 415 29	- 4822 535 80099
	22 413 54	- " 535 90037		22 415 38	22 469 59
	22 413 55	- " 535 80045		22 415 39	22 469 59
	22 413 60	- " 522 30274		22 415 42	C1 315 87
a	22 413 65	+ " 515 20011		22 415 43	- 4822 492 50001
	22 413 66	22 469 18	a	22 415 44	+ 4822 480 30048
	22 413 68	4822 522 30275		22 415 45	- " 532 50227
	22 413 72	22 414 34 +		22 415 46	C1 755 19 +
		22 444 30 +			22 446 44
		22 444 40 +		22 415 51	4822 530 80038
		22 414 02 +			
		C1 403 59		22 415 64	C1 404 22
	22 413 74	22 414 02		22 415 71	C1 404 23
	22 413 80	22 444 30		22 415 74	- 4822 522 30278
	22 413 81	22 444 35	a	22 415 75	- " 522 30279
	22 413 89	C1 904 03		22 415 78	+ " 532 50028
	22 413 91	22 444 40			
	22 414 02	- 4822 522 30417		22 415 84	- 4822 492 50002
	22 414 10	22 416 20 +		22 415 85	C1 404 34
		C1 904 28		22 415 93	C1 755 19 +
	22 414 22	- 4822 381 10132		22 415 94	22 446 44
	22 414 27	C1 404 64			22 416 54
	22 414 29	- 4822 535 80099		22 416 08	08 570 00
	22 414 34	- 4822 522 30276		22 416 09	08 570 00
	22 414 44	- " 535 80044		22 416 20	- 4822 525 10000
	22 414 47	- 4822 502 10304		22 416 31	22 416 20
	22 414 52	49 867 65		22 416 41	C1 404 25
	22 414 53	B 074 AP/3x24		22 416 44	4822 525 60094
				22 416 45	" 535 60054
				22 416 46	

obsolete service code	service code	ordering code	obsolete service code	service code	ordering code
22 416 47	C1 105 24		22 439 36	4822 381 40011	
22 416 54	4822 535 70044		22 439 40	976/4x16	
22 416 66	C1 200 00		22 439 43	4822 532 10094	
22 416 76	B 009 AA/3x 24		22 439 53	C1 317 57	
22 416 77	A9 866 75		22 439 54	4822 466 60001	
22 416 89	4822 451 10003		22 439 59	4822 532 10168	
22 416 96	" 522 30281		22 439 70	976/4x16	
22 416 99	22 448 00		22 439 74	976/4x16	
22 417 03	4822 360 20009		22 439 75	4822 381 20026	
22 417 04	C1 660 71		22 440 16	P5 635 14/722/NB	
22 417 07	4822 522 30418		22 440 40	23 705 14	
22 417 84	C1 406 27		22 440 50	4822 381 20004	
22 417 87	C1 407 67		22 440 53	" 049 00265	
22 431 73	22 443 70		22 440 65	" 380 20024	
22 433 48	935/F12E		22 440 68	A9 867 65	
22 433 71	R 287 KA/02AAO		22 440 70	22 380 20024	
22 437 99	4822 502 10305		22 440 73	A9 867 65	
22 438 03	" 492 50003		22 440 75	C1 904 55	
22 438 04	" 535 90113		22 440 80	4822 049 00267	
22 438 07	" 492 50004		22 441 75	4822 463 30014	
22 438 08	999/5x12		22 443 11	4822 049 00267	
22 438 09	4822 522 30419		22 443 12	C1 755 26	
22 438 13	C1 408 09		22 443 25	4822 535 80186	
22 438 18	C1 408 10		22 443 26	999/5x12	
22 438 19	22 443 85		22 443 30	4822 502 10306	
22 438 22	999/3x10		22 443 40	" 463 50015	
22 438 24	4822 492 40003		22 443 44	C1 607 74	
22 438 83	22 469 60		22 443 45	4822 535 80094	
22 438 90	22 440 50		22 443 70	22 443 44	
22 439 07	4822 525 60055		22 443 83	4822 526 20006	
22 439 10	4822 502 10225		22 443 85	" 492 60002	
22 439 17	22 439 19		22 443 85	4822 462 40055	
22 439 21	4822 380 30021		22 444 30	" 532 30282	
22 439 25	999/3x10		22 444 35	" 522 30283	
22 439 26	4822 535 50038		22 444 40	" 522 30284	
22 439 27	4822 381 20015		22 444 42	08 970 00	
22 439 28	22 439 27		22 445 78	A9 867 64 +	
22 439 30	22 439 27		22 446 40	A9 867 75	
22 439 32	4822 381 20011		22 446 41	" 843 44	
22 439 35	" 455 10016		22 446 42	C1 755 19	
				C1 755 19	
				22 446 44	
				C1 755 19	

	obsolete service code	→ service code → ordering code	obsolete service code	→ service code → ordering code
a	22 446 43	C1 408 60	22 463 85	A9 867 05
	22 446 44	4822 525 60073	22 463 86	A9 867 07
	22 446 45	4822 492 50005	22 463 87	A9 867 04
	22 446 46	22 446 44	22 465 01	A9 867 64
	22 446 47	22 446 44	22 465 04	C1 317 57
	22 446 48	4822 492 50006	22 465 08	A9 867 64 +
	22 446 49	22 446 44		A9 867 66
	22 446 50	C1 402 90	22 466 02	4822 358 10034
	22 446 51	C1 402 90	22 466 03	89 115 45/968
	22 446 52	C1 316 63	22 466 06	4822 532 30018
	22 446 53	C1 315 83	22 466 91	49 899 04
	22 446 54	C1 316 63	22 467 29	4822 380 30003
	22 446 55	4822 522 30285	22 467 36	" 395 80002
	22 446 56	" 522 30286	22 468 76	" 395 60013
	22 446 59	" 463 10001	22 469 18	" 535 70045
a	22 448 00	4822 480 50028	22 469 20	A9 008 32 +
	22 449 80	" 525 60026		E198 AE/A36A250 E
	22 450 86	" 381 80008	22 469 29	970/3x250
	22 451 45	" 380 20009	22 469 31	E198 AE/A36A2K5
	22 451 55	C1 904 24	22 469 48	A9 009 23
	22 451 56	C1 904 28	22 469 49	996/4x10
	22 451 96	4822 463 10002	22 469 59	4822 522 30421
	22 451 98	" 463 10003	22 469 60	" 255 20021
	22 452 69	22 532 37	22 469 63	22 469 70
	22 452 94		22 469 67	22 469 70
	22 453 30	4822 361 30064	22 469 68	4822 492 50007
	22 453 62	" 255 70089	22 469 69	" 290 10003
	22 453 69	C1 904 02	22 469 70	" 693 50058
	22 455 39	C1 904 02	22 469 92	A9 867 65
	22 455 80	4822 463 30012	22 470 10	E2 570 09
	22 455 82	22 455 80 +	22 472 39	4822 273 40132
		22 456 24	22 472 44	" 265 40023
	22 456 03	4822 532 50309	22 474 77	08 570 00
	22 456 11	22 542 74	22 481 17	976/4x16
	22 456 24	4822 463 30001	22 484 03	C1 904 02
	22 460 03	970/3x250	22 484 21	C1 904 02
	22 460 10	R 302 KA/235	22 485 15	22 547 32
	22 460 63	4822 466 80042	22 508 95	4822 525 20014
	22 460 71	" 522 30287	22 510 25	" 365 30018
	22 463 20	R 207 KA/02AA0	22 511 47	" 535 80027

1.9.1966

obsolete service code	→ service code → ordering code	obsolete service code	→ service code → ordering code
	482252230288		
	<del>2251148.1</del>		
22 511 48	- 4822 535 90038	22 519 37	C1 408 54
22 511 49	- " 522 30289	22 519 38	C1 705 62
22 511 51	- " 404 50003	22 519 41	- 4822 451 10001
22 511 52	- " 532 20006	22 519 44	- " 050 00214
22 511 54	-	22 519 49	- " 522 30293
22 511 57	- 4822 535 80047	22 519 60	22 541 76
22 512 96	- " 526 40096	22 519 62	C1 310 94
22 513 99	- " 413 50028	22 519 71	- 4822 535 50031
22 514 09	- " 502 10307	22 519 83	C1 700 71
22 514 21	- " 381 10088	22 519 84	- 4822 404 50001
a 22 514 34	+ 4822 450 60008	22 519 85	- 4822 404 50004
22 514 38	- " 532 60085	22 519 94	- " 463 40001
22 514 49	- " 522 30291	22 519 99	ND 961 91
22 514 83	- " 556 20008	22 524 16	- 4822 522 30623
22 514 84	- " 532 30074	22 524 20	- " 522 30294
22 514 99	- 4822 522 30292	22 524 80	22 532 37
22 515 05	- " 535 80164	22 526 13	- 4822 404 50005
22 515 13	22 515 05	22 526 14	X1 529 36
22 515 14	- 4822 492 50008	22 526 22	- 4822 522 30295
22 515 17	- " 520 40006	22 526 24	- " 522 30296
a 22 515 18	+ 4822 492 50009	22 526 25	22 414 34 +
22 515 36	- " 256 20007		22 444 30 +
22 517 49	- " 381 40012		22 444 40 +
22 517 59	- " 380 20002		22 414 02 +
22 517 70	22 542 74		22 526 22
22 517 85	- 4822 522 30501	22 526 26	22 417 03 +
22 517 92	- 4822 535 90039		22 526 24
22 518 24	- " 522 30502	22 529 89	R 302 KA/235
22 518 50	- " 522 30503	22 529 90	R 302 KA/235
22 518 62	996/4x10	22 532 22	- 4822 395 50011
22 518 68	- 4822 535 90136	22 532 23	- 4822 255 20003
22 518 69	- " 492 60003	22 532 37	- " 492 50012
22 518 70	- " 267 30067	22 534 62	C1 503 11
22 518 76	- " 380 30002	22 535 75	- 4822 450 80002
22 519 21	- " 492 50011	22 535 78	- " 450 80053
22 519 22	- 4822 525 60056	22 540 19	C1 904 28
22 519 23	- " 532 30134	22 540 20	22 416 20
22 519 27	- " 525 60027	22 540 95	- 4822 492 60004
22 519 28	- " 467 40084	22 541 00	- 4822 381 40013
22 519 36	C1 904 29	22 541 07	- 4822 404 50006

1.9.1966

obsolete service code	→ service code → ordering code	obsolete service code	→ service code → ordering code
22 541 06	4822 492 40004	22 740 98	22 443 70
22 541 11	23 705 37	22 741 14	22 414 02
22 541 13	4822 050 00213	22 741 17	C1 402 90
22 541 16	C1 610 36	22 741 20	22 415 74 +
22 541 18	4822 492 60005		22 415 75
22 541 27	4822 361 50094	22 842 84	08 570 00
22 541 48	" 278 90063	22 885 04	4822 381 40004
22 541 54	" 535 70046	22 900 16	A9 867 05
22 541 75	" 535 80048	22 900 18	4822 397 10015
22 541 76	" 522 30297	22 910 86	" 256 20033
22 541 97	08 520 25	22 926 30	89 181 03/20
22 542 12	4822 463 40002	22 926 40	89 181 03/20
22 542 14	23 705 15	22 930 13	4822 381 70001
22 542 25	4822 404 50128	22 945 00	22 440 50
22 542 26	" 417 60039	22 965 21	22 467 29
22 542 27	4822 402 60006	23 005 02	28 225 99
22 542 54	" 525 60057	23 005 21	967/2x4
22 542 56	" 492 60007	23 005 23	4822 290 60012
22 542 61	" 535 90145	23 009 10	978/M2x19
22 542 74	" 492 50013	23 009 51	S8 396 06
22 542 99	4822 358 10035	23 011 24	4822 462 70363
22 543 15	22 440 50	23 011 29	23 012 44
22 543 55	C1 406 90	23 011 87	23 012 44
22 544 01	4822 522 30298	23 012 09	978/1x4AA
22 544 02	" 522 30299	23 012 32	973/07
22 544 07	4822 404 50002	23 012 44/AA	4822 325 80069
22 544 13	C1 403 61	23 315 2E	978/4x3
22 544 14	C1 400 11	23 316 2E	978/4x3
22 544 15	22 446 56	23 503 29	4822 410 20361
22 544 55	4822 358 30063	23 539 60/AA	" 267 30025
22 544 63	C1 702 75	23 575 10/AA	4822 413 90002
22 544 66	C1 702 75	23 575 10/02 AF	23 575 10/02AA
22 544 89	4822 463 30013	23 607 10	F4 075 37/M3
22 545 98	" 528 50032	23 608 70	F4 075 91
22 546 00	" 528 50033	23 609 65/BT	4822 413 40039
22 546 83	4822 381 40009	23 610 58	973/14
22 547 32	" 381 80012	23 610 59	973/16
22 547 58	" 522 20016	23 610 60	4822 413 50446
22 547 74	" 492 40005	23 610 84	973/16
22 547 75	" 522 30298	23 612 12	23 612 12



obsolete service code	→ service code → ordering code	obsolete service code	→ service code → ordering code
23 612 92	973/14	23 664 86	978/2x12
23 613 31	23 610 60	23 664 87	978/2x12
23 613 45	23 610 60	23 667 63	973/03+973/P01
23 613 80	973/18	23 668 11	973/16
23 631 94	959/28	23 668 14/AA	4822 413 60019
23 641 41	959/39	23 668 19	4822 413 10014
23 642 07	959/39	23 668 36	" 413 60021
23 642 65	959/39	23 668 46/AA	" 411 50078
23 644 22	965/2.05x24	23 668 63	A3 784 42
23 644 41	P4 095 03/111/ AA	23 668 66	23 668 14
23 644 75/AA	4822 528 40041	23 668 89	4822 413 10015
23 645 15	E1 572 14.3	23 669 05	P5 310 00/138AA
23 645 16	23 646 76	23 673 51	967/8
23 645 17	967/Q6	23 673 52	967/8
23 646 76/04AB	4822 290 40052	23 673 53	967/8
23 646 77	E1 572 14	23 679 75	4822 413 70031
23 646 79	967/Q2	23 680 07	973/P02
23 646 80	967/Q8	23 680 09	973/P03
23 646 81	967/Q6	23 680 10	973/P04
23 646 82	967/Q4	23 680 48	973/DPO1
23 646 83	967/Q3	23 680 53	973/P01
23 646 84	967/Q2	23 681 33	965/2.05x24
23 647 78	23 647 95	23 681 81	965/2.05x24
23 647 95/3H03AA	4822 404 50094	23 681 89	4822 532 50228
23 649 72	" 268 40028	23 683 02	976/R54
23 650 24	976/8x6	23 683 21/AA	4822 459 40126
23 650 52	4822 532 60049	23 685 54	978/M2x19
23 650 76	P5 656 41/931/ GP	23 685 55	978/S2x19
23 652 28	A9 865 20	23 685 57	978/140AF
23 652 31	P5 192 01/152/ HA	23 685 59	978/1x4AA
23 652 40	A9 022 35	23 685 65	979/4x9
23 652 57	23 990 64	23 685 66	A9 600 38
23 652 78	967/Q2	23 685 94	976/2x19AF
23 653 19	23 650 52	23 686 01	976/3x19
23 653 37	4822 417 50027	23 686 02	978/M3x19
23 653 38	973/D02	23 686 09	976/R39
23 653 39	973/D03	23 686 36	973/01
23 653 40	973/D01	23 686 47	973/502
23 653 81	M7 704 49	23 686 48	973/503
23 662 25	23 705 3213	23 686 44	973/505

obsolete service code	→ service code → ordering code	obsolete service code	→ service code → ordering code
23 686 46	973/S04	23 709 54	4822 462 70287
23 686 48	973/S01	23 709 55	" 693 90096
23 686 84	A9 864 12.1	23 711 91	" 267 40018
23 686 94	4822 263 60002	23 721 99/AA	973/16
23 686 97/HA	" 447 60022	23 722 34	973/17
23 687 69	965/3x38	23 722 42	973/14
23 688 75	978/D27	23 722 44	975/18
23 688 76	978/D17	23 722 48	A9 864 21
23 688 80	978/D17	23 722 50	976/K47R
23 688 83/AA	4822 325 80001	23 722 50/000UB	976/K47W
23 688 90/AB	4822 454 40001	23 722 50/000UJ	976/K47G
23 693 04	965/2,05x14	23 722 50/000VL	976/K47R
23 693 11	965/2,05x14	23 722 58	A3 784 42
23 693 25	965/2,05x14	23 723 05	P4 665 13/910AA +
23 699 22	978/4x65		P4 665 12/910AA
23 699 23	978/4x65	23 723 06/10AA	P4 665 13/910AA +
23 699 28/NA	4822 532 60224		P4 665 12/910AA
23 699 29	" 411 50052	23 723 16	4822 263 40015
23 705 02	4822 413 60022	23 723 23	" 447 60001
a 23 705 04/AA	4822 413 60023	23 723 24	" 693 90077
23 705 06	22 469 60	23 723 25	973/15
23 705 09/AA	4822 693 50056	23 950 14	22 514 09
23 705 13	" 532 70022	23 950 15	22 513 99
23 705 14/AA	" 462 70194	23 950 73	4822 413 40047
23 705 15	" 413 60024	23 951 36	P4 075 91/417
23 705 17/AA	4822 693 50023	23 951 67	4822 413 90001
23 705 19/AA	" 693 50054	23 951 72	P4 075 91/417
23 705 25	22 541 76	23 951 83	972/06
23 705 30	22 469 60	23 951 85	972/06
23 705 32	4822 498 60122	23 952 88	P4 075 37/801/MI
23 705 33	C1 703 28	23 956 17/AT	4822 532 80037
23 705 37/AA	4822 693 50053	23 956 18/AT	" 693 90105
23 705 39/AA	" 413 30023	23 956 71	23 705 32
23 705 48/AA	" 413 50029	23 958 71	4822 693 90107
23 705 49	01 610 27	23 958 72/AT	" 532 80038
23 705 50	4822 462 70309	23 959 43/AT	4822 693 10029
23 705 53	C1 603 77	23 959 44/AT	" 532 80039
23 705 63	4822 462 70003	23 959 45	" 693 10031
23 707 31/AA	" 532 70077	23 959 46	" 532 80041
23 707 35	88 522 56	23 961 02	906/1A

obsolete service code	service code ordering code	obsolete service code	service code ordering code
23 990 47	967/Q3	24 858 22	4822 325 20026
23 990 48	E1 572 14	24 990 19	LP 461 25
23 990 49	967/Q6	24 990 28	LP 461 25
23 990 63.1	4822 290 60091	25 000 75	915/01
23 990 64	4822 290 60086	25 000 96	915/01
23 991 85	978/DS2x19	25 001 02	915/01
23 991 88	A9 866 21	25 001 06	915/01
23 994 32	4822 505 10212	25 001 08	915/01
23 996 61	F5 635 14/722/ NB	25 001 12	915/01
23 997 87	4822 263 60001	25 113 34	906/4K7
23 997 89	978/1x4AA	25 113 84	903/N4M
23 998 85	4822 459 40139	25 113 90	903/T1M
23 999 49	4822 505 10264	25 114 03	903/T20M
23 999 91	B8 703 01	25 114 28	908/30E
24 000 11	LP 423 09	25 114 61	913/2250+250
24 000 21	LP 423 11	25 114 86	906/100K
24 010 00	LP 405 21	25 115 02	903/V1M
24 010 21	LP 405 00	25 115 33	906/100K
24 030 04	LP 143 48 +	25 115 41	908/30E
	LP 456 19	25 115 49	903/V2M
		25 115 54	2x 903/K4M
24 030 11	LP 461 25	25 115 63	906/V22K
24 030 23	LP 461 25	25 115 66	903/T1M
24 040 00	LP 456 08	25 115 76	913/2250+250
24 040 08	LP 163 76 +	25 116 13	903/V2M
	LP 456 08	25 116 25	910/F50
24 110 87	LP 442 67	25 116 69	903/V2M
24 224 70	4822 280 60001	25 116 78	48 118 10/E16M
24 224 73	" 280 60002	25 161 32	976/4x16
24 224 91	" 280 30001	25 161 67	28 225 99
24 408 20	6891D	25 161 71	976/4x16
24 430 00	2x LP 505 01	25 161 72	976/4x16
24 490 08	LP 995 17	25 161 78	976/4x16
24 490 15	LP 995 19	25 161 79	976/4x16
24 610 17	LP 995 23	25 161 92	976/8x30
24 610 47	LP 995 27	25 390 74	914/50E
24 630 77	LP 995 31	25 497 43	978/34x19
24 733 00	LP 503 15	25 514 29	915/01
24 740 91	4822 264 50015	25 514 89	915/01
24 740 92	" 264 40015	25 514 95	915/01
24 773 60	LP 540 00	25 646 52	572/05

obsolete service code	→ service code → ordering code	obsolete service code	→ service code → ordering code
25 655 42	975/4,5x4		
25 655 44	975/5,5x4		
25 655 46	975/7x4		
25 655 47	975/7x4		
25 655 48	975/7x8		
25 655 49	975/9x5		
25 655 51	975/11x6		
25 655 53	08 008 84		
25 655 54	975/11x6		
25 655 55	975/13x8		
25 655 56	975/13x8		
25 655 57	975/9x5		
25 655 58	975/11x5		
25 655 59	975/13x5		
25 655 69	975/3.5x4		
25 655 95	975/8x10		
25 656 03	975/20x17		
25 660 93	963/2.2		
25 668 38	49 891 71		
25 715 65	933/P50K		
25 718 28	900/P15K		
25 721 31	914/3K5		
25 741 01	978/22		
25 741 27	978/22		
25 754 42	979/S1		
25 812 05	979/15		
25 815 47	979/1		
25 840 03	938/B1K		
25 840 17	914/500E		
25 840 39	48 762 01/750E		
	48 762 01/50E		
25 864 96	973/18		
25 865 55	915/03		
25 865 59	940/RP5 or 940/RP6		
25 870 47	B6 352 93		
25 872 06	906/V22K		
25 872 25	915/04		