

FILM-TECH

THE INFORMATION CONTAINED IN THIS ADOBE ACROBAT PDF FILE IS PROVIDED AT YOUR OWN RISK AND GOOD JUDGMENT.

THESE MANUALS ARE DESIGNED TO FACILITATE THE EXCHANGE OF INFORMATION RELATED TO CINEMA PROJECTION AND FILM HANDLING, WITH NO WARRANTIES NOR OBLIGATIONS FROM THE AUTHORS, FOR QUALIFIED FIELD SERVICE ENGINEERS.

IF YOU ARE NOT A QUALIFIED TECHNICIAN, PLEASE MAKE NO ADJUSTMENTS TO ANYTHING YOU MAY READ ABOUT IN THESE ADOBE MANUAL DOWNLOADS.

WWW.FILM-TECH.COM



KELMAR

Systems Inc., 284 Broadway, Huntington Station, NY 11746 • 631.421.1230 • FAX 631.421.1274

Christie AMK Automation Terminations

TB-1

1	GROUND
2	120VAC NEUTRAL FEED
3	120VAC LINE FEED
4	CHANGEOVER FEED
5	CHANGEOVER OPEN
6	CHANGEOVER CLOSE
7	MOTOR IN
8	MOTOR OUT
9	LAMP IN
10	LAMP OUT
11	FEED TO FAILSAFE
12	RETURN FROM FAILSAFE
13	ALARM
14	FORMAT CUE
15	SHOW END CUE
16	LENS 
17	LENS 
18	GROUND
19	GROUND
20	AUX. FEED
21	AUX. PULSE
22	AUX. PULSE
23	
24	
25	



KELMAR

Systems Inc., 284 Broadway, Huntington Station, NY 11746 • 631.421.1230 • FAX 631.421.1274

Christie AMK Automation Terminations

TB-2

26

27

EXCITER IN

28

EXCITER OUT

29

ALARM

30

31

REMOTE START

32

GROUND

33

CURTAIN OPEN (LIGHT CURTAIN OFF)

34

LIGHT CURTAIN ON

35

CURTAIN FEED

36

CURTAIN CLOSE

37

DIMMER RAISE

38

DIMMER DOWN

39

DIMMER FEED

40

MUSIC OFF

41

MUSIC ON

42

MUSIC FEED IN

43

MASKING FEED

44

MASKING

45

MASKING

46

K8 SPARE RELAY COIL

47

K8 SPARE RELAY COIL

48

K8 SPARE RELAY FEED

49

K8 SPARE RELAY N.C. CONTACT

50

K8 SPARE RELAY N.O. CONTACT