Film-Tech

The information contained in this Adobe Acrobat pdf file is provided at your own risk and good judgment.

These manual s are designed to facil itate the exchange of information rel ated to cinema projection and film handling, with no warranties nor obligations from the authors, for qualified field service engineers.

If you are not a qual ified technician, pl ease make no adjustments to anything you may read about in these Adobe manual downloads.

www.film-tech.com



LU-142 MONITOR SPEAKER

.

G-1986	Terminal Strip
G-1987	Cabinet
G-1988	Cabinet Cover
H-2025	Speaker Fastening Screw (4)
H-2716	Terminal Strip Fastening Screw (2)
H-3101	Nameplate Fastening Screw (2)
H-3248	Speaker Fastening Nut (4)
P-1145	Speaker Lockwasher (4)
P-1278	Terminal Strip Lockwasher (2)
P-1917	Speaker Washer (4)
P-2326	Monitor Speaker
P-2383	Cover Acoustic Baffle
P-2761	Cover Fastening Screw (4)
P-2763	Cabinet Acoustic Baffle
P-2765	Nameplate
P-2822	Speaker Spacer (4)

2-1