Film-Tech

The information contained in this Adobe Acrobat pdf file is provided at your own risk and good judgment.

These manual s are designed to facil itate the exchange of information rel ated to cinema projection and film handling, with no warranties nor obligations from the authors, for qualified field service engineers.

If you are not a qual ified technician, pl ease make no adjustments to anything you may read about in these Adobe manual downloads.

www.film-tech.com



SDDS Player System

DIGITAL FILM SOUND DECODER DFP-D2000

DIGITAL FILM SOUND READER

Sony Dynamic Digital Sound ---OPERATION MANUAL <u>Japanese/English</u> Ist Edition (Revised 2) Serial No. 10001 and Higher (DFP-D2000) Serial No. 10001 and Higher (DFP-R2000)

Overview	2(E)
System Configuration	
Location and Function of Parts	5(E)
Notes on Use	
Operation	
Loading Film	9(E)
Operating the DFP-D2000	
Specifications	
SDDS Digital Audio Signals	
General	
I/O Characteristics	13(E)
Accessories and Related Equipment	

The SDDS (Sony Dynamic Digital Sound)¹⁾ Player System is comprised of the DFP-R2000 Digital Film Sound Reader and the DFP-D2000 Digital Film Sound Decoder.

The system reads digital audio data recorded on 35 mm movie film in the SDDS format, and feeds high quality digital sound to a theater sound system.

The features of this system include the following.

Playback of 8 channels of SDDS-format digital audio

The system can read 8 channels of digital audio signals recorded in the SDDS format on the P (picture) and S (sound) sides of the film. It features digital processing, for little or no signal degradation during playback.

P side	C (center) L (left) LC (left center) SL (surround left)
S side	R (right) RC (right center) SR (surround right) SW (sub-woofer)

In addition, the following four channels of compensation signals are read from the opposite sides of the film.

P side	Rmix (mixed R, RC and SR) SW' (compressed SW)
S side	Lmix (mixed L, LC and SL) C' (compressed C)

1) SDDS is a registered trademark of Sony Corporation.

Bypass output of analog audio signals

If necessary, analog audio signals recorded on analog tracks can be output directly during SDDS operation (bypass output). There are two bypass modes—software bypass and hardware bypass. Normally the software bypass mode is selected.

Software bypass

Analog audio signals are output automatically when there are no digital audio signals recorded on the film, or when digital audio signals cannot be read properly.

Hardware bypass

Pressing the DFP-D2000 BYPASS button enables analog audio input signals to be always output directly.

No modifications to the projector needed

You can convert a conventional projector into an SDDS projector simply by installing the DFP-R2000. No modifications to the projector are required.



System configuration

The DFP-R2000, installed on the film projector, reads the digital audio signals recorded on the film and sends them to the DFP-D2000. The DFP-D2000 converts digital audio signals received from the DFP-R2000 into analog audio signals and sends them to the theater sound system.

The IBM PC/AT^{1} or compatible computer is used to initialize DFP-D2000 when it is first installed and to make settings for the theater sound system.

1) IBM and PC/AT are registered trademarks of International Business Machines Corporation.

Location and Function of Parts

DFP-R2000



DFP-R2000

1 Front cover

To load film, open the unit by pulling the left edge of the front cover forward.

2 Upper tension arm

Adjusts film tension.

3 Upper lock arm

Locks and releases the upper tension arm 2.

4 Sprocket

5Lower lock arm

6 Lower tension arm Adjusts film tension.

7 Tension indicator

Shows whether or not film tension is appropriate.

Location and Function of Parts

DFP-D2000

Front panel



1 Power switch

2 Level meters

Show the level of each channel.

③ PROJECTOR indicators

During playback with a changeover system, show which of the projectors is currently in use. If there is trouble with either of the DFP-R2000 units, the PROJECTOR indicator (1 or 2) corresponding to the projector connected to that DFP-R2000 unit flashes.

4 MASTER LEVEL display

Shows the master level in increments of 0.1 dB.

5 MASTER VOLUME dial

Adjusts the master volume.

6 MUTE button

Press this button, turning it on, to mute system output. The mute function suppresses output of analog signals converted from the digital signals read by the DFP-R2000.

7 BYPASS button

Press this button, turning it on, to suppress output of analog signals converted from digital signals, and enable direct output of analog audio signals input to the SYSTEM INPUTS or AUX IN connectors (hardware bypass function).

3 SYSTEM OK indicator

- Lights when the system is operating normally, and goes out when a system error occurs.
- Goes out to indicate a system warning, for example that the fan has stopped rotating or that there is no backup battery.

9 DATA PRESENT indicator

Lights when the unit is reading digital audio signals. Goes out during automatic output of analog audio signals input to the SYSTEM INPUTS or AUX IN connectors (software bypass function).

O REMOTE indicator

Lights when the system is being controlled remotely.

For more information about remote control, contact your SDDS dealer.

Connector panel



DFP-D2000 connector panel

O BYPASS INPUTS connectors

Input analog audio signals for each channel.

2 AUX-IN connector

Input THX[®]-standard analog audio signals for each channel. These connectors are connected in parallel with the BYPASS INPUTS connectors **①**.

3 READER I/O connectors

Connect to the DFP-R2000 for input of digital audio signals read from the film. Use the PROJ 1 connector in a system with one projector, and use both the PROJ 1 and PROJ 2 connectors in a changeover playback system.

$\mathbf{O} \sim \mathbf{AC}$ IN socket

Connect the supplied power cord.

6 RS-232C connector

Connect an IBM PC/AT or compatible computer.

6 AUTOMATION I/O connector

This is a connector for automatic system control. For details, contact vour SDDS dealer.

7 SYSTEM OUTPUTS connectors

Output analog audio signals, consisting of D/A converted digital audio signals read from the film or analog audio bypass input signals.

B AUX-OUT connector

Output THX[®]-standard analog audio signals, consisting of D/A converted digital audio signals read from the film or analog audio bypass input signals. These connectors are connected in parallel with the SYSTEM OUTPUTS connectors **7**.

9 SDDS REMOTE connector

Connect to an SDDS remote control unit. For details, contact your SDDS dealer.

- Installation of this system must be carried out by the SDDS dealer.
- There are no user adjustments or user-replaceable parts inside the DFP-D2000; do not open the front panel.

Handling SDDS film

- Avoid marking the SDDS data tracks using either adhesive labels or ink. If it is essential, keep any marks within a single frame.
- The splice length should also be not more than a single frame.

Operation

Loading Film



Film loading path in the DFP-R2000

- 1 Mount the supply reel and the takeup reel.
- **2** Open the front cover of the DFP-R2000 and the cover of the projector.
- **3** Raise the upper lock arm of the DFP-R2000, release the upper tension arm, and then lower the lower lock arm.
- **4** Pull out a suitable length of film from the supply reel, and feed it along the path indicated in the diagram, as follows.
 - **35 mm film recorded in SDDS format:** solid line in the diagram (indicated in the DFP-R2000 by a blue line)
 - 70 mm film or 35 mm film not recorded in SDDS format: broken line in the diagram
- **5** Return the upper and lower lock arms to their original positions to tension the film.
- 6 Check to be sure that the red line of the tension indicator is at the tip of the triangle. If not, release the upper tension arm, adjust the film position so that the tension indicator red line is at the tip of the triangle, and return the tension arm to its original position.
- **7** Pass the film through the projector and take it up on the takeup reel, just as you would with ordinary movie film.
- 8 Close the front cover of the DFP-R2000 and the cover of the projector.

Operating the DFP-D2000



Control block of the DFP-D2000

To adjust the master level

Rotate the MASTER VOLUME dial.

To mute the audio output

Press the MUTE button. The button lights in red, and the output is muted.

To select hard bypass output of analog audio input Press the BYPASS button.

The button lights in yellow, and analog audio signals input to the BYPASS INPUTS or AUX IN connectors are output without change from the SYSTEM OUTPUTS and the AUX-OUT connectors.

When using a changeover system with two projectors

One of the PROJECTOR indicators lights to show which of the projectors is currently in use.

If the SYSTEM OK indicator does not light

There is trouble somewhere in the system. Contact your SDDS dealer.

Note

To change the initial system settings after installation, or to make acoustic adjustments, use an IBM PC/AT or compatible computer connected to the system.

For details, contact your SDDS dealer.

SDDS Digital Audio Signals

Number of channels Channel assignments	8 Channel 1: Left Channel 2: Left center Channel 3: Center Channel 4: Right center Channel 5: Right Channel 6: Sub-woofer Channel 7: Surround left
	Channel 8: Surround right
Sampling frequency	44.1 kHz
Frequency response	20 Hz to 20 kHz ±1.0 dB
Dynamic range	More than 90 dB
Distortion	Less than 0.07%
Crosstalk	Less than -80 dB
Output level	Low: -10 dBu balanced (adjustable on site)
	High: +4 dBu balanced (factory default)
Headroom	20 dB

Specifications

General

DFP-R2000 Digital Film Sound Reader

DC +24 V (1 A) Power requirements Power consumption 24 W Operating temperature 5°C to 40°C (41°F to 104°F) Operating humidity 10% to 90% (relative humidity) -20° C to $+60^{\circ}$ C (-4° F to $+140^{\circ}$ F) Storage temperature 10 kg (22 lb) Mass Dimensions (w/h/d; excluding projections) $325 \text{ mm} \times 158 \text{ mm} \times 232 \text{ mm}$ $(12^{7}/8 \times 6^{1}/4 \times 9^{1}/4 \text{ inches})$ 35 mm Film width

DFP-D2000 Digital Film Sound Decoder

Power requirements	100 V AC (Japan) 120 V AC (United States and Canada) 230 to 240 V AC (Europe) 50/60 Hz	
Power consumption	200 W (United States, Canada and Japan) 2.3 A (Europe)	
Operating temperature	5°C to 40°C (41°F to 104°F)	
Operating humidity	10% to 90% (relative humidity)	
Storage temperature	-20° C to $+60^{\circ}$ C (-4° F to $+140^{\circ}$ F)	
Mass	Approx. 14.5 kg (31 lb 15 oz)	
Dimensions (w/h/d; including projections)		
	464 mm × 143 mm × 490 mm	
	$(18^{3}/8 \times 5^{3}/4 \times 19^{3}/8 \text{ inches})$	
EIA rack mount space	3 units	
Lock-in time	1 second max.	
Lock range	Rated speed ±5%	
Sync drift	20 msec max.	
Sync drift rate	10 Hz/sec max.	

I/O Characteristics

DFP-R2000

READER I/O connector CCZ-A (1)

DFP-D2000

	BYPASS INPUTS connectors				
		L, LC, C, RC, R, SW, SL, SR XLR 3-pin, female (8)			
		Reference level	+4dBu/-10dBu		
		Maximum level	+24dBu/+10dBu		
		Impedance			
		Connected in para connector.	allel with AUX-IN		
SYSTEM OUTPUTS connectors					
		L, LC, C, RC, R, SW, SL, SR XLR 3-pin, male (8)			
		Reference level			
		Maximum level	+24dBu/+10dBu		
		Impedance	100Ω max.		
		Connected in parallel with AU			
	connector.				
	AUX-IN connector	D-sub 25-pin, female (1) Connected in parallel with BYPASS INPUTS connectors.			
	AUX-OUT connector	D-sub 25-pin, male (1) Connected in parallel with SYSTEM OUTPUTS connectors.			
	READER I/O connectors	PROJ 1, PROJ 2 CCZ-A(2)			
	SDDS REMOTE connector	D-sub15-pin, male (1)			
	RS-232C connector	D-sub 9-pin, famele (1)			
	AUTOMATION I/O connector				
		D-sub 37-pin, ma	ale (1)		

Accessories and Related Equipment

Aaccessories supplied

DFP-R2000

Fly wheel (1 set) Operation guide (1) Reader cable (CCZ-A) (1) Reader mount kit (1 set)

DFP-D2000

Operation manual (1) Power cord (1)

Required equipment for a changeover system

For details, contact your SDDS dealer.

Required customer supplied equipment (when external control is required)

IBM PC/AT or compatible

Design and specifications are subject to change without notice.