## Film-Tech

The information contained in this Adobe Acrobat pdf file is provided at your own risk and good judgment.

These manual s are designed to facil itate the exchange of information rel ated to cinema projection and film handling, with no warranties nor obligations from the authors, for qual ified field service engineers.

If you are not a qual ified technician, pl ease make no adjuatments to anything you may read about in these Adobe manual downloads

www.film-tech.com

## **Sony Cinema Products Corporation**

## **SONY**®

## Tech Note

New pin definitions for the DFP-D3000 AUTOMATION connector for units having firmware v2.60 and later.

Product:	DFP-D3000.
S/N:	All units with firmware version 2.60 and higher.
Document:	TN99042801, CC
Summary:	New definitions of DFP-3000 AUTOMATION connector pins that result from new
	firmware, v2.60 and later.

A number of new features and improvements have been made in firmware v2.60 and later. In order to do this, a number of the pins on the AUTOMATION connector have been changed and have improved functions. Below is a list of all the pins, with changes highlighted.

Pin	Function	Signal
1	Chassis Ground	GND
2	Projector 1 Motor Start	Input: Low = MOTOR 1 RUNNING
3	Master Mute command	Input pulse: Low = MUTE or UNMUTE
4	Preset 1 Select (and tally pulldown)	Input pulse: Low = SELECT
5	Preset 2 Select (and tally pulldown)	Input pulse: Low = SELECT
6	Preset 3 Select (and tally pulldown)	Input pulse: Low = SELECT
7	Preset 4 Select (and tally pulldown)	Input pulse: Low = SELECT
8	Preset 5 Select (and tally pulldown)	Input pulse: Low = SELECT
9	Preset 6 Select (and tally pulldown)	Input pulse: Low = SELECT
10	Preset 7 Select (and tally pulldown)	Input pulse: Low = SELECT
11	Preset 8 Select (and tally pulldown)	Input pulse: Low = SELECT
12	Motor 1	Output tally: Low = MOTOR 1 RUNNING
13	Motor 2	Output tally: Low = MOTOR 2 RUNNING
14, 15	Logic Common	0 V
16, 17	Tally Common	0 V
18	Optical Change Over Command	Input: Low = PEC 2, High = PEC 1
19	Optical Change Over Tally	Output tally: Low = PEC 2 selected
20	Projector 1 Tally	Output tally: Low = SDDS Reader 1
21	Projector 2 Tally	Output tally: Low = SDDS Reader 2
22	Master Mute Tally	Output tally: Low = Master muted
23	Pink Noise	Input: Low = ON
24-29	Reserved	No Connections
30	+5V	Power
31	-5V	Power
32	SDDS Data OK (any preset active)	Output pulse: Low = SDDS OK
33	Projector 2 Motor Start	Input: Low = MOTOR 2 RUNNING
34	AUX1 Digital Data OK	Input: Low = Data OK
35	AUX2 Digital Data OK	Input: Low = Data OK
36	SDDS Data not OK	Output pulse: Low = SDDS NG
37	Reserved	